

Index

Note to the Reader: Throughout this index **boldfaced** page numbers indicate primary discussions of a topic. *Italicized* page numbers indicate illustrations.

- Absolute coordinates
 - puzzler, **412**
 - solution, **421–422**
- ACAD.CUI file, 60, 83
- ACAD.LIN file, **98–101**
- ACAD.LSP file, 308
- ACAD.MNS file, 60
- ACAD.PAT file, 81
- ACAD.PSP file, 68–72
- ACADDOC.LSP file, 60, 308
- ACADISO.LIN file, 98, **100–101**
- ACADISO.PAT file, 81
- ACADLSPASDOC variable, 308
- accurate drawings, **9**
- actions for dynamic blocks, 166
- Activate AutoCAD button, 281, 281
- actual size drawings, 2–3, 3
- ADC (AutoCAD DesignCenter)
 - for blocks, 170, 171
 - and workstations, 58
- Add Watch dialog box, 317, 318
- AIA (American Institute of Architects)
 - layer standards, 149
- ALERT function, 358
- ALIASEDIT tool, 72
- aliases, command, 68, **72**
- aligned dimensions, **30, 30**
- Allow Exploding option, 159
- Allow Other Users To Refedit Current Drawing option, 50
- Alternate Units tab
 - architectural dimensions, 123
 - mechanical dimensions, **114–115, 115**
- Always Keep Text Between Ext Lines option, 113, 121, 127
- American Institute of Architects (AIA)
 - layer standards, 149
- ampersands (&) in menu names, 90
- AND operator, 339
- angconv.lsp program, 299–301
- angles
 - increments, 19
 - interior, **18–20, 19**
 - points from, **292–294**
 - precision, 15
- ANGTOS function, **296–297**
- animation in debugging, **322**
- annotating programs, **328–330**
- anonymous blocks, dimensions as, **106–107, 158**
- APERTURE variable, **33, 326**
- APPLOAD command, 279, 306–307
- architectural dimensions, **119, 119**
 - Alternate Units tab, 123
 - child styles, **123–125, 123–125**
 - feet and inches, 119
 - Fit tab, **121–122, 121, 124, 124**
 - Lines tab, **119, 119**
 - metric, **125–126**
 - Primary Units tab, **122, 122**
 - rules for, **131–133**
 - Symbols And Arrows tab, **120, 121, 123**
 - Text tab, **120–121, 121, 124, 124**
 - Tolerances tab, 123
- architectural lineweights, **142**
- archiving files, **44, 44**
- arcs, tangent, **20–21, 21**
- AREA command, **21–23**
- ARG files, 56
- ARRAY command, 14, **17, 139**
- Array dialog box, 14, 14
- arrays
 - for circular center lines, 139
 - polar, **16, 16**
 - rectangular, **14–16, 14**
- Arrow keys, 208
- arrowheads
 - appearance, 112, *112*, 120
 - custom, **109**
 - with leaders, 215
- .arx extension, 307
- ASCII files, 64
- ASME version, mechanical dimensions, **117–118**
- ASSOC function, **331, 334**
- association lists, 334
- associative dimensions, **107–108, 215**
- asterisks (*)
 - with dimension names, 106
 - for SSGET, 339
- at sign symbols (@) for starting drawings, 20
- ATOF function, 297
- ATOI function, 297
- atoms, 341–342
- attaching XRefs, **183–184, 183, 185**
- ATTDEF command, 174–175
- ATTDISP command, 174, 178
- ATTEDIT command, 174
- ATTEXT command, 174, 178, 180–181
- ATTREDEF command, 174
- ATTREQ command, 174
- Attribute Definition dialog box, 175, 175
- Attribute Extraction wizard, 178, 179
- attributes, **172–173, 172–173**
 - adding, **175–176, 175–176**
 - defining, **173–174, 177–178, 178**
 - modes, **176–177**
 - value extractions, **178–182, 179, 181–182**
- ATTSYNC command, 174
- AUGI (Autodesk User Group International), **39**
- AUPREC variable, 15
- Auto option in UNDO, 29
- Auto Tracking, 20
- AutoCAD DesignCenter (ADC)
 - for blocks, 170, 171
 - and workstations, 58
- Autodesk User Group International (AUGI), **39**
- AutoLISP programs, **259–260, 273, 311**
 - annotating, **328–330**
 - AUGI for, **39**
 - background, 274
 - for block definitions
 - drawings from, **270**
 - redefining, **267–268**
 - calculations. *See* calculations
 - command-line for, **278**
 - commands and functions, **274, 276–277**
 - CIRCLE, **286**
 - COND, INITGET, and GETKEYWORD, **354–357**
 - GET, **290–294**
 - IF, **342–347**
 - REPEAT, **348–350**
 - WHILE, **351–354**
 - ZX, **283–285, 283**
- debugging. *See* debugging techniques
- DOS in, **360–364, 364**
- editor, **279–282, 280–281**

entering, 277–278
 error handling, 325–328
 for file size reductions, 264
 finding, 275
 inserting drawings, 286–287
 loading, 306–310
 managing, 308
 OVERKILL tool
 puzzler, 419
 solution, 433
 for points, 290–294
 puzzlers
 question, 415
 solution, 424–425
 rules for, 305–306
 saving, 278–279
 selection sets and entity
 manipulation, 331
 ASSOC, ENTGET, and
 ENTSEL, 331–337
 SSGET, 338–341
 structure, 276–277
 text and string manipulation,
 357–360, 358
 troubleshooting, 261
 variables, 287–288, 312
 writing, 275–276
 automatic batch files, 67–68, 67–68
 automatic program loading, 306–310
 Automatic Save File Location option, 61
 Automatic Save setting, 49–50
 automating scaling, 221
 Autosave files, 42–43, 43
 Average function, 192

B

Back option, 29
 backing up files, 24, 42, 66–67
 Backspace key, 249
 BACKUP.BAT file, 67
 BASE command, 162
 basic linetypes, 98–99
 .bat extension, 65
 batch files
 automatic, 67–68, 67–68
 for backups, 66–67
 for block definitions
 drawings from, 269
 redefining, 266–267
 DOS, 63–68, 67–68
 for file size reductions, 262–263, 265
 logon, 65–66
 troubleshooting, 261
 for updates, 259
 batting, blown-up
 puzzler, 419
 solution, 432
 BATTMAN tool, 174, 176
 BBegin option, 29
 benchtest.scr script, 253–256, 255–256
 best practices, 5–12
 BHATCH command, 309
 Bind option, 185–186
 bit codes, 355
 bit-flag values, 70
 BLANK tag, 181
 BLOCK command, 158–159, 163, 170
 Block Definition dialog box,
 158–159, 159
 Block option, 160
 “Block references itself” errors, 160–161
 BLOCKICON command, 171
 BLOCKOUT.BAT file, 269
 BLOCKOUT.LSP, 270
 BLOCKOUT.SCR file, 269–270
 blocks, 155–156, 156
 anonymous, 106–107, 158
 attributes for. *See* attributes
 basics, 156–158
 benefits, 6
 commands for
 BASE, 162
 BLOCK, 158–159, 163
 INSERT, 162–163, 162
 REFEDIT, 163–164
 WBLOCK, 159–162
 definitions
 drawings from, 269–271
 redefining, 265–268
 dynamic, 165
 existing blocks for, 167
 objects for, 165, 166
 editor, 163
 invisible
 puzzler, 420
 solution, 434
 for layers, 164–165
 nesting, 162
 in Paper Space, 202–203
 in plotting, 197
 redefining, 163
 scaling
 puzzler, 417, 417
 solution, 428, 428
 in symbol libraries, 170, 171
 tool palette references to, 75–76, 76
 updating, 164
 in XRefs, 185–186
 blown-up batting
 puzzler, 419
 solution, 432
 Boole, George, 387
 Boolean algebra, 387
 Both Text And Arrows option, 113, 121
 bound XRefs
 puzzler, 420, 420–421
 solution, 434

BOUNDARY command
 for polylines, 431
 for selections, 17–18, 17, 401
 brackets ([]) in linetype definitions, 100
 BREAK command, 137–138
 breakpoints, 281, 319–322
 breaks in layouts, 231–234, 232–235
 broken absolute coordinates
 puzzler, 412
 solution, 421–422
 broken AutoLISP programs
 puzzler, 415
 solution, 424–425
 broken Delete key
 puzzler, 413
 solution, 423
 Bug Watch feature, 60
 Build Output window, 279, 280
 buttons
 icons, 89
 macros for, 87–89, 87–88
 ByLayer
 for lineweights, 35, 142, 242
 for properties, 7–8

C

CADDR function, 332
 CADR function, 332–333
 calculations, 294
 area, 21–23, 23
 basics, 294
 combining functions, 303–304,
 303–305
 math functions, 294–295
 in programs, 295–296
 radian and degree conversions,
 297–301, 299
 string and number conversions,
 296–297
 transparent functions, 302, 302
 camel case, 327
 CAR function, 332–334
 Cartesian coordinate system, 387
 case sensitivity, 277
 CDF (comma delimited) format, 182
 CDR function, 332–333, 335
 cells, table, 192
 CELTSCALE variable, 33
 center lines and center marks, 138–141,
 139–141
 CHAMFER command, working with, 26
 changed variables
 puzzler, 419
 solution, 431–432
 Check Edit Window button, 281, 282
 child styles
 architectural dimensions, 123–125,
 123–125
 mechanical dimensions, 116, 117

- chlts.lsp program, 336–337
- CHSPACE tool
 - benefits, 38
 - in Express Tools, 203, 214
 - puzzler, 420
 - in scaling, 220
 - solution, 433–434
- CIRCLE command
 - improving, 286
 - for tangent arcs, 20–21, 21
- circular center lines and marks, 139–141, 139–141
- civil and surveying dimensions, 126
 - Fit tab, 127, 127
 - Lines tab, 126, 126
 - Primary Units tab, 127–130, 127
 - Text tab, 127, 127
- CLEANSCREENOFF command, 46
- CLEANSCREENON command, 46
- clipped objects, 209
- clunky commands, 208
- CMD command, 64
- CMDECHO variable, 323–324
- code testing, 312–315, 313–315, 322–325
- color
 - layer, 153–154
 - Visual LISP editor, 281
- color-dependent plot styles, 241
- color tables vs. style tables, 143
- combining functions, 303–304, 303–305
- Comeau, Meridith, 366–367
- comma delimited (CDF) format, 182
- Comma Separated Value (CSV)
 - format, 180
- COMMAND function, 284
- command-line, 13
 - ARRAY, 15
 - AutoLISP, 278
 - switches, 58, 59
- Command Tools tab, 82
- commands
 - aliases, 68, 72
 - AutoLISP, 274
 - clunky, 208
 - command-line, 13
 - display, 35–36
 - DOS, 64–65
 - edit, 25–32, 26, 28, 30
 - external, 68–72, 69, 72
 - names, 284
 - settings, 32–33
- commas (,) in linetype definitions, 99
- Comment Block button, 281, 282
- commercial projects, layer names in, 149–152
- Communications Center, 58, 59
- complex linetypes, 100–103, 101–103
- computers
 - bench testing script, 253–256, 255–256
 - sluggish, 254
- COND function, 354–357
- conditional operators, 339
- consistency
 - in layer names, 7
 - in Paper Space, 208
- Console, Visual LISP editor, 279, 280
- Constant mode for attributes, 176
- construction lines, 17
- Continue button, 281, 281
- Control option, 29
- conversions
 - inches to millimeters, 295–296
 - radians and degrees, 297–301, 299
 - strings and numbers, 296–297
 - tables, 241–242
- Convert To Block option, 159
- CONVERTCTB command, 241
- CONVERTPSTYLES command, 241–242
- coordinates
 - absolute
 - puzzler, 412
 - solution, 421–422
 - points from, 291–292
 - user coordinate system, 370–372, 371–372
 - world coordinate system, 369, 371
- Copy With Base Point option, 203
- copying attributes, 175
- CopyRotate command, 92, 93
- Count function, 193
- Create Separate Hatches option, 218
- Create Tool Palette option, 76
- crossing lines rule, 131
- CSV (Comma Separated Value)
 - format, 180
- Ctrl key in debugging, 316
- CUI (Customizable User Interface), 73, 83
 - keyboard shortcuts, 93–97, 95–97
 - menu editing
 - cursor, 91, 92
 - grips, 92, 93
 - pull-down, 89–90, 90–91
 - toolbars
 - button macros, 87–89, 87–88
 - creating, 84–86, 84–86
- Current option, 370
- Current VP Freeze property, 209
- cursor menus, 91, 92
- Customizable User Interface. *See* CUI (Customizable User Interface)
- Customize dialog box, 76–78, 77
- customizing fields, 189–190, 189
- CYLINDER command, 404
- Danis, Scott, 327
- database programs, 179
- DATE attribute, 172
- .dtx extension, 307
- DDUCS command, 370
- debugging techniques, 312
 - animation, 322
 - code testing, 312–315, 313–315, 322–325
 - parentheses and quotation mark matching, 315–316, 316
 - variable checking, 316–322, 317–320
- decimal feet dimensions, 126
- decimal-inch units, 110
- decimal points, 334
- defaults
 - file-saving location, 45, 45
 - settings, 346–347
 - values, 343–345
- defining attributes, 173–174, 177–178, 178
- definition lines, 99
- DEFUN statement, 284, 346
- DEFUN-Q statement, 309
- degree and radian conversions, 297–301, 299
- DELAY function, 249
- Delete key, broken
 - puzzler, 413
 - solution, 423
- Delete option, 159
- DELTA option, 30
- Demand Load Xrefs Enabled With
 - Copy option, 50
- dense hatch
 - puzzler, 414
 - solution, 423–424
- Descartes, Rene, 387
- description lines, 99
- design standards, 2
 - actual size, 2–3, 3
 - “as built” structures, 3
 - best practices, 5–12
 - logical increments, 4
 - Maximum Material Condition, 3–4
- DesignCenter
 - for blocks, 170, 171
 - and workstations, 58
- desk organizer 3D model, 373–395, 373–395
- diameter dimensions, 116, 117, 125
- DIMALIGN command, 30
- DIMALIGNED command, 128
- DIMASO variable, 108, 425
- DIMASSOC variable
 - for ordinate dimensions, 31–32
 - for Paper Space, 214

- settings, 108, 216–218, 425–426
 - warning for, 54
 - DIMBASE command, 130
 - DIMBASELINE command, 118
 - DIMCEN variable, 110
 - DIMCENTER command, 112, 139–140, 139, 217
 - DIMCONTINUE command, 118, 130
 - DIMDLI command, 214
 - Dimension Style Manager dialog box
 - for architectural dimensions, 119, 119
 - child styles, 116, 117
 - puzzler, 412, 412
 - solution, 421
 - dimensions, 106
 - 3D, 218
 - aligned vs. rotated, 30, 30
 - as anonymous blocks, 106–107, 158
 - architectural, 119, 119
 - Alternate Units tab, 123
 - feet and inches, 119
 - Fit tab, 121–122, 121, 124, 124
 - Lines tab, 119, 119
 - metric, 125–126
 - Primary Units tab, 122, 122
 - rules for, 131–133
 - Symbols And Arrows tab, 120, 121, 123
 - Text tab, 120–121, 121, 124, 124
 - Tolerances tab, 123
 - arrowheads
 - appearance, 112, 112, 120
 - custom, 109
 - with leaders, 215
 - associative, 107–108, 215
 - civil and surveying, 126
 - Fit tab, 127, 127
 - Lines tab, 126, 126
 - Primary Units tab, 127–130, 127
 - Text tab, 127, 127
 - increments, 6
 - mechanical, 110
 - Alternate Units tab, 114–115, 115
 - ASME and ISO versions, 117–118
 - child styles, 116, 117
 - decimal-inch units, 110
 - Fit tab, 113, 113
 - Lines tab, 111, 111
 - Primary Units tab, 114, 114, 118
 - rules for, 130–131, 132
 - Symbols And Arrows tab, 112, 112
 - Text tab, 112–113, 112
 - Tolerances tab, 115–116, 116
 - names, 106
 - ordinate, 31
 - origins, 217
 - overriding, 6
 - in Paper Space
 - puzzler, 416
 - solution, 425–426
 - in plotting, 214–218, 216–217
 - styles
 - for plotting, 210
 - standard, 108–109
 - in template files, 148
 - in XRefs, 185–186
 - tiny
 - puzzler, 418
 - solution, 429
 - tiny text
 - puzzler, 418
 - solution, 429
 - units, 107, 110
 - unreliable
 - puzzler, 419
 - solution, 432
 - variables, 31–32
 - DIMEX tool, 38
 - DIMIN tool, 38
 - DIMLFAC variable, 207
 - DIMLINEAR command, 30
 - DIMORD command, 31
 - DIMORDINATE command, 118
 - DIMREASSOC tool, 38–39, 432
 - DIMREASSOCIATE command, 215
 - DIMSCALE variable, 32, 118, 429
 - DIMSTYLE command, 110
 - directories, 60, 61
 - disabled viewport locking
 - puzzler, 413
 - solution, 422
 - disappearing previews
 - puzzler, 412, 412
 - solution, 421
 - disciplines in commercial project layer names, 149–150
 - display commands, 35–36
 - display precision, 15
 - Display tab, 47–49, 48
 - DISPSILH variable, 376, 387
 - DIST command, 23
 - distances, points from, 292–294
 - DIVIDE command, 26
 - dollar signs (\$) in filenames, 42
 - DONUT command, 344
 - DOS, 62–63, 62–63
 - in AutoLISP programs, 360–364, 364
 - batch files, 63–68, 67–68
 - commands, 64–65
 - DOS screen, 62, 62
 - dots (.)
 - for association lists, 334
 - with commands, 282
 - dotted pairs, 334
 - double-clicking on parentheses, 316, 316
 - Drafting Settings dialog box, 8
 - Drafting tab, 54, 54
 - Drafting Tooltip Settings, 54
 - Draw Dim Line Between Ext Lines option, 124
 - Drawing Exchange Format (DXX) format, 182
 - Drawing Recovery Manager, 43
 - drawing set description files (DSDs), 237
 - Drawing Units dialog box
 - for dimensions, 122
 - for scaling, 428, 428
 - for status bar display, 107
 - for surveyor units, 129, 129
 - drawings
 - from block definitions, 269–271
 - information from, 21–24, 23
 - inserting, 286–287
 - symbols in, 170
 - updating, 249, 258–260
 - DRAWORDER command, 128, 229
 - drive letters, mapping to network folders, 61
 - DSDs (drawing set description files), 237
 - DTEXT command, 391
 - in Model Space, 220
 - suggestions for, 21, 21
 - DTR function, 299–301
 - .dwb extension, 307
 - DVIEW command, 208, 236–237, 236–237, 399
 - DWF files, 245–246
 - DWFIN command, 183
 - DWG files, 357
 - DWGNAME variable, 190
 - DXF group codes, 332, 334–335, 335
 - DXX (Drawing Exchange Format) format, 182
 - dynamic blocks, 165
 - existing blocks for, 167
 - objects for, 165, 166
 - DYnamic option in LENGTHEN, 30
 - dynamic UCS option, 370
 - DYNPICOORDS variable, 421–422
-
- E
- EATTEDIT command, 174
 - EATTEXT tool, 174, 178, 180–181
 - Edit Attributes dialog, 177, 178
 - Edit Block Definition dialog box, 167
 - EDIT command, 180
 - Edit Scale List option, 54
 - editing
 - attributes, 177, 178, 180
 - commands, 25–32, 26, 28, 30
 - cursor menu, 91, 92
 - grips menu, 92, 93
 - pull-down menus, 89–90, 90–91

editors

- AutoLISP, 279–282, 280–281
- for blocks, 163
- MTEXT, 220, 391

efficiency

- drawing, 13
- interface. *See* interface

eight-dot-three (8.3) convention, 61, 61

End option in UNDO, 29

EndSection.lsp program, 355–357

Enterprise CUI files, 83

ENTGET function, 331, 334

Entire Drawing option, 161

entities

- upon entities
 - puzzler, 419
 - solution, 433
- manipulation, 331
 - ASSOC, ENTGET, and ENTSEL, 331–337
 - SSGET, 338–341

selection

- for area, 22
- puzzler, 414
- solution, 423
- stuck on layers
 - puzzler, 413
 - solution, 422

ENTLAST function, 289

ENTSEL function, 331, 333–334

equal signs (=) for SSGET, 339

error handling, 325–328

exclamation points (!) for SSGET, 339

EXPERT variable, 430

EXPLODE command, 27

exporting tool palettes, 82–83

Express Tools, 37–39

- for complex linetypes, 101–103, 101–103
- limitations, 392

extensions

- AutoLISP, 306–307
- file, 42

external commands, 68–72, 69, 72

External Reference dialog box, 1
83–184, 183

external references. *See* XRefs

extracting

- attribute values, 178–182, 179, 181–182
 - drawing information, 21–24, 23
- EXTRUDE command, 377, 385

fields

- customizing, 189–190, 189
- in database programs, 179

FILEDIA variable, 250

FILENAME attribute, 173

FILEPATH attribute, 173

files

- archiving, 44, 44
- Autosave, 42–43, 43
- backing up, 24, 42, 66–67
- default file-saving location, 45, 45
- extensions, 42, 306–307
- formats
 - puzzler, 418
 - solution, 431
- moving, 10
- opening, 68–69, 69
- on removable media, 43–44
- renaming, 10, 36–37, 37, 63
- replacing, 266
- size reductions, 262–265, 265
- template. *See* template files

Files tab, 46–47, 48

FILLET command

- for desk organizer, 388
- for tangent arcs, 20–21
- working with, 26

FILTER command, 31

filters, layer, 34

findfile function, 68, 69

fire copies, 44

Fit tab

- architectural dimensions, 121–122, 121, 124, 124
- civil and surveying dimensions, 127, 127
- mechanical dimensions, 113, 113

fixtxt.lsp program, 340–341

flat-surface models, 368–369

FLATSHOT tool, 427

FLATTEN tool, 38, 426

floating-point decimals, 294

floating viewports, 200–201, 201

- regions for, 229–230, 230

rotating, 236, 236–237

scaling, 110, 127, 172

tiling, 199

flyouts, 80, 81

folders, 60–61, 61

- missing
 - puzzler, 414, 414
 - solution, 424

FOLDERS.BAT file, 65

fonts, 133–135, 133

- lost, 134

in presentations, 48

Format Edit Window button, 281, 282

formats

- attribute, 180, 182
- drawing, 357

file

- puzzler, 418
- solution, 431

formulas in tables, 191–193, 192–193

Freeze Or Thaw In Current Viewport option, 224

freezing layers, 34, 224, 224

From osnaps, 20, 20

Front UCS, 370, 371

Full Path option, 184

functions

- AutoLISP, 276–277
- combining, 303–304, 303–305
- creating, 299–301
- GET, 290–292
- math, 294–295
- in tables, 191–193
- transparent, 302, 302

G

general error trapping, 326

geometry, plotting, 197, 226–227

GET functions, 290–294

GETANGLE function, 298–299

GETFILED function, 358, 358

GETKEYWORD function, 354–357

GETSTRING function, 289, 299

GETVAR function, 278, 287, 292

global variables, 287–288, 312, 346

graphics and graphics standards, 105, 143, 143–144

dimensions. *See* dimensions

DWF files, 245–246

linetypes and lineweights, 135–136, 142–143

center lines, 138–141, 139–141

hidden lines, 136–138, 137

raster-based and vector-based, 243, 243

raster files, 244

screen capture, 243–244

template files. *See* template files

text styles, 133–135, 133

WMFOUT for, 244–245, 245

greater than signs (>) for SSGET, 339

GRID command for symbols, 168

grips menu, 92, 93

group codes, 332, 334–335, 335

GROUP command, 24–25

groups

- in commercial project layer names, 150
- dimension, 131
- in symbol libraries, 170, 171
- for tool palettes, 76–78, 77

F

.fas extension, 307

feet and inches dimensions, 119

FIELDDISPLAY variable, 191

H2S2H.BAT file, 66–67
 handle_file.lsp program, 348–350
 handles, entity, 331
 hatches
 dense
 puzzler, 414
 solution, 423–424
 edit problems
 puzzler, 413, 413
 solution, 422
 lost boundaries
 puzzler, 412
 solution, 422
 in plotting, 218–219, 219
 height, text, 9, 135
 Help system, 6–7
 hexadecimal numbers, 331
 hidden lines, 136–138, 137
 HIDE command, 391
 Hide File Extensions For Known File
 Types option, 42–43
 Hide System Printers option, 51
 host layers, 164–165
 HPASSOC variable, 422

I2M.lsp program, 295–296
 icons, button, 89
 IF function, 342–347
 ii.lsp program, 302
 IMAGE command, 183
 IMAGECLIP command, 128
 images, raster and vector, 243, 243
 imperial settings, 11
 inch to millimeter conversions,
 295–296
 Incremental Save Percentage setting, 50
 increments
 angle, 19
 dimension, 6
 logical, 4
 indentation in programs, 327
 INDEXCTL variable, 187–188
 indexes in XRefs, 187–188, 188
 information
 extracting, 21–24, 23
 in Paper Space, 209
 INITGET function, 290, 354–357
 INSERT command, 162–163, 162,
 286–287
 Insert Field command, 190
 Insert option for XREFs, 185
 inserting drawings, 286–287
 Insertion Point option, 177
 InsertTB.lsp program, 288–289
 integers, 294
 interface, 73
 changing, 45–46

CUI. *See* CUI (Customizable User Interface)
 linetypes, 97–103, 101–103
 menus
 cursor, 91, 92
 grips, 92, 93
 pull-down, 89–90, 90–91
 tool palettes. *See* tool palettes
 interior angles, 18–20, 19
 INTERSECT command, 385, 403
 invisible attributes, 176, 178, 178
 invisible block references
 puzzler, 420
 solution, 434
 Invisible mode, 176
 irregular viewports, 231, 231
 islands, viewports with, 229–230, 230
 ISO version, mechanical dimensions,
 117–118
 isometric view, 377
 ITOA function, 297

Johnson, Steve, 60
 jumping parentheses, 316

Katahdin Cedar Log Homes, 366, 367
 keyboard, shortcuts, 93–97, 95–97

labels in programs, 328
 Layer 0, 165
 LAYER command, 251
 layers
 blocks for, 164–165
 color, 153–154
 features, 34–35
 freezing, 34, 224, 224
 names, 7, 34, 148–153
 for plotting, 212
 working with, 7–8
 in XRefs, 185–186, 186
 LAYMERGE tool, 38
 Layout tab, 199
 layouts
 breaks in, 231–234, 232–235
 DVIEW for, 236–237, 236–237
 in Paper Space, 9, 208–210
 plotting, 195, 220–221, 228–240,
 229–240
 PSVPSCALE for, 234
 PUBLISH for, 237–239, 238–239
 sheet sets, 239–240, 240
 viewports
 irregular, 231, 231
 with islands, 229–230, 230

maximizing, 228–229
 switching, 228, 229
 LAYWALK tool, 38
 LEADER command, 220
 leaders, 215, 220
 Least Material Condition (LMC), 4
 legacy commands, 84
 length, line
 puzzler, 416, 416
 solution, 426–427, 426
 LENGTHEN command, options, 30
 less than signs (<) for SSGET, 339
 letter form, 135
 libraries, symbol. *See* symbol libraries
 and symbols
 linear child styles, 123–124, 123–124
 lines
 construction, 17
 hidden, 136–138, 137
 lengths
 puzzler, 416, 416
 solution, 426–427, 426
 perspective, 395–399, 396–400
 Lines tab
 architectural dimensions, 119, 119
 civil and surveying dimensions,
 126, 126
 mechanical dimensions, 111, 111
 linetypes, 97–98, 135–136
 basic, 98–99
 center lines and center marks,
 138–141, 139–141
 complex, 100–103, 101–103
 hidden lines, 136–138, 137
 for plotting, 210–211
 puzzler, 416, 417
 solution, 427, 427
 lineweights, 35, 142–143, 242
 Lisp language, 341–342
 LIST command, 23, 428
 lists, 341–342
 LMC (Least Material Condition), 4
 Load acad.lsp With Every Drawing
 option, 51–52
 Load Active Edit Window button, 281,
 282, 319
 Load/Unload Applications dialog box,
 279, 279
 loading AutoLISP programs, 306–310
 local variables, 287–288, 312
 locking
 layers, 34
 viewports
 puzzler, 413
 solution, 422
 LOGAED.BAT file, 65–66
 logical increments, 4
 logical names for layers, 7
 logical operators, 339
 logons, batch files, 65–66

long path statements, 71
lost fonts, 134
lost hatch boundaries
 puzzler, 412
 solution, 422
.lsp extension, 307
LTSCALE variable, 33–34, 210
LTPESH.PSH file, 100
LUNITS variable, 296
LUPREC variable, 15

M

macros for buttons, 87–89, 87–88
Main CUI file, 83
Maine state office building, 366, 366
major groups in commercial project
 layer names, 150
Make Linetype tool, 101–102
Make New Dimensions Associative
 option, 54
Make Shape tool, 101–102, 101
mapping drive letters to network
 folders, 61
Mark option, 29
marks, center, 138–141, 139–141
matching parentheses and quotation
 marks, 315–316, 316
math functions, 294–295
maximizing viewports, 228–229
Maximum Material Condition (MMC),
 3–4
McFarland, Jon, 63
MDB (Microsoft DataBase) format, 180
MEASURE command, 26, 26, 103
MEASUREMENT variable, 100
mechanical design, layer names in,
 153–154
mechanical dimensions, 110
 Alternate Units tab, 114–115, 115
 ASME and ISO versions, 117–118
 child styles, 116, 117
 decimal-inch units, 110
 Fit tab, 113, 113
 Lines tab, 111, 111
 Primary Units tab, 114, 114, 118
 rules for, 130–131, 132
 Symbols And Arrows tab, 112, 112
 Text tab, 112–113, 112
 Tolerances tab, 115–116, 116
mechanical lineweights, 142
mechanical parts, 3–4
menus
 cursor, 91, 92
 grips, 92, 93
 pull-down, 89–90, 90–91
metric system, 5
metric units
 architectural dimensions, 125–126

 civil and surveying dimensions, 129
 mechanical dimensions, 117–118
 settings, 11
Metso Paper USA tissue dryer, 367,
 367–368
Microsoft DataBase (MDB) format, 180
mid.lsp program, 292–294, 328–330
middle scroll wheels
 in plotting, 217, 217
 in zooming, 35–36
millimeters, converting inches to,
 295–296
minor groups in commercial project
 layer names, 150
MINSERT command, 158
missing folders
 puzzler, 414, 414
 solution, 424
missing linetypes
 puzzler, 416, 417
 solution, 427, 427
missing warnings
 puzzler, 418
 solution, 430
MKLTYPE tool, 38, 101–102
MKSHAPE tool, 101–102, 101
MKSHP tool, 38
MMC (Maximum Material Condition),
 3–4
Model Space
 CHSPACE for. *See* CHSPACE tool
 geometry in, 226–227
 plotting, 195, 198–200,
 212–213, 213
 scaling text in, 220
 TILEMODE for, 199–200, 199
Model Space tab, 198
modes, attribute, 176–177
Modify Dimension Style dialog box, 109
 Alternate Units tab
 architectural dimensions, 123
 mechanical dimensions,
 114–115, 115
 Fit tab
 architectural dimensions,
 121–122, 121, 124, 124
 civil and surveying dimensions,
 127, 127
 Lines tab
 architectural dimensions,
 119, 119
 civil and surveying dimensions,
 126, 126
 mechanical dimensions, 111, 111
 Primary Units tab
 architectural dimensions,
 122, 122
 civil and surveying dimensions,
 127–130, 127

 mechanical dimensions, 114,
 114, 118
 Symbols And Arrows tab
 architectural dimensions, 120,
 121, 123
 mechanical dimensions, 112, 112
Text tab
 architectural dimensions,
 120–121, 121, 124, 124
 civil and surveying dimensions,
 127, 127
 mechanical dimensions,
 112–113, 112–113
Tolerances tab
 architectural dimensions, 123
 mechanical dimensions,
 115–116, 116
MONOCHROME.CTB table, 241
MONOCHROME.STB table, 241
moving files, 10
MPEDIT command, 17
MTEXT editor, 220, 391
MTEXTED variable, 430
multisheet DWF, 238
multiviews
 in Paper Space, 206
 solid models from, 400–408,
 400–408
MVIEW command, 202, 209, 225, 230
MVSETUP command, 206

N

names
 commands, 284
 dimensions, 106
 files, 10, 63
 layers, 7, 34, 148–153
 requirements, 61, 61
 Standard, 10
 variables, 289–290
 wildcards for, 36–37, 37, 149
nautical charts, 128
nesting blocks, 162
NET USE command, 66
network folders, mapping drive letters
 to, 61
New Palette option, 80
New Sheet Set Wizard, 241
nil value, 286, 313
No Plot setting, 34
NOT operator, 339
notes in programs, 328–330
Noun/Verb Selection option, 55
NTH function, 332–333
number and string conversions,
 296–297
Number.lsp program, 351–354

Number Of Recently-Used Files To List setting, 50
 Number option in UNDO, 29

objects

in commercial project layer names, 151
 for dynamic blocks, 165, 166
 in Paper Space and Model Space, 202, 209

Objects option, 161
 Off object rule, 131
 OFFSET command, 27
 on-site engineering, 3
 OOPS command, 27
 Open And Save tab, 49–50, 51
 opening files, 68–69, 69
 Options dialog box, 32, 46
 3D Modeling tab, 54, 55
 Display tab, 47–49, 48
 Drafting tab, 54, 54
 Files tab, 46–47, 48
 Open And Save tab, 49–50, 51
 Plot And Publish tab, 50–51, 52
 Profiles tab, 56, 56
 Selection tab, 55–56, 56
 System tab, 51–52, 52
 User Preferences tab, 53
 OR operator, 339
 ordinate dimensions, 31
 origins, dimensions, 217
 OSMODE variable, 70, 278, 325–326
 Over Dimension Line, With Leader option, 121
 OVERKILL tool, 39, 39
 puzzler, 419
 solution, 433
 overriding dimension values, 6

Page Setup dialog box, 221, 222

palettes, tool. *See* tool palettes
 PAN command, 233
 Paper Size setting, 50
 Paper Space

advantages, 205–210, 210
 CHSPACE for. *See* CHSPACE tool
 drawbacks, 202–205, 204–205
 layouts in, 9, 208–210
 plotting, 195, 200–202, 201, 213
 parameters for dynamic blocks, 166
 parent layers, 164
 parentheses (
 in AutoLISP, 276–277, 284
 matching, 315–316, 316
 Partial CUI files, 83

PARTIALLOAD command, 37
 PARTIALOPEN command, 37
 passwords, setting, 50
 Path setting, 47
 paths
 long, 71
 overview, 60–61
 setting, 47
 for XREFs, 184, 185
 PAUSE function, 286
 PEDIT command
 for area, 22
 for arrays, 16
 for polylines, 382–383
 PEDITACCEPT variable, 425
 Percent option, 30
 periods (.)
 for association lists, 334
 with commands, 282
 perspective line drawing, 395–399, 396–400
 Perspective View option, 394
 PICKADD variable, 56, 423
 Pickbox Size setting, 55
 PICKBOX variable, 34
 PICKFIRST variable, 55, 422–423
 PICKSTYLE variable, 25, 422
 PLAN command, 208, 390
 PLINE command, 376
 PLINEGEN variable, 137–138, 137, 427
 Plot And Publish tab, 50–51, 52
 Plot setting, 34
 Plot Style Table Editor, 242, 242
 plot-style tables, 240–242, 242
 Plot To File option, 50
 PLOT OFFSET command, 431
 plotting, 195
 block design in, 197
 definitions in, 197
 dimensions in, 214–218, 216–217
 geometry in, 197, 226–227
 graphics
 DWF files, 245–246
 raster-based and vector-based, 243, 243
 raster files, 244
 screen capture for, 243–244
 WMFOUT for, 244–245, 245
 hatch patterns in, 218–219, 219
 layouts, 9, 220–221, 228–240, 229–240
 in Model Space, 195, 198–200, 212–213, 213
 in Paper Space, 9, 195, 200–202, 201
 drawbacks, 202–205, 204–205
 guidelines for, 213
 plot-style tables, 240–242, 242
 preparing for, 210–212, 211

steps in, 221–226, 222–226
 text in, 219–221
 POINT command, 31, 292
 points
 from coordinates, 291–292
 creating, 290–294
 from distances and angles, 292–294
 polar arrays
 alternatives to, 18
 creating, 16, 16
 POLAR function, 290, 292, 312–315, 313
 polycircle.lsp program, 343–345
 polycircle_defaults.lsp program, 346–347
 polylines
 3D, 382–383
 unextrudable
 puzzler, 419
 solution, 431
 PQCHECK program, 315
 precision
 angle, 14–15, 14
 in best practices, 6
 dimension, 6
 presentation profiles, 48
 preset layouts, 212
 Preset mode, 177
 previews, disappearing
 puzzler, 412, 412
 solution, 421
 Primary Units tab
 architectural dimensions, 122, 122
 civil and surveying dimensions, 127–130, 127
 mechanical dimensions, 114, 114, 118
 Priority For Coordinate Data Entry setting, 53
 profiles
 presentation, 48
 with workspaces, 58
 Profiles tab, 56, 56
 program variables, 287, 312
 programs
 AutoLISP. *See* AutoLISP programs
 scripts. *See* scripts
 PROJECT attribute, 172
 Prompt option, 177
 properties
 ByLayer, 7–8
 tools, 78–79, 78–79
 PROPERTIES command, 23, 25–26
 PSLTSCALE variable, 33, 210–211, 432
 PSVPSCALE variable, 234
 PUBLISH command, 128, 237–239, 238–239
 Publish dialog box, 238–239, 238
 Publish Selected Layouts option, 239
 pull-down menus, 89–90, 90–91

PURGE command
 for symbols, 170
 working with, 36, 37

puzzlers, 411
 absolute coordinates
 question, 412
 solution, 421–422

AutoLISP OVERKILL
 question, 419
 solution, 433

AutoLISP programs
 question, 415
 solution, 424–425

block scaling
 question, 417, 417
 solution, 428, 428

blown-up batting
 question, 419
 solution, 432

bound XRefs
 question, 420, 420–421
 solution, 434

CHSPACE
 question, 420
 solution, 433–434

Delete key
 question, 413
 solution, 423

dense hatch
 question, 414
 solution, 423–424

dimension nightmare
 question, 419
 solution, 432

dimension text
 question, 418
 solution, 429

dimensions
 question, 416, 418
 solution, 425–426, 429

disabled viewport locking
 question, 413
 solution, 422

disappearing previews, 412
 question, 412
 solution, 421

entities stuck on layers
 question, 413
 solution, 422

entities upon entities
 question, 419
 solution, 433

entity selection
 question, 414
 solution, 423

file format
 question, 418
 solution, 431

hatch edit problems
 question, 413, 413
 solution, 422

invisible block references
 question, 420
 solution, 434

line lengths
 question, 416, 416
 solution, 426–427, 426

lost hatch boundary
 question, 412
 solution, 422

missing folders
 question, 414, 414
 solution, 424

missing linetypes
 question, 416, 417
 solution, 427, 427

sideways text
 question, 418
 solution, 430

toolbars
 question, 418
 solution, 429

unextrudable polylines
 question, 419
 solution, 431

variables changed
 question, 419
 solution, 431–432

versions
 question, 417
 solution, 428

viewport selection
 question, 418
 solution, 430

warnings missing
 question, 418
 solution, 430

working sets
 question, 415, 415
 solution, 424

QDIM command, 31, 118, 215

QNEW command, 145, 146

QSAVE command, 24, 89

QSELECT command
 benefits, 11–12, 11
 for ordinate dimensions, 31

quick area calculations, 22–23, 23

Quit button, 281, 281

QUIT command, 263

quotation marks (“)
 AutoLISP, 276–277, 284
 matching, 315–316, 316

QUOTE function, 342

R

radial dimensions, 116, 117, 125

radians and degree conversions,
 297–301, 299

radius and diameter dimensions
 rule, 131

Radius Dimensions under Use For
 setting, 116

raster-based fonts, 134

raster-based images, 243, 243

raster files, plotting to, 244

rc_broken_version.lsp program,
 298–299, 299

rc.lsp program, 301

rc2.lsp program, 301

Re-Initialization dialog box, 72, 72

reactors, 274

real numbers, 294

real programmers, 327–328

records in database programs, 179

rectangular arrays, 14–16, 14

REDEFINE command, 309

redefining
 blocks, 163, 265–268
 commands, 309–310

REDO command, 29

Reduce Aperture Size option, 54

reducing file size, 262–265, 265

Redundant dimensions rule, 131

REFCLOSE command, 424

REFEDIT command
 for blocks, 163–164
 precautions, 10
 for XRefs, 188

Reference dimensions rule, 131

Reference option
 for ROTATE, 28
 for SCALE, 28, 28

references, external. *See* XRefs

REGION command, 18, 229–230, 401

regions, 18, 18
 for area calculations, 21–23, 23
 for floating viewports, 229–230, 230

REINIT command, 72

related blocks in symbol libraries, 170, 171

relational tests, 338–341

Relative Path option, 184, 185

relative polar tracking, 18

Relative To Paper Space option, 218

Release.lsp program, 358–360

Relshell.lsp program, 361–364, 364

remarks, 69

REMEMBERFOLDERS variable, 257

removable media, 43–44

Rename command, 36–37, 37, 63

renaming files, 10, 36–37, 37, 63

REPEAT function, 348–350

replacing files, 266

Reset button, 281, 281

resetting variables, 257–258, 258
 residential projects, layer names in, 152–153
 RESUME function, 249
 Retain option, 159
 reusing code, 285–286
 Reverse Mouse Wheel Zoom option, 54
 Richardson, Paul, 327, 366
 Right-Click Optimization option, 53
 right-hand rule, 410
 Right UCS, 371, 372
 romans.shx font, 113
 ROTATE command, 28, 299, 301
 ROTATE3D command, 402
 rotated dimensions, 30, 30
 rotating floating viewports, 236, 236–237
 round-tripping, 167
 RSCRIPT function, 249
 RTD function, 299–301
 RTOS function, 296–297

S

SAVE command
 adding to menus, 89–90, 90–91
 working with, 24
 Save Current As option, 58
 SAVEAS command, 24
 SAVETIME variable, 43
 saving
 AutoLISP text files, 278–279
 options for, 24, 24
 template files, 145, 146
 SCALE command, 28, 28, 392
 Scale Dimensions To Layout option, 113, 121, 127
 SCALE tag, 173
 Scaletxt.lsp program, 352–353
 scaling
 blocks
 puzzler, 417, 417
 solution, 428, 428
 in Paper Space, 206–207
 in plotting, 214
 text, 220–221
 .scr extension, 250
 screen capture, 243–244
 screen saver extensions, 250
 SCRIPT command, 250
 scripts, 247. *See also* AutoLISP programs
 applications, 271–272
 for block definitions
 drawings from, 269–271
 redefining, 265–268
 characteristics, 248
 for computer bench testing, 253–256, 255–256
 example, 251, 251
 for file size reductions, 262–265, 265
 for resetting variables, 257–258, 258
 setup for, 252–253, 253
 for startup, 256–257, 257
 troubleshooting, 260–261
 for updating drawings, 258–260
 writing and running, 248–250
 scroll wheels
 in plotting, 217, 217
 in zooming, 35–36
 SDF (space delimited) format, 182
 search paths, 46
 SECTION command, 403
 Security Options settings, 50
 Select All Layouts option, 239
 selection
 entity
 puzzler, 414
 solution, 423
 viewport
 puzzler, 418
 solution, 430
 selection sets, 331
 ASSOC, ENTGET, and ENTSEL, 331–337
 SSGET, 338–341
 Selection tab, 55–56, 56
 semicolons (;)
 in commands, 282
 for remarks, 69
 in scripts, 249
 SET function, 341–342
 SETENV function, 423
 SETQ function, 289, 320, 342
 settings
 commands, 32–33
 defaults, 346–347
 setup for scripts, 252–253, 253
 SETVAR function, 278
 SHADEMODE variable, 375, 388, 394
 SHEET attribute, 172
 sheet sets, layout, 239–240, 240
 SHELL command, 64, 361
 Shortcut Keys dialog box, 96–97, 96
 shortcut menus, 91
 shortcuts
 keyboard, 93–97, 95–97
 to template files, 147, 147
 SHTOTAL attribute, 172
 SHX fonts, 120, 133–134
 sideways text
 puzzler, 418
 solution, 430
 size
 drawing, 2–3, 3
 file, 262–265, 265
 paper, 50
 slashes (/) for SSGET, 339
 SLICE command, 403–404, 406
 sluggish computers, 254
 SNAP command, 168
 SOLDRAW command, 206, 218
 solid models
 from 2D multiviews, 400–408, 400–408
 advantages, 369
 SOLIDEDIT command, 403–404, 406
 SOLPROF command, 206, 218, 407
 SOLVIEW command, 206
 space delimited (SDF) format, 182
 spaces
 in AutoLISP, 276–277
 in linetype definitions, 99
 in scripts, 249
 in variable names, 290
 SPACETRANS command, 220
 Spacing rule, 131
 spatial indexing, 187–188, 188
 specific error trapping, 326
 Specify Origin Of UCS option, 372
 SSECT.lsp program, 291–292, 303–304, 303–305
 ssect_xtra.lsp program, 324–325
 SSGET function, 290–292, 338–341
 Standard as name, 10
 standards, 143, 143–144
 dimension styles, 108–109
 template files, 144–154, 145–146
 tool palettes for, 12, 12
 START command, 68, 70
 startup
 scripts for, 256–257, 257
 switches, 58, 59
 STARTUP function, 309–310
 startupexample.lsp program, 310
 status in commercial project layer names, 150, 152
 strings
 manipulating, 357–360, 358
 number conversions with, 297
 structural_section.lsp program, 304
 stuck entities
 puzzler, 413
 solution, 422
 style-dependent tables, 242, 242
 style tables vs. color tables, 143
 styles
 child, 116, 117, 123–125, 123–125
 dimensions, 108–109
 plotting, 210
 in template files, 148
 in XRefs, 185–186
 subdirectories, 60, 61
 SUBTRACT command, 230, 385, 387
 Sum function, 193
 .sv\$ file, 42

swept-surface models, **369**
 switches, startup, **58, 59**
 switching viewports, **228, 229**
 symbol libraries and symbols, **167**
 in drawing files, **170**
 managing, **169**
 related blocks in, **170, 171**
 symbol creation for, **168, 169**
 template files for, **170**
 Symbols And Arrows tab
 architectural dimensions,
 120, 121, 123
 for arrowheads, **109**
 mechanical dimensions, **112, 112**
 Symbols rule, **131**
 System tab, **51–52, 52**
 system variables
 in AutoLISP, **287, 312**
 for dimensions, **110**
 System Variables dialog box, **258, 258**
 SystemVariable field, **190**
 SYSVDLG tool, **39, 258**

T

Tab key, **208**
 Table format for attributes, **180**
 tables, **190–193, 192–193**
 plot-style, **240–242, 242**
 style vs. color, **143**
 Tag option, **177**
 tangent arcs, **20–21, 21**
 TBUPDATE.BAT file, **266–267**
 TBUPDATE.LSP file, **267–268**
 TBUPDATE.SCR file, **267**
 technical-graphics standards, **105**
 template files, **144**
 for attributes, **181–182**
 contents, **147**
 creating, **45, 144–147, 145–146**
 dimension styles in, **148**
 layer colors in, **153–154**
 layer names in, **148–153**
 for plot styles, **242**
 for symbols, **170**
 variable settings for, **147–148**
 working with, **45**
 testing, code, **312–315, 313–315,**
322–325
 text
 AutoLISP files, **278–279**
 dimension
 puzzler, **418**
 solution, **429**
 DTEXT for, **21, 21, 391**
 height, **9, 135**
 manipulating, **357–360, 358**
 in Model Space, **220**
 MTEXT for, **220, 391**

 in plotting, **219–221**
 sideways
 puzzler, **418**
 solution, **430**
 styles, **133–134**
 fonts, **134–135**
 letter form, **135**
 for plotting, **210**
 Text tab
 architectural dimensions, **120–121,**
 121, 124, 124
 civil and surveying dimensions,
 127, 127
 mechanical dimensions,
 112–113, 112
 3 Point option, **372, 372**
 3D dimensions, **218**
 3D Modeling tab, **54, 55**
 3D models, **365–366**
 from 2D geometry, **395–408,**
 396–408
 coordinate systems, **369–372,**
 371–372
 creating, **373–395, 373–395**
 samples, **366–367**
 suggestions, **409–410**
 types, **368–369**
 3D objects in Paper Space, **206**
 3DCORBIT command, **405**
 3DORBIT command, **393–394, 399**
 3DPOLY command, **3832**
 TILEMODE variable, **199–200, 199**
 TIME command, **24**
 time-sensitive right-clicking, **53**
 tiny dimension text
 puzzler, **418**
 solution, **429**
 tiny dimensions
 puzzler, **418**
 solution, **429**
 tissue dryer, **367, 367–368**
 title blocks for plotting, **210**
 Toggle Breakpoint button, **281, 281**
 toggling variables, **343**
 Tolerance rule, **130**
 Tolerances tab
 architectural dimensions, **123**
 mechanical dimensions,
 115–116, 116
 tool palettes, **74–75, 74**
 block references to, **75–76, 76**
 exporting, **82–83**
 groups for, **76–78, 77**
 for standards, **12, 12**
 tools
 adding, **80–82, 80–82**
 properties, **78–79, 78–79**
 Tool Properties dialog box, **74, 74**
 TOOLBAR command, **429**

 toolbars
 buttons on
 icons, **89**
 macros, **87–89, 87–88**
 creating, **84–86, 84–86**
 puzzler, **418**
 solution, **429**
 TOOLPALETTES command, **74**
 Total option in LENGTHEN, **30**
 Trace window, **279, 280**
 Track Using All Polar Angle Settings
 option, **18**
 transparent functions, **302, 302**
 troubleshooting scripts, **260–261**
 true position strategy, **226, 227**
 True shape rule, **130**
 TrueType fonts, **134–135**
 2D geometry, **395–408, 396–408**
 2D multiviews, solid models from,
 400–408, 400–408
 TXT format, **180**
 TXT.SHX font, **133**
 TXT2MTXT tool, **38**
 TXTEXP tool, **27, 390, 392**
 typos in troubleshooting, **260**

U

UCS (user coordinate system), **198,**
370–372, 371–372
 UCS II toolbar, **370**
 UCSFOLLOW variable, **370**
 UCSICON command, **375–376, 375**
 ui.lsp program, **343**
 UNDEFINE command, **90, 309–310**
 underscores ()
 in commands, **282**
 in menu names, **90, 96**
 UNDO command, **27–29, 326**
 unextrudable polylines
 puzzler, **419**
 solution, **431**
 UNION command, **230, 385, 392–393, 404**
 unit sizing for symbols, **168**
 units for dimensions, **107, 110**
 architectural, **122–123, 122**
 civil and surveying, **127–130, 127**
 mechanical, **114–115, 114–115, 118**
 updating
 blocks, **164**
 drawings, **249, 258–260**
 Use Named Plot Styles option, **242**
 Use Paper Space Units For Scaling
 option, **211**
 user coordinate system (UCS), **198,**
370–372, 371–372
 User Preferences tab, **53**
 utilities, **36–37, 37**

values

attributes, **177–182**, 179, 181–182
 default, **343–345**

variables

AutoLISP, **287–288**, 312

changed

puzzler, **419**
 solution, **431–432**

checking, **316–322**, 317–320

dimension, **31–32**

names, 289–290

in Paper Space, **207**

resetting, **257–258**, 258

for template files, **147–148**

togglng, **343**

vector-based fonts, 134

vector-based images, **243**, 243

Verify mode, **176–177**

versions

puzzler, **417**

solution, **428**

VIEW command, 35

View toolbar, 374

viewports

floating. *See* floating viewports

irregular, **231**, 231

with islands, **229–230**, 230

locking

puzzler, **413**

solution, **422**

maximizing, **228–229**

in Model Space, **199–200**, 199

selection

puzzler, **418**

solution, **430**

switching, **228**, 229

Viewports dialog box, 380–381,

380, 388

views in Paper Space, **206**, **209**

VISRETAIN variable, **186–187**

Visual Basic for Applications, 274

V

Visual LISP editor, 274, **279–282**,
 280–281, 315

Visual LISP Interactive Editing

Environment (VLIDE), 312

VLISP command, 279

.vlx extension, 307

VPCLIP command, 209

VPLAYER command, 209, 225,
 225–226

VPMAX tool, **228–229**

VPMIN command, 228

VPORTS command, 35, 198, 202, 389

VSCURRENT variable, 375

VTDURATION variable, 36

VTENABLE (View Transition Enable)

feature, **36**

VTFTS variable, 36

W

warehouse floor strategy, 227, 228

warnings, missing

puzzler, **418**

solution, **430**

Watch window, **316–322**, 317–320

Watch Window button, 281, 281

WBLOCK command

for DWG files, **24**, 24

options, **159–162**

in Paper Space, **203–205**, 204–205

for sheet sets, 241

WABOUT.BAT file, **262–263**, 265

WABOUT.LSP file, **264**

WABOUT.SCR file, **263**

WCS (world coordinate system),
369, 371

WHILE function, **351–354**

wildcards

for layer names, 149

with RENAME, **36–37**, 37

Windows Scripting Language, 62

wireframe models, **368**

WMFOOT command, **206**,

244–245, 245

working sets

puzzler, **415**, 415

solution, **424**

workspaces, **57–58**

world coordinate system (WCS),
369, 371

X

XATTACH command, 183

XCLIP command, **187**, 209

XCLIPFRAME variable, 187

XEDIT command, **188**

XLOADCTL variable, 188

XLS format, 180

XOPEN command, 189

XOR operator, 339

XPLODE command, 158

XREF command, 183

XRefs, **182–183**

attaching, **183–184**, 183, 185

bound

puzzler, **420**, 420–421

solution, **434**

layer and spatial indexing in,

187–188, 188

layers, blocks, and dimension styles

in, **185–186**, 186

managing, **185**

REFEDIT and XEDIT for, **188**

VISRETAIN for, **186–187**

XCLIP for, **187**

Z

Zero Suppression setting, 122

zooming and ZOOM command

to limits, 380

middle scroll wheel for, **35–36**

in Paper Space, 207

ZX for, **283–285**, 283

ZX command, **283–285**, 283

