

# Index

**Note to the Reader:** Throughout this index **boldfaced** page numbers indicate primary discussions of a topic. *Italicized* page numbers indicate illustrations.

---

## A

- AC adapters, 848
- Accelerated Graphics Port (AGP), **21**, **21**, 89–90, 90, 848
- access methods, media, 252–253
- access points (APs), 259, 360, 385–386, 386, 848
- access time, 122, 848
- Account Disabled option, 723
- accounts, user
  - in Windows 2000, 730–732, 730–732
  - in Windows NT, 721–723, 722–724
  - in Windows XP, 736–737, 736
- ACK (acknowledgment) packets, 748, 848
- activation, Windows XP, 618–619, 896
- Active Directory, 848
- active hubs, 254, 848
- active-matrix screens, 47, 848
- active partitions, 590, 848
- active termination, 149, 849
- active windows, 502, 503
- actuator arms, 120, 120, 849
- adapter cards, 39, 849
  - for building PCs, 289
  - dislodged, 449
  - installing, 321–324, 322
  - modems, 41, 41
  - networking, 704
  - NICs, 40–41, 40
  - SCSI, 145
  - sound, 41, 42
  - upgrading, 375–377, 376
  - video, 39, 40
- address bus, 95, 849
- address lease periods, 849
- addresses, 849
  - I/O, 84, 278–279, 877
  - IP, 746–747, 880
    - automatic, 747–748
    - static, 747
  - IPX, 755
    - network addresses, 239–240, 755–756, 755, 881
    - socket identifiers, 756
    - station addresses, 756
    - memory, 276–277, 884
    - protocol, 239–240
    - SCSI, 144, 150–152
- advanced attributes, 517–518, 517
- Advanced Micro Devices (AMD) processors, 103–104
- Advanced settings, System control panel for, 529–530
- advanced startup options, 566
  - in Windows 9x, 567
  - in Windows 2000/XP, 567–568
  - in Windows NT, 568–569
- AGP (Accelerated Graphics Port), **21**, **21**, 89–90, 90, 848
- air, compressed, 282–283
- air cooling, 401
- alignment, printhead, 200
- all-black printer pages, 203–204
- allocation units, 591–592, 849
- alpha releases, 434
- alternative operating systems, 468–469
  - Linux, 469–470
  - Mac OS, 469
- AMD (Advanced Micro Devices) processors, 103–104
- American Standard Code for Information Interchange (ASCII), 850
- AMR (Audio Modem Riser) slots, 91, 91
- analog devices, 849
- antistatic bags, 406, 849
- antistatic mats, 406, 406
- antistatic wrist straps, 405, 405, 849
- antivirus programs, 820, 849
- APIPA (Automatic Private IP Addressing), 748, 851
- AppleTalk protocol, 239, 849
- Application layer in OSI model, 234, 235, 849
- applications, 461–462
  - Computer Management Console for, 538
  - installing, 820
  - in operating system upgrades, 623–624
  - reinstalling, 428

- start problems with, 820
- Task Manager for, 532
- in troubleshooting, 813
- APs (wireless access points), 259, 360, 385–386, 386, 848
- Archive attribute, 829
- Archiving option, 518
- ARCNet (Attached Resource Computer Network), 241, 851
- ASCII (American Standard Code for Information Interchange), 850
- ASD.EXE (Automatic Skip Driver), 833, 833
- asynchronous communication, 850
- AT bus, 85, 850
- AT command set, 442–444
- AT system connectors, 14, 14, 850
- ATA (AT Attachment) interface, 132–133, 132, 878
  - ATA-1, 136
  - ATA-2, 136, 850
  - ATA-3, 137, 850
  - ATA/ATAPI-4, 138, 850
  - ATA/ATAPI-5, 138, 850
  - ATA/ATAPI-6, 139, 850
  - ATA/ATAPI-7, 139, 850
  - ATAPI, 137, 850
  - DMA modes in, 134–135
  - PIO modes in, 133–134
  - summary, 139–140
  - UltraDMA modes in, 135
- Attached Resource Computer Network (ARCNet), 241, 851
- ATTRIB.EXE tool, 829
- attributes, 509–510, 509, 829
  - advanced, 517–518, 517
  - changing, 516–517, 517
  - system, 905
- ATX motherboards, 17, 851
- ATX system connectors, 15, 15, 851
- Audio Modem Riser (AMR) slots, 91, 91
- auto-hiding Taskbar, 487
- auto-ranging multimeters, 284, 851
- AUTOEXEC.BAT file, 430, 558, 851
- Automated System Recovery, 573
- automatic IP addressing, 747
  - APIPA, 748
  - DHCP, 747–748
- Automatic Private IP Addressing (APIPA), 748, 851
- automatic Registry restores, 545
- Automatic Skip Driver (ASD.EXE), 833, 833

- Automatic Updates, 531
- Autorun option, 851
- average latency, 122

---

## B

- B (Bearer) channels, 258, 852
- baby AT motherboards, 17, 851
- back ends in LANs, 221
- back-panel punchouts, 307
- backside bus, 72, 851
- Backup utility, 543, 543
- backups, 542–543, 543, 851
  - DOS configuration files, 432–433
  - Registry, 831
  - sequential storage devices for, 119
  - tape, 39
- “Bad or Missing Command Interpreter” error, 817
- bad pixels, 350, 447
- bad video, 446–447
- bandwidth, 240, 851
- basic input/output system (BIOS), 92, 852
  - CMOS setup program, 852
  - shadowing, 852
  - in troubleshooting, 448
  - upgrading, 374–375
- Basic Rate Interface (BRI), 258, 851
- basis weight, 192, 851
- batch files, 558, 851
- batteries
  - CMOS, 30–31, 857
  - for portables, 377
- baud rate, 380, 852
- bays, 6, 347
- Bearer (B) channels, 258, 852
- beeps, 328
- belts, printer, 170–171, 171
- Berg connectors, 13, 13, 852
- beta releases, 435
- bias voltage, 182–183, 852
- bidirectional parallel ports, 54
- bidirectional satellite connections, 258, 852
- binary schemes, 852
- BIOS (basic input/output system), 92, 852
  - CMOS setup program, 852
  - shadowing, 852
  - in troubleshooting, 448
  - upgrading, 374–375

- BIOS chips, 30
- BIOS enabled SCSI devices, 151
- bit size of memory chips, 107
- bits, 380, 852
- bits per second (bps), 853
- blackouts, 388, 852
- blank printer pages, 202–203
- blanks, 311, 321, 322, 852
- blinking lights on modems, 381
- blockers, 89, 852
- Blue Screen of Death (BSOD), 819, 852
- Bluetooth technology, 189–190, 852
- BNC connectors, 243, 243, 852
- bonding, 258, 852
- boot files, Windows NT/2000/XP, 563
- BOOT.INI file, 563
- boot ROM, 853
- boot sequence, 564, 853
  - advanced startup options, 566
    - in Windows 9x, 567
    - in Windows 2000/XP, 567–568
    - in Windows NT, 568–569
  - CMOS setting for, 328, 331
  - issues in, 817
  - ROM for, 34
  - in Windows 9x, 564–565
  - in Windows NT/2000/XP, 565–566
- bootable disks, 287, 429, 588–589, 590, 853
- booting clean, 428
- BOOTSECT.DOS file, 563
- borders, window, 502, 503
- bps (bits per second), 853
- BRI (Basic Rate Interface), 258, 851
- bridges, 254–255, 853
- broadband Internet access, 256, 382, 853
- broadcasts, 254, 853
- brouters, 255, 853
- brownouts, 388, 853
- browsers, 746, 770, 771, 853
  - IE, 772
    - disk caches for, 802–803, 802–803
    - proxy settings, 774–776, 775
    - security settings and script support, 772–774, 772–774
    - Windows 9x settings for, 598, 598
- BSOD (Blue Screen of Death), 819, 852
- bubble-jet printers, 168, 853
  - parts of, 169
    - control, interface, and power circuitry, 174
    - head carriages, belts, and stepper motors, 170–171, 170–171
    - paper-feed mechanisms, 171–173, 172–173
    - printheads/ink cartridges, 169–170, 169
    - printing process, 174–175
    - problems, 199
      - paper jams, 200–201
      - print quality, 199–200
- buffers, 174, 277, 853
- BUFFERS= settings, 798–799, 853
  - in Windows 9x, 799
  - in Windows NT/2000/XP, 799–800
- bugs, 853–854
- building PCs, 272
  - case fans, 324
  - configuration settings, 274
    - DMA, 277–278
    - I/O addresses, 278–279
    - IRQ lines, 275–276
    - memory addresses, 276–277
  - connecting power and testing, 327–331
  - DIP switches, 274, 274
  - dongles, 324
  - double-checking, 327
  - finishing up, 332
    - network/modem connection installation, 332, 332
    - operating system installation, 334
    - speakers/headphones installation, 332–333, 332–333
  - jumpers, 273, 273
  - key terms, 336
  - motherboards. *See* motherboards
  - parts for, 287–290
  - power supply installation, 309–311, 309–310
  - removal and replacement procedures, 334
  - review question answers, 341–342
  - review questions, 337–340
  - storage device installation
    - CD/DVD devices, 318–321, 319–320
    - expansion cards, 321–324, 322, 324
    - external peripherals, 325, 325–326
    - floppy disk drives, 311–314, 312–314
    - hard disk drives, 314–316, 314–317
  - summary, 335
  - tools for, 280
    - hardware. *See* hardware
    - software, 287
  - workspace for, 279–280, 279

burners, CD, 37  
 bus clocks, 84, 854  
 bus connector slots, 854  
 bus length, SCSI, 149–150  
 bus mastering, 84, 854  
 bus topologies, 229–230, 229, 854  
 buses, 94, 854  
   address, 95  
   architectures, 83  
     AGP, 89–90, 90  
     AMR slots, 91, 91  
     CNR slots, 91–92, 92  
     disk interfaces, 92, 93  
     expansion bus features, 83–84  
     ISA, 84–88, 85  
     PCI, 88–89, 89  
     USB, 91  
   backside, 72  
   data, 94–95  
   external, 94  
   frontside, 72  
   speed, 95–96  
   upgrades for, 368  
 bytes, 854

---

## C

Cabinet (CAB) files, 829  
 cable access methods, 252, 854  
 cable modems, 382, 382, 854  
 Cable Select jumper option, 144  
 cables and cabling, 241, 257, 854  
   in ATA/ATAPI-4, 138  
   in ATA/ATAPI-5, 138  
   CD-ROM, 318, 320–321  
   coaxial, 242–243, 242–243  
   fiber-optic, 245–246, 246–247  
   floppy disk, 131, 131, 312–313, 312  
   hard disk drive, 315–316, 316–317  
   IEEE 1394, 58, 59  
   parallel, 55, 55  
   pass-through, 320, 320  
   PS/2, 59–60, 60  
   RCA, 59, 59  
   RS-232, 247–248  
   in SCSI installation, 147–149, 147–149  
   serial, 56–57, 57  
   summary, 248–249  
   twisted-pair, 244–245, 244–245

USB, 57–58  
   wireless networks, 248  
 cache memory, 72, 82–83, 94, 854  
 caches, 369, 800–803, 801–803, 854  
 caliper, paper, 192, 854  
 cameras, 384, 385  
 capacity  
   floppy disk, 129–130  
   hard disk drive, 121  
 capturing process for network printing, 688  
 Card Services software, 354, 854–855  
 cards, adapter. *See* adapter cards  
 carpal tunnel syndrome, 855  
 carriage belts, 171, 171, 855  
 carriage motors, 855  
   in bubble-jet printers, 170–171, 171  
   in dot-matrix printers, 199  
 carriage stepper motors, 855  
 Carrier Sense Multiple Access with Collision Avoidance (CSMA/CA), 252–253  
 Carrier Sense Multiple Access with Collision Detection (CSMA/CD), 252  
 carriers in laser printers, 176  
 cartridges  
   ink, 169–170, 169, 879  
   tape, 906  
   toner. *See* toner and toner cartridges  
 CAS (Column Address Strobe) latency, 108, 855  
 case fans, 324, 324, 855  
 case frames, 346, 855  
 cases, 5–6, 5, 855  
   in building PCs, 288  
   comparison, 12  
   desktop, 10, 10  
   full tower, 6–8, 7  
   mid tower, 8, 8  
   midi tower, 9  
   mini tower, 8–9, 9  
   mounting drives in  
     CD-ROMs, 318, 319  
     floppy, 311–312, 312  
     hard disk, 315, 315  
   for portables, 346  
   proprietary designs, 11  
   removing covers, 304, 304–305  
   slimline, 10–11, 11  
   video card installation in, 321–322, 322  
 cathode ray tube (CRT) technology, 42, 859  
 CCDs (charge-coupled devices), 383, 855  
 CD-R drives, 855

- CD-ROM/CD-RW/DVD/DVDRW drives,
  - 37–38, 37, 124–126, 125, 855
  - for building PCs, 289
  - installing, 318
    - case preparation, 318
    - data cables, 318, 320
    - jumpers, 318, 319
    - mounting in case, 318, 319
    - power cables, 321
    - sound pass-through cables, 320, 320
- CD-RW (rewritable) drives, 855
- Celeron processor, 101
- central processing units. *See* CPUs (central processing units)
- centralized processing, 221, 855
- Centronics ports, 53, 53, 855
- CGA (Color Graphics Adapter) video, 43, 856
- chains, SCSI, 144, 900
- Challenge Handshake Authentication Protocol (CHAP), 760, 856
- Change permissions in Windows NT, 725
- Change Type option, 528
- CHAP (Challenge Handshake Authentication Protocol), 760, 856
- characters per second (cps) in daisy-wheel printers, 167
- charge-coupled devices (CCDs), 383, 855
- charge cycles, NiCad, 377
- charging corona, 856
- charging in laser printer process, 181, 181, 856
- checking hard disks, 543–544
- checksumming, 856
- checksums, 856
- chip creep, 73, 449, 856
- chip pullers, 856
- chips, dislodged, 449
- chipsets, 70–71, 71, 856
  - Northbridge, 71–72
  - Southbridge, 72
- Choose From A List Of Internet Service Providers (ISPs) option, 764
- CHS (Cylinder, Head, Sector) addressing, 136, 859
- clamshell design, 346, 856
- classic operating systems, 463–464
  - CP/M, 464–465, 464
  - MS-DOS and PC-DOS, 465
    - origins, 465–466
    - versions, 466–468
- cleaning in laser printer process, 174–175, 180–181, 181, 856
- cleaning systems, 412–413
- clicking, 484
- client computers, 224–225, 857
- client-server resource model, 228–229, 228
- client software, 225, 857
- clients, 856
  - buggy, 429
  - for NetWare network access, 715–716, 716
  - in networking, 704
    - Windows 9x, 703–706, 704–705
    - Windows 2000/XP, 712–714, 712–714
    - Windows NT Workstation, 706–714, 707, 710–714
- clock doubling, 99, 857
- clock multipliers, 330, 857
- clock rate, 857
- clock signals, 84, 857
- clock speed, 94, 330, 857
- clock tripling, 857
- clone computers, 18, 466
- close buttons, 502, 503
- closed source code, 462
- clusters, 123, 591–592, 857
- CMOS (Complementary Metal Oxide Semiconductor), 34, 857
  - battery for, 30–31, 857
  - settings, 328–330, 857
    - in boot sequence, 328, 331
    - CPU, 330
    - floppy drive, 331
    - hard disk drive, 142–143, 331
    - parallel and serial port, 330–331
- “CMOS Configuration Has Changed” error, 327
- CMYK (cyan, magenta, yellow, and black) system, 175, 857
- CNR (Communication Network Riser) slots, 91–92, 92, 858
- coaxial cable, 242–243, 242–243, 857
- collapsing folders, 513
- collisions
  - in AppleTalk, 239
  - in IEEE 802.3 CSMA/CD, 236
- Color Graphics Adapter (CGA) video, 43, 856
- Column Address Strobe (CAS) latency, 108, 855
- combination floppy disks, 129
- COMMAND.COM file, 558, 857
- command interpreters, 857
- command prompt, 505, 506
  - text commands, 507–510, 509
  - utilities and programs run from, 506–507, 506

- command updates in ATA/ATAPI-5, 138
- Communication Network Riser (CNR) slots, 91–92, 92, 858
- communication ports, 75–76
- communications for printer, 188
  - IEEE 1394, 189
  - infrared, 188–189
  - network, 188
  - parallel, 188
  - SCSI, 189
  - serial, 188
  - USB, 188
  - wireless, 189–190
- compact disc read-only memory. *See* CD-ROM/CD-RW/DVD/DVDRW drives
- compact installation type, 586, 626, 858
- compatibility
  - in OS installation, 582–585
  - in OS upgrades, 623–624
  - upgrades for, 367–368
- Complementary Metal Oxide Semiconductor. *See* CMOS (Complementary Metal Oxide Semiconductor)
- composition, paper, 192
- compressed air, 282–283
- compression
  - in disk read/write process, 122
  - file, 518
- Computer Management Console, 536–537, 537
  - for services and applications, 538
  - for storage, 538
  - system tools in, 537–538
- Computer Management tool, 826, 827
- Computer Name and Administrator Password screen, 614
- computer preparation for OS installation, 589
  - Windows startup disk
    - for formatting, 591
    - for optimization, 591–592
    - for partitioning, 589–591, 590
    - using, 593
- computers
  - names of, 858
  - resolving, 748–750
    - in Windows 98/Me upgrades, 627
  - safety for, 407–408
  - System control panel for, 527
- conditioning step in EP process, 858
- conductors, 858
- conduits, 385, 858
- CONFIG.SYS file, 430, 558, 858
- ConfigSafe tool, 838
- configuration settings, 274
  - DMA, 277–278
  - I/O addresses, 278–279
  - IRQ lines, 275–276
  - issues in, 816
  - memory addresses, 276–277
- conflicts, SCSI ID, 151
- Connect To The Internet option, 763
- Connect To The Network At My Workplace option, 764
- Connect Using A Broadband Connection That Is Always On option, 765
- Connect Using A Broadband Connection That Requires A Username And Password option, 765
- Connect Using A Dial-Up Modem option, 765
- connection protocols, 261
- connectivity devices, 253, 858
  - bridges, 254–255
  - brouters, 255
  - gateways, 255
  - hubs/switches, 254
  - repeaters, 253–254
  - routers, 255
- connector slots, 83
- connectors
  - coaxial cable, 243, 243
  - CPU\_FAN, 299–300, 300
  - fiber-optic cable, 246, 247
  - keyboard, 26, 26, 325, 325
  - peripheral port, 27–29, 27–30, 48–53, 48–53
  - power, 13, 13
    - AT system, 14, 14
    - ATX system, 15, 15
  - CD-ROM, 321
  - floppy drive, 13, 14, 313–314, 313
  - motherboard, 25, 25
  - standard peripherals, 15, 15
  - twisted-pair cable, 244–245, 245
- consistency of Registry, 831
- consumables, printer, 193–194, 895
- contention in IEEE 802.3 CSMA/CD, 236
- Control boxes, 502, 502
- control circuits in bubble-jet printers, 174
- Control Panel
  - in laser printers, 209–210
  - programs in, 523–526, 525
  - System. *See* System control panel
- Control Program for Microcomputer (CP/M)
  - operating system, 464–465, 464, 858

- controller boards, 133
  - controllers
    - floppy disk, 130–131, 130, 872
    - hard disk drive, 35
  - conventional memory, 858
  - converting to FAT32, 833, 834
  - cooling mechanisms, 294–295, 294
    - heatsink fans, 299–301, 300
    - heatsinks, 295–299, 296–299
    - optimizing, 400
      - air cooling, 401
      - liquid cooling, 294, 401–402
      - phase change cooling, 402
  - cooperative multitasking, 462, 471, 858
  - copiers, 196–197
  - Copy To option, 528
  - copying Windows 98 files in upgrades, 628
  - core voltage, CPU, 330, 858
  - corona assembly, 203
  - corona rollers, 179, 858
  - corona wires, 859
  - corrupt files, SCANDISK for, 823–825, 824
  - cost, laptops vs. desktops, 345
  - CP/M (Control Program for Microcomputer)
    - operating system, 464–465, 464, 858
  - cps (characters per second) in daisy-wheel printers, 167
  - CPU\_FAN connector, 299–300, 300
  - CPUs (central processing units), 31–33, 32, 93, 855
    - architecture differences, 93–97
    - for building PCs, 288
    - cache memory for, 82–83, 94
    - chipsets for, 70–72, 71
    - clock speed, 94, 330, 859
    - clocks, 84, 859
    - CMOS settings for, 330
    - fans for, 299–301, 300, 328
    - form factors, 96–97, 896
    - installing, 291–293, 291–293
    - manufacturers, 98
      - AMD, 103–104
      - Intel, 98–103, 99–100
    - sockets, 23–24, 24, 76, 896
      - Slot 1, 78–79, 78–79, 902
      - Slot 2, 80
      - Slot A, 79, 902
      - Socket 7, 76–77, 77, 903
      - Socket 8, 77–78, 78, 903
      - Socket 370, 79–80, 80, 902
      - Socket 423, 81, 81, 902
      - Socket 478, 82, 82, 903
      - Socket A, 81, 81, 903
    - upgrading, 367–368, 371–372
  - crashes, hard disk, 152
  - CRC (Cyclical Redundancy Checking), 859
    - in ATA/ATAPI-4, 138
    - in UltraDMA mode, 135
  - creating objects, 515, 515
  - crosstalk, 859
  - CRT (cathode ray tube) technology, 42, 859
  - CSMA/CA (Carrier Sense Multiple Access with Collision Avoidance), 252–253
  - CSMA/CD (Carrier Sense Multiple Access with Collision Detection), 252
  - current
    - measuring, 286, 286
    - vs. voltage, 409
  - custom installation type, 586, 626, 859
  - cutouts, 307
  - cutover threshold in UPSs, 388, 859
  - CVT1.EXE tool, 833, 834
  - cyan, magenta, yellow, and black (CMYK)
    - system, 175, 857
  - Cyclical Redundancy Checking (CRC), 859
    - in ATA/ATAPI-4, 138
    - in UltraDMA mode, 135
  - Cylinder, Head, Sector (CHS) addressing, 136, 859
  - cylinders, 121, 121, 859
- 
- ## D
- D (Delta) channels, 258, 859
  - daisy-chaining, 147, 147, 860
  - daisy-wheel printers, 166–167, 167, 860
  - Dallas chip, 441
  - DAT (digital audio tape), 862
  - data bits, 860
  - data bus, 94–95, 860
  - data cables
    - CD-ROM, 318, 320
    - floppy drive, 312–313, 312
    - hard disk drive, 315–316, 316
  - data compression, 860
    - in disk read/write process, 122
    - file, 518
  - Data Link layer in OSI model, 234, 235, 860
  - Data Over Cable Service Interface Specification (DOCSIS), 257, 382, 860

- data set ready (DSR) signal, 866
- data terminal equipment (DTE) signal, 866
- data terminal ready (DTR) signal, 866
- data transfer rate, 860
- datagrams, 860
- date and time settings, 330, 614
- daughterboards, 860
- DB-series connectors, 48–49, 48, 860
- DC adapters, 356
- DC power supplies (DCPSs) in laser printers, 178
- DDR SDRAM (Double Data Rate SDRAM), 105–106
- de facto standards, 125, 860
- de jure standards, 125, 860
- dead pixels, 350, 447
- debouncing feature, 860–861
- dedicated servers, 224, 861
- default CMOS settings, 330, 861
- default gateways, 747, 861
- defragmenting disks, 795–796, 861
  - in Windows 9x, 796
  - in Windows 2000 Professional, 796, 797
  - in Windows NT Workstation, 796
  - in Windows XP Professional, 797–798, 798
- Delete option for user profiles, 528
- deleting objects, 515
- Delta (D) channels, 258, 859
- Depends On Password access, 719
- Description setting in Windows 98/Me upgrades, 627
- Desktop, 483–486, 484–485, 861
- desktop cases, 10, 10, 861
- Desktop Control Panel, 861
- desktop replacement laptops, 355, 861
- detection phase in Windows 9x installation, 596–597, 596
- developing in laser printer process, 176, 182–183, 182, 861
- developing rollers, 182, 861
- device addressing, SCSI, 150–152
- device bays, 6, 861
- device drivers. *See* drivers
- Device Manager, 533–534, 533–534, 538, 861
  - System control panel for, 528
  - for troubleshooting, 825–826, 825–826
  - for updating drivers, 534–536, 535–536
- DHCP (Dynamic Host Configuration Protocol), 706, 746–748, 751, 866
- diagnostics and troubleshooting, 198, 812, 861
  - bubble-jet printer problems, 199
    - paper jams, 200–201
    - print quality, 199–200
  - dot-matrix printer problems, 197
    - print quality, 197–198
    - printout jams inside printer, 198
    - stepper motor problems, 197–198
  - file-related problems, 814
    - boot issues, 817
    - configuration file issues, 816
    - swap file issues, 816
    - system files not found, 815
  - hardware. *See* hardware
  - key terms, 840
  - laser printer problems, 201
    - all-black pages, 203–204
    - blank pages, 202–203
    - ghosting, 206
    - image smudging, 205
    - pages of garbage, 206
    - paper jams, 201–202
    - printer testing, 207–209, 207
    - repetitive small marks and defects, 204, 204
    - tips, 209–210
    - vertical black lines, 205
    - vertical white lines, 205
  - other common problems, 818–821
  - power, 327
  - printing problems, 818
  - resources for, 422–423, 838–839
  - review question answers, 845–846
  - review questions, 841–844
  - steps in
    - documentation, 814
    - elimination of possibilities, 814
    - gathering information, 813–814
    - talking to customer, 813
  - summary, 839–840
  - tools for. *See* tools
  - video, 445
    - bad video, 446–447
    - LCD problems, 447
    - no video, 445–446
    - virus attacks, 821–822
- dial-up connections, 862
  - POTS, 256
  - in Windows XP, 762–767, 762–768
- dial-up modems, 380–381

- dial-up networking, 862
  - Windows 9x, 757–760, 757–758
  - Windows 2000, 760–762, 761
- dialers, 256, 862
- dies, 295–296, 296, 862
- differential backups, 862
- differential signaling, 145–146, 862
- digital audio tape (DAT), 862
- digital cameras, 384, 385, 862
- digital signals, 862
- Digital Subscriber Line (DSL), 256–257, 862
- Digital Subscriber Line (DSL) modems, 383
- digitally signed drivers, 647, 862
- DIMMs (Dual Inline Memory Modules), 22, 22, 74, 74, 862
- DIN-n connectors, 862
- DIP (dual inline package) switches, 274, 274, 862
- DIPs (dual inline packages), 32, 862
- Direct Memory Access (DMA), 277–278, 864
- Direct Rambus DRAM, 106
- Direct Rambus memory bus, 863
- direct-solder method, 863
- direct-solder ports, 29, 30
- directories. *See* folders
- disconnecting from Internet, 777–778
- disk caches, 800, 863
  - Internet Explorer, 802–803, 802–803
  - in Windows 9x, 800–801
  - in Windows NT/2000/XP, 801–802, 801
- disk-caching programs, 863
- disk controllers, 863
- Disk Defragmenter tool, 538
- disk drives, 118–119, 863
  - hard disk drives. *See* hard disk drives; IDE (Integrated Drive Electronics) systems
  - key terms, 157–158
  - removable, 124
    - CD-ROM, 124–126, 125. *See also* CD-ROM/CD-RW/DVD/DVDRW drives
    - floppy, 124, 124. *See also* floppy disk systems
    - optical, 126
    - tape, 126–127, 126
  - review question answers, 163–164
  - review questions, 159–162
  - SCANDISK for, 823–825, 824
  - SCSI. *See* SCSI (Small Computer System Interface)
  - summary, 156
- disk duplexing, 153, 154, 863
- disk interfaces, 92, 93
- Disk Management tool, 538
- disk mirroring, 153, 153, 863
- Disk Operating System (DOS), 864–865
  - MS-DOS and PC-DOS, 465, 886
    - origins, 465–466
    - printing in, 688
    - versions, 466–468
  - troubleshooting, 430
    - backups, 432–433
    - CONFIG.SYS and AUTOEXEC.BAT files, 430
    - REM Statements, 430–432
- disk sectors, 863
- disk striping, 154–155, 154
- disk subsystem enhancements, 402
- disk theory, 127, 127
- disk thrashing, 795, 816
- disk volumes, 152
- diskettes, 35, 127–128, 128, 864
- dislodged chips and cards, 449
- display systems, 42, 864
  - display concepts, 42
  - liquid crystal displays, 46–47, 47
  - monitors, 45–46, 45
  - for portable computers, 346, 349–350, 359
  - troubleshooting, 445
    - bad video, 446–447
    - LCD problems, 447
    - no video, 445–446
    - video technologies, 42–45
- distributed processing, 221, 864
- distributions, Linux, 469
- DIX connectors, 243, 243
- DIX Ethernet networks, 240, 864
- DLL (Dynamic Link Library) files, 866
- DMA (Direct Memory Access), 277–278, 864
- DMA channels, 84, 87, 864
- DMA modes, 134–135, 864
- DNS (Domain Name System), 745–746, 864
- docking ports, 864
- docking stations, 355, 355, 864
- DOCSIS (Data Over Cable Service Interface Specification), 257, 382, 860
- Documents submenu, 491
- Domain Name System (DNS), 745–746, 864
- domains, 527, 864
- dongle connections, 29, 29, 864
- dongles, 29, 29, 324, 864

DOS (Disk Operating System), 864–865  
 MS-DOS and PC-DOS, 465, 886  
   origins, 465–466  
   printing in, 688  
   versions, 466–468  
 troubleshooting, 430  
   backups for, 432–433  
   CONFIG.SYS and AUTOEXEC.BAT files, 430  
   REM Statements for, 430–432  
 DOS prompt, 865  
 DOS shells, 865  
 dot-matrix printers, 167–168, 168, 865  
   troubleshooting, 197  
     print quality, 197–198  
     printout jams inside printer, 198  
     stepper motor problems, 197–198  
 dot pitch, 45, 390, 865  
 dots per inch (dpi), 865  
 double-clicking, 484  
 Double Data Rate SDRAM (DDR SDRAM), 105–106  
 double-density disks, 865  
 dpi (dots per inch), 865  
 Dr. Watson utility, 819  
 draft quality printing, 168  
 DRAM (Dynamic Random Access Memory), 33, 105, 867  
   Direct Rambus, 106  
   Double Data Rate SDRAM, 105–106  
   Extended Data Out, 105  
   Fast Page Mode, 105  
   Synchronous, 105  
 drawing tablets, 865  
 drive bays, 347, 865  
 drive geometry, 121, 121, 865  
 drive holes, 128, 865  
 drive imaging, 588, 865  
 drive interfaces, 25  
 drive letters, 865  
 drivers, 462, 861, 865  
   ASD.EXE for, 833, 833  
   in hardware installation, 647  
   loading and installing, 648  
   for NICs, 252  
   for printers, 191  
   signing, 528, 865  
   updating, 534–536, 535–536, 621  
   upgrades for, 368  
 drives. *See* disk drives  
 DSL (Digital Subscriber Line), 256–257, 862

DSL (Digital Subscriber Line) modems, 383  
 DSL endpoints, 257, 866  
 DSR (data set ready) signal, 866  
 DTE (data terminal equipment) signal, 866  
 DTR (data terminal ready) signal, 866  
 dual booting, 587–588, 866  
 Dual Inline Memory Modules (DIMMs), 22, 22, 74, 74, 862  
 dual inline package (DIP) switches, 274, 274  
 dual inline packages (DIPs), 32, 862  
 dumb terminals, 866  
 DUN connections, 862  
   Windows 9x, 757–760, 757–758  
   Windows 2000, 760–762, 761  
 duplex, 866  
 duplex printing, 866  
 duplexing, 153, 154  
 DVD burners, 38  
 DVD-ROM drives. *See* CD-ROM/CD-RW/  
   DVD/DVDRW drives  
 dye-sublimation printers, 187  
 Dynamic Host Configuration Protocol (DHCP), 706, 746–748, 751, 866  
 Dynamic Link Library (DLL) files, 866  
 Dynamic RAM (DRAM), 33, 105, 867  
   Direct Rambus, 106  
   Double Data Rate SDRAM, 105–106  
   Extended Data Out, 105  
   Fast Page Mode, 105  
   Synchronous, 105

---

## E

e-mail, 746, 776–777, 777, 868  
 ECC (Error Correcting Code) memory, 108, 869  
 ECP (Enhanced Capabilities Port), 55, 868  
 edge connectors, 867  
 EDIT program, 506–507, 506, 829–830  
 EDO (Extended Data Out) DRAM, 105, 867  
 EEOC (Equipment Exceeds Operator  
   Capability) errors, 425  
 EEPROM (Electrically Erasable Programmable  
   Read-Only Memory), 374, 867  
 EGA (Enhanced Graphics Adapter) video, 43, 867  
 EIDE (Enhanced IDE), 136  
 8-bit buses, 848  
 8.3 naming convention, 511, 586, 848  
 802.3 standard, 848  
 802.11b standard, 360

- 802.11g standard, 360
- 80386 processor, 98
- 80486 processor, 98–99, 99
- EISA (Extended Industry Standard Architecture), 867
- EISA Configuration Utility (EISA Config), 867
- Electrically Erasable Programmable Read-Only Memory (EEPROM), 374, 867
- electricity, 867
- electromagnetic drawing tablets, 867
- electromagnetic interference (EMI), 241, 387, 867
- electron guns, 45, 45, 390, 868
- electronic stepper motors, 178, 868
- electrophotographic (EP) printers. *See* EP (electrophotographic) laser printers
- electrostatic discharge (ESD), 404–405, 868
  - antistatic bags for, 406
  - antistatic mats for, 406, 406, 869
  - antistatic wrist straps for, 405, 405, 849
  - other protection methods, 406–407
- emergency repair disks (ERDs)
  - Windows 2000, 571–573, 572
  - Windows NT Workstation, 571
- EMI (electromagnetic interference), 241, 387, 867
- EMM386.EXE file, 558, 868
- EMS (Expanded Memory Specification), 869
- Enable Printer Spooling option, 669
- encoding in disk read/write process, 122, 868
- Encryption option, 518
- End User License Agreement (EULA), 595, 869
- endpoints, DSL, 257, 866
- Enhanced Capabilities Port (ECP), 55, 868
- Enhanced Graphics Adapter (EGA) video, 43, 867
- Enhanced IDE (EIDE), 136
- enhanced keyboards, 868
- Enhanced Parallel Ports (EPP), 55, 868
- enumeration/detection phase in Windows 9x
  - installation, 596–597, 596
- envelope feeders, 196, 868
- environment variables, 529, 804, 868
- environmental problems, 449–450
- EP (electrophotographic) laser printers, 175, 868
  - components, 176
    - DC power supply, 178
    - drums, 868
    - fusing assembly, 179, 179
    - high-voltage power supply, 177
    - laser scanning assembly, 177, 177
    - ozone filter, 180
    - paper transport assembly, 178, 178
    - printer controller circuitry, 180
    - toner cartridges, 176–177, 176
    - transfer corona assembly, 178–179, 179
  - print process, 180, 868
    - charging, 181, 181
    - cleaning, 180–181, 181
    - developing, 182–183, 182
    - fusing, 183–184, 184
    - summary, 184, 184
    - transferring, 183, 183
    - writing, 181–182, 182
- EPP (Enhanced Parallel Ports), 55, 868
- EPROM (Erasable Programmable Read-Only Memory), 869
- Equipment Exceeds Operator Capability (EEOC) errors, 425
- Erasable Programmable Read-Only Memory (EPROM), 869
- ERDs (emergency repair disks)
  - Windows 2000, 571–573, 572
  - Windows NT Workstation, 571
- ergonomics, 869
- error codes, laser printer, 208–209
- Error Correcting Code (ECC) memory, 108, 869
- ESD (electrostatic discharge), 404–405, 868
  - antistatic bags for, 406
  - antistatic mats for, 406, 406, 869
  - antistatic wrist straps for, 405, 405, 849
  - other protection methods, 406–407
- Ethernet networks, 240, 869
- Ethernet ports, 27, 28, 869
- EULA (End User License Agreement), 595, 869
- even parity, 869
- even parity RAM, 107
- Event Viewer utility, 537, 827
- exhaust fans, 209
- exit rollers, 869
- expandability, laptops vs. desktops, 345
- Expanded Memory Specification (EMS), 869
- expanding folders, 513
- expansion bus and ports, 869
  - features, 83–84
  - in portables, 353–354, 354
- expansion cards. *See* adapter cards
- expansion devices in portables, 358–359
- expansion slots, 19–21, 21, 869
- Extended Data Out (EDO) DRAM, 105, 867
- extended DOS partitions, 869
- Extended Graphics Array (XGA) video, 44, 914
- Extended Industry Standard Architecture (EISA), 867

extended memory managers, 870  
 Extended Memory System (XMS), 870  
 extended partitions, 590, 870  
 external bus, 94, 870  
 external cache memory, 82–83, 870  
 external hard disks, 870  
 external modems, 381, 870  
 external peripheral connections, 325, 325–326  
 external storage, 383  
 EXTRACT.EXE tool, 829

---

## F

fail-safe defaults, 330  
 fans  
   case, 324, 324, 855  
   for CPUs, 328  
   for heatsinks, 299–301, 300  
 FAQ (Frequently Asked Questions) files, 423, 870  
 Fast Page Mode (FPM) DRAM, 105  
 FAT (file allocation table), 123, 586, 871  
 FAT32 filesystem, 587, 833, 834  
 fault tolerance, 152  
   disk duplexing, 153, 154  
   disk mirroring, 153, 153  
   disk striping, 154–155, 154  
   RAID, 155–156  
 fax modems, 196–197, 870  
 FC-PGA (Flip Chip-PGA) package type, 97, 870  
 FC-PGA2 package type, 97  
 FDDI (Fiber Distributed Data Interface), 871  
 FDISK.EXE tool, 590, 590, 830, 870  
 feed rollers, 178, 178, 870  
 feeders, 196, 870  
 Fiber Distributed Data Interface (FDDI), 871  
 fiber-optic cabling, 245–246, 246–247, 871  
 Fibre Channel, 147  
 Field Replaceable Units (FRUs), 334, 450, 873  
 file allocation table (FAT), 123, 586, 871  
 file compression programs, 871  
 file-copy phase  
   Windows 9x installation, 595–596, 596  
   Windows NT Workstation installation  
     graphical, 603–608, 603–608  
     text-based, 600–603, 601–602  
 file handles, 798  
 file servers, 224, 871  
 file system type in OS installation, 586–587  
 File Transfer Protocol (FTP), 746, 753, 776, 871  
 files  
   attributes of, 509–510, 509, 829  
     advanced, 517–518, 517  
     changing, 516–517, 517  
   corrupt, 871  
   important. *See* important files  
   locking, 222, 871  
   managing, 511–512  
   permissions for, 518–520, 519  
   problems related to, 814  
     boot issues, 817  
     configuration file issues, 816  
     swap file issues, 816  
     system files not found, 815  
   sharing, 716, 871  
     in Windows 9x, 718–720, 719  
     in Windows 2000, 732–734, 732–734  
     in Windows NT, 724–726, 724–726  
     in Windows XP, 737, 737  
   Windows Explorer for  
     capabilities of, 512–513, 512  
     navigating, 513–516, 513–515  
 Files and Settings Transfer Wizard, 622  
 FILES= settings, 798–799  
   in Windows 9x, 799  
   in Windows NT/2000/XP, 799–800  
 final releases, 435  
 Final Tasks screen, 614  
 finding files, 514, 514  
 finger mouse, 352, 352, 871  
 finishers, 196, 871  
 fire safety, 408  
 firewall protection, 768–770, 769  
 FireWire interface, 58, 59, 878  
   peripheral connection methods, 659–660  
   ports, 51, 51  
   for printers, 189  
 firmware, 31, 195, 197, 368, 872  
 5¼-inch floppy disks, 128, 128  
 fixed disk drives. *See* hard disk drives  
 fixed resistors, 872  
 flash memory, 872  
 flashlights, 282  
 flat-blade screwdrivers, 280, 280  
 flat-panel displays, 872  
 flatbed scanners, 872  
 Flip Chip-PGA (FC-PGA) package  
   type, 97, 870  
 floating-point calculations, 872  
 floating-point processors, 872

floppy disk systems, 35–36, 36, 124, 124, 311, 872  
 for building PCs, 289  
 cables, 131, 131, 312–313, 312, 872  
 capacity of, 129–130  
 CMOS settings, 331  
 controllers, 130–131, 130, 872  
 form factors for, 129  
 installing and configuring, 132  
 media, 35, 127–129, 128, 872  
 mounting in case, 311–312, 312  
 on-board connectors, 25  
 power supply connectors for, 13, 313–314, 313, 873  
 troubleshooting, 447–448  
 floppy drive interfaces, 25, 873  
 flux transitions, 122, 873  
 folders, 863  
   managing, 511–512  
   sharing  
     in Windows 9x, 718–720, 719  
     in Windows 2000, 732–734, 732–734  
     in Windows NT, 724–726, 724–726  
     in Windows XP, 737, 737  
   Windows Explorer for  
     capabilities of, 512–513, 512  
     navigating, 513–516, 513–515  
 fonts, 195, 873  
 footprints, 873  
 form factors, 96, 873  
   CPU  
     FC-PGA, 97  
     FC-PGA2, 97  
     OOI, 97  
     PGA, 96  
     PPGA, 97  
     SECC, 96–97  
     SECC2, 97  
     SEP, 97  
   floppy disk, 129  
   motherboards, 17–18, 18  
 form feed (FF), 873  
 FORMAT.COM, 873  
 formatter boards, 206, 873  
 formatting, 873  
   hard disks, 123, 143  
   partitions, 612–613  
   volumes, 152  
   Windows startup disk for, 591  
 FPM (Fast Page Mode) DRAM, 105

fragmentation, disk, 873  
   defragmenting, 795–796, 861  
     in Windows 9x, 796  
     in Windows 2000 Professional, 796, 797  
     in Windows NT Workstation, 796  
     in Windows XP Professional, 797–798, 798  
 free memory, 873  
 Frequently Asked Questions (FAQ) files, 423, 870  
 friction feed mechanisms, 873  
 front ends in LANs, 221  
 front-panel connectors, 307–308, 308  
 frontside buses, 72, 873  
 FRUs (Field Replaceable Units), 334, 450, 873  
 FTP (File Transfer Protocol), 746, 753, 776, 871  
 fuel cells, 378  
 full AT motherboards, 17, 874  
 Full Control permissions, 674, 725, 729, 873  
 full-duplex communications, 250, 874  
 full-height floppy drives, 129  
 full installation type, 586, 874  
 Full share access, 719  
 full tower cases, 6–8, 7, 874  
 function keys, 874  
 fuser heat lamps, 210  
 fusing assembly, 179, 179, 874  
 fusing in laser printer process, 183–184, 184, 874

---

## G

game ports, 27, 29, 874  
 gateways, 255, 874  
   default, 747, 861  
   wireless, 360  
 GDI.EXE file, 874  
 general information in Windows 2000  
   upgrades, 636  
 General Protection Faults (GPFs), 434–435, 818, 874  
 ghosting, 206  
 gigabytes, 874  
 Gopher protocol, 754  
 GPFs (General Protection Faults), 434–435, 818, 874  
 graphical installation phase  
   Windows 2000 Professional, 613–615, 613  
   Windows NT Workstation, 603, 603  
     computer information gathering, 603–605, 604–605

- finishing, 607–608, 607–608
- Windows networking installation, 605–606, 606
- Windows XP, 616–620, 617–620
- graphics accelerator boards, 875
- graphics mode, 43, 875
- GUIs (graphical user interfaces), 462, 482, 874–875
  - command prompt, 505, 506
    - text commands, 507–510, 509
    - utilities and programs run from, 506–507, 506
  - Computer Management Console, 536–538, 537
  - configuration, 510
  - Control Panel
    - programs in, 523–526, 525
    - System. *See* System control panel
  - Desktop, 483–486, 484–485
  - disk management, 541
    - backups, 542–543, 543
    - checking and optimizing, 543–544
    - disk preparation, 541, 542
  - failure to start, 819
  - file management, 511–512
    - attributes, 509–510, 509, 516–518, 517
    - permissions, 518–520, 519
    - Windows Explorer for, 512–516, 512–515
  - hardware management, 533
    - Device Manager, 533–534, 533–534
    - driver updates, 534–536, 535–536
  - icons, 497–498, 498
    - My Computer, 498–500, 499–500
    - Network Neighborhood/My Network Places, 500–501, 501
    - Recycle Bin, 501–502, 501
  - key terms, 547
  - Registry Editor, 544–546, 544
  - review question answers, 552–553
  - review questions, 548–551
  - Start Menu. *See* Start menu
  - summary, 546–547
  - system tools, 520–523, 521
  - Task Manager, 531–533, 531
  - Taskbar, 486–487, 486
  - virtual memory, 539–540, 539
  - windows
    - elements of, 502–503, 502–503
    - states of, 504–505, 504
  - Windows interface, 482–483, 483

---

## H

- half-duplex communications, 250, 875
- half-height drives, 129, 875
- handheld PCs (HPCs), 344, 875
- handheld scanners, 875
- hard disk drives, 35, 35, 119–120, 120, 875
  - for building PCs, 289
  - CMOS settings for, 142–143, 331
  - controllers, 875
  - defragmenting, 795–796, 861
    - in Windows 9x, 796
    - in Windows 2000 Professional, 796, 797
    - in Windows NT Workstation, 796
    - in Windows XP Professional, 797–798, 798
  - fault tolerance, 152
    - disk duplexing, 153, 154
    - disk mirroring, 153, 153
    - disk striping, 154–155, 154
    - RAID, 155–156
  - formatting, 123, 143, 873
    - partitions, 612–613
    - volumes, 152
    - Windows startup disk for, 591
- IDE. *See* IDE (Integrated Drive Electronics) systems
- installation, 314
  - data cables, 315–316, 316
  - jumpers, 314, 314
  - mounting in case, 315, 315
  - power cables, 316, 317
- managing, 541
  - backups, 542–543, 543
  - checking and optimizing, 543–544
  - preparation, 541, 542
- on-board connectors, 25
- organization of, 120–121, 120–121
- for portables, 378–379
- for printer fonts, 195
- read/write processes, 122–123
- specifications for, 121–122
- troubleshooting, 441–442
- upgrading, 368, 373–374, 373

- hard memory errors, 875
- hard resets, 875
- hardware, 875
  - compatibility of
    - in OS installation, 582–585
    - in OS upgrading, 623

- installing. *See* hardware installation
- managing, 533
  - Device Manager, 533–534, 533–534
  - driver updates, 534–536, 535–536
- networking, 703
- profiles for, 528
- System control panel for, 527–528
- tools, 280
  - compressed air, 282–283
  - flashlights, 282
  - multimeters, 283–286, 284–286
  - needle-nose pliers, 282, 282
  - screwdrivers, 280–282, 280–281
  - soldering irons, 283
  - wire strippers, 283, 283
- troubleshooting, 422, 437, 812
  - BIOS issues, 448
  - Device Manager for, 825–826, 825–826
  - display systems, 445–447
  - floppy drives, 447–448
  - FRUs, 450
  - hard disk drives, 441–442
  - key terms, 451
  - keyboard and mouse, 445
  - miscellaneous problems, 449–450
  - motherboards, 441
  - peripherals, 442–444
  - POST routines, 438–440
  - power supplies, 448–449
  - resources for, 422–423
  - review question answers, 455
  - review questions, 452–454
  - software in, 428–429
  - sound cards, 448
  - steps in, 424–428
  - summary, 450–451
  - in Windows 2000 upgrades, 635
- Hardware Compatibility List (HCL), 583, 875
- hardware installation, 646
  - key terms, 691
  - peripheral connection methods, 658–660
  - printers. *See* printers and printing procedure, 647–649
  - review question answers, 696–697
  - review questions, 692–695
  - rights and security issues, 646–647
  - summary, 691
  - version-specific issues, 649
    - Windows 9x, 649–651, 650–652
    - Windows 2000, 655–657, 656
      - Windows NT, 652–655, 652–655
      - Windows XP, 657–658, 657
- hardware interrupts, 876
- hardware ports, 84
- Hayes command set, 442–444
- HCL (Hardware Compatibility List), 583, 875
- head carriages, 170–171, 170
- headers
  - in network data frames, 876
  - in OSI model, 233
- heads, 119, 120, 876
- heat spreaders, 74, 876
- heatsinks, 294, 876
  - fans for, 299–301, 300
  - FC-PGA2 packages, 97
  - installing, 295–299, 296–299
- Help command, 493–495, 493–495
- Help And Support command, 493–495, 493–495
- Hercules Graphics Cards (HGC), 43
- hermaphroditic data connectors, 245, 876
- hertz, 876
- hexadecimal numbering system, 876
- HGC (Hercules Graphics Cards), 43
- Hibernation option, 497
- Hidden attribute, 829
- high-density disks, 876
- high-level formatting, 123, 876
- High Memory Area (HMA), 876
- High Voltage Differential (HVD) signaling, 146, 876
- high-voltage power supplies (HVPSs), 177, 203, 876
- high-voltage probes, 410, 876
- HIMEM.SYS driver, 558, 877
- HMA (High Memory Area), 876
- home pages, 877
- host adapters, 35, 35, 877
- hosts, TCP/IP, 745–747, 877
- hot-swap cards, 358
- hot-swap hard drives, 373
- HPCs (handheld PCs), 344, 875
- HTML (Hypertext Markup Language)
  - protocol, 746
- HTTP (Hypertext Transfer Protocol), 746, 753, 877
- HTTPS protocol, 746
- hubs, 254, 877
  - in star topologies, 230
  - USB, 50, 58, 58
- HVD (High Voltage Differential) signaling, 146, 876

HVPSs (high-voltage power supplies), 177, 203, 876  
 HWINFO.EXE tool, 832  
 hybrid topologies, 232, 877  
 hyperlinks, 746  
 Hypertext Markup Language (HTML) protocol, 746  
 Hypertext Transfer Protocol (HTTP), 746, 753, 877

**I**

i.link interface, 58  
 I/O addresses, 84, 278–279, 877  
 I/O voltages, 330, 877  
 IBM clone machines, 466  
 IBM-compatible computers, 878  
 IBM data connectors (IDCs), 245, 245, 877  
 IBM PCs, 877  
 IBM PS/2 computers, 878  
 ICF (Internet Connection Firewall), 767  
 ICMP (Internet Control Message Protocol), 238, 880  
 icons, 483, 497–498, 498, 878  
     My Computer, 498–500, 499–500  
     Network Neighborhood/My Network Places, 500–501, 501  
     Recycle Bin, 501–502, 501  
 ICs (integrated circuits), 879  
 ID conflicts, SCSI, 151  
 IDCs (IBM data connectors), 245, 245, 877  
 IDE (Integrated Drive Electronics) systems, 132–133, 132, 878  
     installation, 140–141, 141  
         CMOS drive configuration, 142–143  
         master/slave configuration, 141–142, 142  
     technologies, 133, 133  
         ATA-1, 136  
         ATA-2, 136  
         ATA-3, 137  
         ATA/ATAPI-4, 138  
         ATA/ATAPI-5, 138  
         ATA/ATAPI-6, 139  
         ATA/ATAPI-7, 139  
         ATAPI, 137  
         DMA modes in, 134–135  
         PIO modes in, 133–134  
         summary, 139–140  
         UltraDMA modes in, 135  
 IE (Internet Explorer) browser, 772  
     disk caches for, 802–803, 802–803  
     proxy settings, 774–776, 775  
     security settings and script support, 772–774, 772–774  
     Windows 9x settings for, 598, 598  
 IEEE 802 project models, 235–236  
     IEEE 802.3 CSMA/CD, 236  
     IEEE 802.5 Token Ring, 236–237  
 IEEE 1394 interface, 58, 59, 878  
     peripheral connection methods, 659–660  
     ports, 51, 51  
     for printers, 189  
 IHSs (Integrated Heat Sinks), 97  
 illegal operation errors, 819, 878  
 image smudging, 205  
 images, drive, 588, 878  
 impact printers, 166, 878  
     daisy-wheel, 166–167, 167  
     dot-matrix, 167–168, 168  
 important files, 556, 557  
     in Windows 9x, 557  
         Registry, 561, 562  
         startup files, 557–558  
         system file configuration tools, 558–561, 559–560  
     in Windows NT/2000/XP, 563  
         boot files, 563  
         system file configuration tools, 563–564  
 “Inaccessible Boot Device” error, 817  
 incremental backups, 878  
 Indexing option, 518  
 Indexing Service, 538  
 Industry Standard Architecture (ISA), 881  
     bus, 84–88, 85  
     slots, 20, 20  
 Infrared Data Association (IrDA)  
     standard, 52, 878  
 infrared devices, 386, 878  
     for portables, 354  
     ports, 51–52, 51  
     for printers, 188–189  
 inheriting permissions, 727  
 INI files, 436–437, 879  
 initialization commands, 442, 879  
 ink, 193–194  
 ink cartridges, 169–170, 169, 879  
 ink-jet printers, 168  
 inoculating against viruses, 822, 879

- input devices for portables, 350, 357
  - keyboards, 350–351
  - mice and pointing devices, 351
  - touch screens, 352–353, 352
  - touchpads, 351
  - touchpoints, 351–352, 352
  - trackballs, 351
- inserting video cards, 322–323, 322
- Install a New Copy of Windows 2000 (Clean Install) screen, 632
- Install Directory, 626
- installation manuals, 838
- installing
  - adapter cards, 321–324, 322
  - applications, 820
  - CPUs, 291–293, 291–293
  - drivers, 648
  - hardware. *See* hardware installation
  - heatsink fans, 299–301, 300
  - heatsinks, 295–299, 296–299
  - IDE/ATA disk systems, 140–143, 141–142
  - memory, 301–302, 302–303
  - modems, 379–380
  - motherboards. *See* motherboards
  - NICs, 251–252
  - operating systems. *See* operating systems (OSs)
  - power supplies, 309–311, 309–310
  - speakers and headphones, 332–333, 332–333
  - storage devices. *See* storage devices
- integrated circuits (ICs), 879
- Integrated Drive Electronics. *See* IDE
  - (Integrated Drive Electronics) systems
- Integrated Heat Sinks (IHSs), 97
- Integrated Services Digital Network (ISDN), 257–258, 383, 881
- integrated system boards, 17, 879
- Intel processors, 98
  - 80386, 98
  - 80486, 98–99, 99
  - Celeron, 101
  - future, 101–102
  - Overdrive and MMX, 100, 879
  - Pentium and Pentium Pro, 99–100, 100
  - Pentium II, 101
  - Pentium III, 101
  - Pentium 4, 101
  - summary, 102–103
- intellectual resources for troubleshooting, 422–423
- intelligent hubs, 254, 879
- interface circuitry, 879
- interfaces, printer, 187, 879
  - bubble-jet, 174
  - communication types, 188–190
  - software, 190–191, 879
- interlacing video, 44, 879
- interleaving, 122–123, 879
- internal modems, 381
- International Standards Organization (ISO), 880
- Internet, 255–256, 880
  - access software, 756–757
  - browsers, 770–776, 771–775
  - e-mail, 776–777, 777
  - firewall protection, 768–770, 769
  - FTP, 776
  - monitoring and disconnecting from
    - Internet, 777–778
    - Windows 9x DUN connections, 757–760, 757–758
    - Windows 2000 DUN connections, 760–762, 761
    - Windows XP DUN connections, 762–767, 762–768
  - connection types, 256
    - cable, 257
    - connection protocols, 261
    - dial-up/POTS, 256
    - DSL, 256–257
    - ISDN, 257–258
    - satellite, 258–259
    - summary, 260
    - wireless, 259–260
  - for diagnostic resources, 839
- Internet addresses, 880
- Internet Connection Firewall (ICF), 767
- Internet Control Message Protocol (ICMP), 238, 880
- Internet Explorer (IE) browser, 772
  - disk caches for, 802–803, 802–803
  - proxy settings, 774–776, 775
  - security settings and script support, 772–774, 772–774
  - Windows 9x settings for, 598, 598
- Internet Protocol (IP), 238, 880
- Internet Service Providers (ISPs), 256, 745, 880
- Internet zones, 773
- Internetwork Packet Exchange/Sequenced Packet Exchange. *See* IPX/SPX
  - (Internetwork Packet Exchange/Sequenced Packet Exchange) protocol
- internetworks, 700, 880

interrupt request (IRQ) lines, 83–84, 880  
     ISA default, 87  
     settings for, 275–276  
 interrupt request (IRQ) signals, 880  
 interrupts, 880  
 “Invalid boot disk” error, 817  
 invalid working directories, 821  
 inverse multiplexing, 258  
 IO.SYS file, 558  
 IP (Internet Protocol), 238, 880  
 IP addresses, 746–747, 880  
     automatic, 747–748  
     static, 747  
 IPCONFIG utility, 752–753, 881  
 IPX/SPX (Internetwork Packet Exchange/  
     Sequenced Packet Exchange) protocol,  
     238, 754–755  
     addressing in, 755  
     network addresses, 239–240, 755–756,  
         755, 881  
     socket identifiers, 756  
     station addresses, 756  
     configuring and managing, 756  
     name resolution in, 756  
 IrDA (Infrared Data Association)  
     standard, 52, 878  
 IRQ (interrupt request) lines, 83–84, 880  
     ISA default, 87  
     settings for, 275–276  
 IRQ (interrupt request) signals, 880  
 ISA (Industry Standard Architecture), 881  
     bus, 84–88, 85  
     slots, 20, 20  
 ISDN (Integrated Services Digital Network),  
     257–258, 383, 881  
 ISDN terminal adapters, 881  
 ISO (International Standards  
     Organization), 880  
 ISPs (Internet Service Providers), 256,  
     745, 880

---

## J

joystick ports, 27, 29  
 jumpers and DIP switches, 31, 31,  
     273, 273, 881  
     CD-ROM, 318, 319  
     hard drive, 314, 314

---

## K

kernel file, 881  
 key terms  
     building PCs, 336  
     diagnostics and troubleshooting, 840  
     disk drive storage, 157–158  
     GUI, 547  
     hardware  
         installation, 691  
         troubleshooting, 451  
     motherboards, 108–110  
     networking, 262–263, 778–779  
     operating systems, 474  
         architectures, 574  
         installing and upgrading, 638  
     optimization  
         PC, 414  
         Windows, 805  
     PC architecture, 60–62  
     portable systems, 361  
     printers, 211  
     safety, 414  
     upgrading, 392  
 keyboard/mouse port, 881  
 keyboard ports for portables, 354  
 keyboards  
     for building PCs, 289  
     connectors for, 26, 26, 325, 325  
     for portables, 350–351  
     PS/2 ports for, 52–53, 53, 59–60, 60  
     safety for, 410  
     troubleshooting, 445  
 keys  
     PCI bus, 89  
     Registry, 437  
 kilobits, 881  
 kilobits per second, 881  
 kilobytes, 881  
 kiosks, 352  
 knowledge base, 423

---

## L

L1 cache memory, 82, 881  
 L2 cache memory, 82–83, 881  
 lands, CD, 125

- LANs (local area networks), 221–222, 221–222, 883
- lapping process, 295, 881
- laptops. *See* portable systems
- laser printers, 175, 882
  - electrophotographic (EP). *See* EP (electrophotographic) laser printers
  - LED page printers, 185
    - print process, 185–186
    - toner cartridges for, 185
  - troubleshooting, 201
    - all-black pages, 203–204
    - blank pages, 202–203
    - ghosting, 206
    - image smudging, 205
    - pages of garbage, 206
    - paper jams, 201–202
    - printer testing, 207–209, 208
    - repetitive small marks and defects, 204, 204
    - tips, 209–210
    - vertical black lines, 205
    - vertical white lines, 205
- laser scanning assemblies, 177, 177, 882
- latency, 108, 121–122, 882
- LBA (Logical Block Addressing), 883
  - in ATA-2, 136
  - in CMOS drive configuration, 143
- LBA address size expansion, 139, 882
- LCD (liquid crystal display) technology, 42, 46–47, 47, 882
  - connections for, 325, 326
  - troubleshooting, 447
- LDAP (Lightweight Directory Access Protocol), 754
- lease periods, DHCP, 748
- least significant bit (LSB), 882
- LED page printers, 185, 882
  - process, 185–186
  - toner cartridges for, 185
- legacy devices, 368, 472, 882
- letter quality (LQ) printers, 167, 882
- Level 2 (L2) cache memory, 82–83, 881
- levels, RAID, 882
- license agreements
  - EULA, 595, 869
  - Windows 98/Me upgrades, 626
  - Windows 2000 upgrades, 633
- lights, modem, 381
- Lightweight Directory Access Protocol (LDAP), 754
- LiIon (lithium ion) batteries, 377, 883
- line conditioners, 387, 882
- line power, 387, 882
- Line Printer (LPR) Protocol, 754
- link lights, 251, 882
- Linux operating system, 469–470
- liquid cooling, 401–402, 882
- liquid crystal display (LCD) technology, 42, 46–47, 47, 882
  - connections for, 325, 326
  - troubleshooting, 447
- lithium ion (LiIon) batteries, 377, 883
- loading drivers, 648
- local area networks (LANs), 221–222, 221–222, 883
- local buses, 883
- Local Intranet zones, 773
- local printers, 660
  - in Windows 9x, 660
    - adding, 660–663, 661–663
    - existing, 664–665, 664–665
    - print jobs, 666–667, 667
    - spooling, 666, 666
  - in Windows 2000, 674
    - adding, 675–678, 675–678
    - existing, 678–680, 679
    - print jobs, 681, 682
    - security, 681, 681
    - spooling, 680, 680
  - in Windows NT, 667
    - adding, 667–670, 668–671
    - existing, 672–673
    - print jobs, 674
    - security, 674, 674
    - spooling, 673, 673
  - in Windows XP, 682
    - adding, 682–684, 683
    - existing, 684–685, 684
    - print jobs, 686, 687
    - security, 686, 686
    - spooling, 685–686, 685
- local resources, 701, 883
- Local Users And Groups utility, 537
- locating drivers, 647
- Log On From field, 713
- Log On Using Dial-Up Networking field, 714
- logging on, 883
  - problems in, 820
  - Windows 2000, 713–714, 713–714

- Windows NT Workstation, 608–609, 609, 710–711, 711
- Windows XP, 714
- logic boards, 883
- Logical Block Addressing (LBA), 883
  - in ATA-2, 136
  - in CMOS drive configuration, 143
- logical drives, 883
- logical memory, 883
- logical partitions, 590, 883
- logical topologies, 229, 883
- low-level formatting, 123, 143, 883
- low print quality problems, 197–198
- Low Voltage Differential (LVD) signaling, 146, 883
- LPR (Line Printer) Protocol, 754
- LPTx ports, 883
- LQ (letter quality) printers, 167, 882
- LSB (least significant bit), 882
- LVD (Low Voltage Differential) signaling, 146, 883

---

## M

- MAC address, 884
- Mac OS operating system, 469
- main motors, 884
  - dot-matrix printers, 199
  - laser printers, 210
- maintenance stations, 170
- major release versions, 435
- Make This The Default Internet Connection option, 767
- Manage Documents permissions, 674, 729
- manual Registry restores, 545
- manuals, 838
- MAPI (Messaging Application Programming Interface), 776, 885
- master drives, 136, 884
- Master File Table (MFT), 885
- master/slave configuration, 141–142, 142
- math coprocessors, 884
- MAUs (multistation access units), 240–241, 886
- Maximized windows, 504, 504
- maximum bus length, SCSI, 149–150
- Mbps (megabits per second), 884
- MBs (megabytes), 884
- MCA (Micro Channel Architecture), 884
- media
  - floppy disk systems, 35, 127–129, 128
  - network, 241
    - access methods, 252–253
    - cabling, 241–249, 242–243, 246–247
    - NICs, 249–252
  - print, 192–193
  - removable. *See* removable media
- megabits (Mbits), 884
- megabits per second (Mbps), 884
- megabytes (MBs), 884
- megahertz (MHz), 884
- memory, 33, 34, 104, 884
  - for building PCs, 288–289
  - CMOS, 34
  - DIMMs, 74, 74
  - DRAM, 33, 105
    - Direct Rambus, 106
    - Double Data Rate SDRAM, 105–106
    - Extended Data Out, 105
    - Fast Page Mode, 105
    - Synchronous DRAM, 105
  - installing, 301–302, 302–303
  - MicroDIMMs, 75
  - motherboard, 72–73
  - operational characteristics, 106
    - bit size of chip, 107
    - ECC vs. non-ECC, 108
    - latency, 108
    - parity vs. non-parity, 107–108
  - performance, 403
  - for portables, 347, 357, 378
  - printer, 195
  - RIMMs, 74, 74
  - ROM, 34
  - SIMMs, 73, 73
  - slots, 22, 22
  - SoDIMMs, 75, 75
  - SRAM, 33, 104
  - upgrading, 367, 372
  - VRAM, 106
- memory addresses, 276–277, 884
- memory effect, 377, 884
- memory maps, 884
- memory optimization, 884
- memory refresh, 884
- menu bars, 502, 503
- mesh topologies, 231–232, 232, 885
- Messaging Application Programming Interface (MAPI), 776, 885
- meters, 283–286, 284–286

- MFT (Master File Table), 885
- MHz (megahertz), 884
- Micro Channel Architecture (MCA), 884
- MicroDIMMs, 75, 885
- Microsoft Diagnostics (MSD), 834–835, 835, 886
- Microsoft Disk Operating System (MS-DOS), 465, 886
  - origins, 465–466
  - printing in, 688
  - versions, 466–468
- Microsoft Windows, 470–471. *See also* specific operating systems by name
  - versions, 471
    - Windows 1, 471
    - Windows 2, 471
    - Windows 3.x, 471–472
    - Windows 95, 472–473
    - Windows 98/Me/NT/2000/XP, 473
- mid tower cases, 8, 8, 885
- mini tower cases, 9, 885
- mini-DIN 6 connectors, 52–53, 53
- mini tower cases, 8–9, 9, 885
- Minimize buttons, 502, 503
- Minimized windows, 505
- minimum installation type, 586
- minimum requirements for OS installation, 582–585
- mirroring, 153, 153, 155
- “Missing NTLDR” error, 817
- MMX processor, 100
- Modem Dialing Information screen, 614
- modems and transceivers, 41, 41, 885
  - cable modems, 382, 382
  - DSL modems, 383
  - installing, 379–380
  - ISDN modems, 383
  - regular modems, 380–381
- modifying Registry entries, 545
- Molex connectors, 15, 15
- monitoring from Internet, 777–778
- monitors, 45–46, 45, 885
  - for building PCs, 290
  - connections for, 325, 326
  - safety for, 410
  - upgrading, 390–391, 390
- monochrome video, 43, 885
- mopiers (multiple original copiers), 194, 885
- most significant bit (MSB), 886
- motherboards, 16, 16, 18, 18, 886
  - architecture, 70
  - bus, 83
    - chipsets, 70–72, 71
    - memory, 72–73
  - BIOS, 30, 92
  - for building PCs, 288
  - chipsets, 70–72, 71
  - CMOS battery, 30–31
  - communication ports, 75–76
  - cooling mechanisms, 294–295, 294
    - heatsink fans, 299–301, 300
    - heatsinks, 295–299, 296–299
  - CPUs. *See* CPUs (central processing units)
  - expansion slots, 19–21, 20–21
  - external cache memory, 82–83
  - firmware, 31
  - form factors for, 17–18, 18
  - installing, 303–304
    - front-panel connectors, 307–308, 308
    - installing and securing, 308–309, 309
    - removing back-panel punchouts, 307
    - removing case cover, 304, 304–305
    - standoffs for, 305–307, 306
  - jumpers and DIP switches, 31, 31
  - key terms, 108–110
  - keyboard connectors, 26, 26
  - memory for. *See* memory
  - memory slots, 22, 22
  - on-board disk connectors, 25
  - peripheral ports and connectors, 27–29, 27–30
    - in portables, 346, 347
  - power connectors, 25, 25
  - removing from box, 290–291
  - review question answers, 115–116
  - review questions, 111–114
  - summary, 108
  - troubleshooting, 441
  - types of, 16–17
  - upgrading, 370–371, 371
- mounting in cases
  - CD-ROM drives, 318, 319
  - floppy drives, 311–312, 312
  - hard disk drives, 315, 315
- mouse, 886
  - for building PCs, 289
  - connections for, 325, 326
  - and pointing devices for portables, 351
    - ports for, 354
    - touch screens, 352–353, 352
    - touchpads, 351
    - touchpoints, 351–352, 352
    - trackballs, 351

PS/2 ports for, 52–53, 53, 59–60  
 safety for, 410  
 troubleshooting, 445

MS-DOS and PC-DOS operating systems,  
 465, 886  
 origins, 465–466  
 printing in, 688  
 versions, 466–468

MSB (most significant bit), 886

MSBACKUP program, 886

MSCONFIG tool, 559–561, 560, 828, 828, 886

MSD (Microsoft Diagnostics) tool, 834–835,  
 835, 886

MSDOS.SYS file, 557

multifunction interface boards, 133

multifunction printers, 197, 886

multimedia, 886

multimeters, 283–286, 284–286, 886

multiple files, selecting, 513

multiple original copiers (mopiers), 885

multiplexers, 247, 886

multipurpose servers, 224, 886

multistation access units (MAUs),  
 240–241, 886

multisync monitors, 886

multitasking, 275, 462–463, 471, 887

multithreading, 463, 887

multiword DMA modes, 134–135, 887

My Computer icon, 498–500, 499–500

My Network Places icon, 500–501, 501

My Recent Documents submenu, 491

---

## N

NAK (negative acknowledgment) packets,  
 748, 887

names  
 files, 511, 586  
 IPX/SPX resolution, 756  
 shares, 718, 720

narrow SCSI, 145

navigation in Windows Explorer, 513–516,  
 513–515

near letter quality (NLQ) printers, 168, 887

needle-nose pliers, 282, 282

negative acknowledgment (NAK) packets,  
 748, 887

Nehalem processor, 102

NetBEUI protocol, 238–239, 749, 887

NetBIOS (Network Basic Input/Output  
 System), 238–239, 749, 887

NetWare network access, 715–716, 716

network addresses, 888  
 in IPX, 755–756, 755  
 in TCP/IP, 747

Network Basic Input/Output System  
 (NetBIOS), 238–239, 749, 887

network interface cards. *See* NICs (network  
 interface cards)

Network layer in OSI model, 234, 235, 888

Network Neighborhood icon, 500–501

Network News Transfer Protocol (NNTP), 754

network operating systems (NOSs), 226, 461, 888

network security providers, 888

networks and networking, 220–221, 462,  
 700–701, 887  
 adapter cards for, 704, 887  
 architectures, 240  
 ARCNet, 241  
 Ethernet, 240  
 Token Ring, 240–241  
 basics, 701–702, 702  
 in building PCs, 331, 331  
 client software for, 887  
 IEEE 802 project models, 235–237  
 OSI model, 233–234, 235  
 protocols, 237–240  
 clients in, 704  
 Windows 9x, 703–706, 704–705  
 Windows 2000/XP, 712–714, 712–714  
 Windows NT Workstation, 706–714,  
 707, 710–714  
 components, 223  
 network operating systems, 226  
 resources, 225  
 servers, 223–224  
 workstations, 224–225  
 connectivity devices, 253–255

DUN  
 Windows 9x, 757–760, 757–758  
 Windows 2000, 760–762, 761

identification of, 527

installation on, 588, 887

Internet. *See* Internet

key terms, 262–263, 778–779

LANs vs. WANs, 221  
 LANs, 221–222, 221–222  
 WANs, 222, 223

logon problems, 820

- media, 241
    - access methods, 252–253
    - cabling, 241–249, 242–243, 246–247
    - NICs, 249–252
  - in OS installation, 586
  - for portables, 355, 359–360
  - printing on, 687
    - communication for, 188
    - in Windows 9x, 687–690, 688–690
    - in Windows NT/2000/XP, 690–691
  - protocols, 237, 704, 744–745, 897
    - addressing, 239–240
    - AppleTalk, 239
    - IPX/SPX. *See* IPX/SPX (Internetwork Packet Exchange/Sequenced Packet Exchange) protocol
    - NetBEUI, 238–239
    - TCP/IP. *See* TCP/IP (Transmission Control Protocol/Internet) suite
  - resources in, 225–227
    - client-server model, 228–229, 228
    - peer-to-peer networks, 227, 227
    - sharing resources. *See* sharing files and printers
  - review question answers, 268–269, 785–786
  - review questions, 264–267, 780–784
  - summary, 261, 778
  - Task Manager for, 532
  - topologies, 229–233, 229–232
  - troubleshooting connections, 821
  - in Windows 95, 702
  - Windows 2000 Professional settings for, 614
  - NiCad (nickel cadmium) batteries, 377, 888
  - nickel metal hydride (NiMH) batteries, 377, 888
  - NICs (network interface cards), 40–41, 40, 224, 249, 887
    - drivers for, 252
    - installing, 251–252
    - PC bus type, 252
    - performance, 252, 402–403
    - preparing data for, 249
    - in printers, 188, 195–196
    - sending and controlling data for, 250
    - settings for, 250–251
  - NiMH (nickel metal hydride) batteries, 377, 888
  - NLQ (near letter quality) printers, 168, 887
  - NNTP (Network News Transfer Protocol), 754
  - No Access permission
    - in Windows 2000, 734–735
    - in Windows NT, 674, 725, 728
  - no video, troubleshooting, 445–446
  - Nocona processor, 102
  - node addresses, 888
    - in IPX, 756
    - in TCP/IP, 747
  - nodes, 888
  - non-PnP devices, 646
  - nonconductors, 888
  - nondedicated servers, 224, 888
  - nonintegrated system boards, 16, 888
  - noninterlaced monitors, 888
  - Northbridge chipsets, 71–72, 888
  - NOSs (network operating systems), 226, 461, 888
  - notebook computers, 889. *See also* portable systems
  - NSLOOKUP utility, 752
  - NT File System (NTFS), 587, 725, 889
  - NTBOOTDD.SYS file, 563
  - NTDETECT.COM file, 563
  - NTFS (NT File System), 587, 725, 889
  - NTLDR file, 563
  - NTOSKRNL.EXE file, 563
  - null modems, 56, 889
  - numeric keypads, 889
  - NWLink protocol, 754–755, 889
    - addressing in, 755
    - network addresses, 239–240, 755–756, 755, 881
    - socket identifiers, 756
    - station addresses, 756
    - configuring and managing, 756
    - name resolution in, 756
- 
- O**
- objects, 501
  - octets, 240, 889
  - odd parity, 889
  - odd parity RAM, 107
  - off board disk interfaces, 25
  - ohms, 889
  - OLGA on Interposer (OOI) package type, 97, 889
  - on-board disk connectors, 25
  - on-board disk interfaces, 25
  - on-chip cache memory, 82
  - OOI (OLGA on Interposer) package type, 97, 889
  - open source code, 462, 469
  - Open Systems Interconnection (OSI) model, 233–234, 235, 890

- opening files, 513
- operating system architectures, 556
  - boot sequence, 564
    - advanced startup options, 566–569
    - Windows 9x, 564–565
    - Windows NT/2000/XP, 565–566
  - important files, 556, 557
    - in Windows 9x, 557–561, 557, 559–560, 562
    - in Windows NT/2000/XP, 563–564
  - key terms, 574
  - review question answers, 579–580
  - review questions, 575–578
  - startup disks and emergency repair disks
    - Automated System Recovery, 573
    - Windows 98/Me, 569–570, 570
    - Windows 2000, 571–573, 572
    - Windows NT Workstation, 571
  - summary, 573–574
- “Operating System Not Found” error, 817
- operating systems (OSs), 460–462, 461, 889
  - alternative, 468–469
    - Linux, 469–470
    - Mac OS, 469
  - architectures. *See* operating system architectures
  - choosing, 474
  - classic, 463–464
    - CP/M, 464–465, 464
    - MS-DOS and PC-DOS, 465–468
    - OS/2, 468
  - error messages, 428
  - GUI. *See* GUIs (graphical user interfaces)
  - installing, 334, 582
    - computer preparation for, 589–593, 590
    - hardware compatibility and requirements, 582–585
    - key terms, 638
    - methods, 588–589
    - options, 585–588
    - post-installation routines, 620–622, 621
    - prerequisites, 582
    - review question answers, 643–644
    - review questions, 639–642
    - summary, 638
    - Windows 9x. *See* Windows 9x/Me operating systems
    - Windows 2000 Professional. *See* Windows 2000 operating system
    - Windows NT Workstation. *See* Windows NT Workstation
    - Windows XP. *See* Windows XP operating system
  - key terms, 474
  - review question answers, 479–480
  - review questions, 475–478
  - summary, 474
  - terms and concepts, 462–463
  - in troubleshooting, 813
  - types of, 463
  - upgrading, 622
    - application compatibility, 623–624
    - hardware compatibility, 623
    - key terms, 638
    - to NT Workstation 4.0, 629–631, 630
    - prerequisites, 622
    - review question answers, 643–644
    - review questions, 639–642
    - service packs and updates, 624
    - summary, 638
    - upgrade paths, 622–623
    - upgrade utilities for, 624
    - to Windows 98/Me, 624–629, 625, 627
    - to Windows 2000, 631–636, 631–633, 635
    - to Windows XP, 636–638, 637
  - Windows, 470–471. *See also* specific Windows operating systems by name
    - Windows 1, 471
    - Windows 2, 471
    - Windows 3.x, 471–472
    - Windows 95, 472–473
    - Windows 98/Me/NT/2000/XP, 473
- optical drives, 39, 124, 126, 889
- optical mouse, 289, 889
- optical scanners, 384, 384
- optical touch screens, 890
- optimization, 788
  - defragmenting disks, 795–796
    - in Windows 9x, 796
    - in Windows 2000 Professional, 796, 797
    - in Windows NT Workstation, 796
    - in Windows XP Professional, 797–798, 798
- disk caches, 800
  - in Internet Explorer, 802–803, 802–803
  - in Windows 9x, 800–801
  - in Windows NT/2000/XP, 801–802, 801
- FILES= and BUFFERS= settings, 798–799
  - in Windows 9x, 799
  - in Windows NT/2000/XP, 799–800
- hard disks, 543–544

key terms, 805  
 PC performance, 400  
   additional performance enhancements, 403–404  
   cooling system optimization, 400–402  
   disk subsystem, 402  
   key terms, 414  
   memory, 403  
   NIC, 402–403  
   review question answers, 419–420  
   review questions, 415–418  
   specialized video cards, 403  
   summary, 414  
 review question answers, 809  
 review questions, 806–808  
 summary, 804  
 temporary files, 803–804  
 virtual memory, 788–789  
   in Windows 9x, 789–790, 790  
   in Windows 2000, 792–793, 792  
   in Windows NT, 790–792, 791  
   in Windows XP, 793–795, 794–795  
 Windows 98 boot disk for, 593  
 Windows startup disk for, 591–592  
 option diskettes, 890  
 opto-mechanical mouse, 890  
 Organic Land Grid Arrays, 97  
 OS/2 operating system, 468  
 OSI (Open Systems Interconnection) model, 233–234, 235, 890  
 OSs. *See* operating systems (OSs)  
 Other users in Windows 2000, 731  
 overclocking, 330, 404, 890  
 Overdrive processor, 100, 879  
 ozone filters, 180

---

## P

packets, 137, 748, 890  
 paddle boards, 133  
 page-description languages, 190–191, 890  
 page frames, 890  
 page printers, 175, 185, 890  
   process, 185–186  
   toner cartridges for, 185  
 pages, 890  
 paging files, 539, 790, 890  
 Palm Desktop functions, 385  
 Palo Alto Research Center (PARC), 470

PAP (Password Authentication Protocol), 760  
 paper, 192  
 paper-feed mechanisms, 171–173, 172–173, 890  
 paper-feed sensors, 173, 173, 890  
 paper feeders, 173, 173  
 paper jams  
   in bubble-jet printer, 200–201  
   in laser printers, 201–202  
 paper pickup rollers, 178, 178, 891  
 paper registration rollers, 891  
 paper transport assembly, 178, 178, 891  
 paper trays, 172–173, 173, 891  
 parallel ports and interfaces, 27, 27, 54, 891  
   bidirectional, 54  
   cables, 55, 55  
   CMOS settings for, 330–331  
   enhanced, 55  
   for peripheral connections, 658  
   for printers, 188  
   standard, 54  
 parallel processing, 99, 891  
 PARC (Palo Alto Research Center), 470  
 parity, 891  
   in fault tolerance, 155  
   in RAM, 107–108  
 parked printheads, 175, 891  
 partition tables, 891  
 partitions, 541, 891  
   formatting, 612–613  
   Windows 9x boot disk for, 589–591, 590  
   in Windows 2000 Professional  
     installation, 612  
 pass-through boards, 133  
 pass-through cables, 320, 320  
 passive hubs, 254, 891  
 passive matrix screens, 47, 47, 891  
 passive termination, 149, 891  
 Password Authentication Protocol (PAP), 760  
 Password Never Expires option, 723  
 passwords, 891  
   Windows 2000, 713  
   Windows NT, 723  
 patches, 429, 435  
 paths, 511, 891  
 PC architecture, 4, 5  
   adapter cards, 39–41, 40–42  
   cases, 5–12, 5, 7–11  
   CPUs, 31–33, 32  
   display devices, 42–47, 45, 47  
   key terms, 60–62

- memory, 33–34, 34
- motherboards. *See* motherboards
- ports and cables. *See* peripherals
- power supplies, 12–15, 12–15
- review question answers, 67–68
- review questions, 63–66
- storage devices, 34–39, 35–37
- summary, 60
- PC Card expansion bus, 353, 892
  - information and identification, 353–354, 354
  - for upgrading, 379
- PC Card slots, 892
- PC Card socket services, 892
- PC Cards, 892
- PC-DOS operating systems, 465, 886
  - origins, 465–466
  - PC-DOS 1.0, 892
  - printing in, 688
  - versions, 466–468
- PC Memory Card International Association (PCMCIA), 892
- PCBs (printed-circuit boards), 895
- PCI (Peripheral Component Interconnect)
  - bus, 892
  - information and identification, 89, 89
  - slots, 21, 21
- PCMCIA expansion bus, 353, 892
  - information and identification, 353–354, 354
  - for upgrading, 379
- PCMCIA (PC Memory Card International Association), 892
- PCs (personal computers)
  - architecture. *See* PC architecture
  - building. *See* building PCs
- PDAs (Personal Digital Assistants), 344, 385, 892
- peel-off labels, 199
- peer-to-peer networks, 227, 227, 892
- Pentium processors, 99–100, 100, 892
  - Pentium II, 101
  - Pentium III, 101
  - Pentium 4, 101
  - Pentium Pro, 99–100, 892
- perf obstructions, 198
- performance. *See also* optimization
  - laptops vs. desktops, 345
  - NICs, 252
  - System control panel for, 529
  - Task Manager for, 532
- Performance Logs And Alerts utility, 537
- Peripheral Component Interconnect (PCI)
  - bus, 892
  - information and identification, 89, 89
  - slots, 21, 21
- peripherals, 379, 892
  - connection methods, 658
    - FireWire, 659–660
    - parallel, 658
    - SCSI, 659
    - serial, 658
    - USB, 659
  - external storage, 383
  - interfaces and cables, 54, 892
    - parallel, 54–55, 55
    - serial, 55–60, 56–60
  - modems and transceivers, 379–383, 382
  - port connector types, 27–29, 27–30, 48
    - Centronics, 53, 53
    - DB-series, 48–49, 48
    - IEEE 1394, 51, 51
    - infrared, 51–52, 51
    - PS/2, 52–53, 53
    - RCA, 52, 52
    - RJ-Series, 49–50, 49
    - USB, 50–51, 50
  - scanners and digital cameras, 383–384, 384–385
  - troubleshooting, 442–444
- permissions
  - file, 518–520, 519
  - in Windows NT, 725–726, 726, 728–729, 728–729
- persistence of vision, 44
- personal computers (PCs)
  - architecture. *See* PC architecture
  - building. *See* building PCs
- Personal Digital Assistants (PDAs), 344, 385, 892
- Personalize Your Software screen, 614
- PGA (Pin Grid Array) packages, 32, 96, 893
- phase change cooling, 402, 893
- Phillips screwdrivers, 281, 281
- phosphors, 45, 390, 391
- Physical layer in OSI model, 234, 235, 893
- physical topologies, 229, 893
- pickup rollers, 172, 172
- pickup stepper motors, 172, 893
- Pin Grid Array (PGA) packages, 32, 96, 893
- PING utility, 752, 893
- pinouts, serial cable, 56, 56

- pins
  - in dot-matrix printers, 167
  - memory chip, 22
- PIO (Programmed I/O) method, 133–134, 893
- pits, CD, 125
- pixels, 350, 447, 893
- Plain Old Telephone Service (POTS), 256, 894
- planar boards. *See* motherboards
- Plastic Pin Grid Array (PPGA) package type, 97, 893
- platforms, 482, 893
- platters, 119, 893–894
- plenum-rated coating, 242, 894
- pliers, 282, 282
- plug-and-play files in Windows 2000
  - upgrades, 634
- Plug-and-Play (PnP) hardware, 646, 894
- Point and Print technology, 690, 894
- pointing devices for portables, 351
  - ports for, 354
  - touch screens, 352–353, 352
  - touchpads, 351
  - touchpoints, 351–352, 352
  - trackballs, 351
- polling, network, 253
- POP3 (Post Office Protocol 3), 754, 776–777, 894
- port addresses, 278–279
- port replicators, 355, 894
- portability, laptops vs. desktops, 345
- portable installation type, 586, 626, 894
- portable systems, 46, 344, 894
  - architecture, 344–345
  - cases, 346
  - component installation, 356
    - displays, replacing, 359
    - expansion devices, 358–359
    - input devices, 357
    - memory, 357
    - power systems, 357
    - storage devices, 356–357
    - wireless networking, 359–360
  - vs. desktops, 345
  - displays, 346, 349–350
  - docking stations, 355, 355
  - expansion bus and ports, 353–354, 354
  - input devices, 350, 357
    - keyboards, 350–351
    - mice and pointing devices, 351–353, 352
  - key terms, 361
  - memory, 347
    - motherboard and supporting circuitry, 346, 347
    - networking, 355
    - power systems, 356
    - review question answers, 364
    - review questions, 362–363
    - storage, 347–348, 348–349
    - summary, 360
    - upgrading, 377
      - hard drives, 378–379
      - memory, 378
      - PCMCIA cards for, 379
      - power sources, 377–378
- ports, 48, 894. *See also* cables and cabling
  - communication, 75–76
  - for peripherals. *See* peripherals
- POST (power on self-test), 438–440, 894–895
- post-installation routines, 620, 621
  - restoring user data files, 621–622
  - updating drivers, 621
- Post Office Protocol 3 (POP3), 754, 776–777, 894
- PostScript, 894
- Potomac processor, 102
- POTS (Plain Old Telephone Service), 256, 894
- power
  - connecting, 327–328
  - coverage problems, 387–388
  - quality problems, 387
  - troubleshooting, 327
- power on self-test (POST), 438–440, 894–895
- power supplies, 12–13, 12, 895
  - in bubble-jet printers, 174, 894
  - for building PCs, 288
  - connectors for, 13, 13
    - AT system, 14, 14
    - ATX system, 15, 15
    - CD-ROM, 321
    - floppy drive, 13, 14, 313–314, 313
    - motherboard, 25, 25
    - standard peripherals, 15, 15
  - installing, 309–311, 309–310
  - in laser printers, 177–178, 203
  - for portables, 356–357, 377–378
  - safety for, 408–409
  - troubleshooting, 448–449
  - upgrades for, 367
- power surges, 895
- power users, 895
- PPGA (Plastic Pin Grid Array) package type, 97, 893

- PPPoE connections, 765
- preemptive multitasking, 462–463, 895
- prefile copy phase in Windows 9x
  - installation, 595
- Preparing to Upgrade to Windows 2000 screen, 633, 633
- Prescott processor, 102
- Presentation layer in OSI model, 234, 235, 895
- preventative maintenance, 895
  - cleaning systems, 412–413
  - electrostatic discharge, 404–407, 405–406
- PRI (Primary Rate Interface), 258, 895
- primary DOS partitions, 895
- primary mouse clicks, 484
- primary network logons, 706
- primary partitions, 590
- Primary Rate Interface (PRI), 258, 895
- Print permissions, 674, 729
- print servers, 224
- printed-circuit boards (PCBs), 895
- printer control assemblies, 896
- printer control circuits, 174, 896
- printer controller circuitry, 180
- printer-resident fonts, 195, 896
- printers and printing, 166, 386–387, 660
  - bubble-jet. *See* bubble-jet printers
  - buffers in, 174, 895
  - drivers for, 191, 206
  - dye-sublimation, 187
  - impact, 166
  - daisy-wheel, 166–167, 167
  - dot-matrix, 167–168, 168
  - interfaces
    - bubble-jet, 174
    - communication types, 188–190
    - software, 190–191, 879
  - key terms, 211
  - laser. *See* EP (electrophotographic) laser printers; laser printers
  - local. *See* local printers
  - network, 687
    - communication for, 188
    - in Windows 9x, 687–690, 688–690
    - in Windows NT/2000/XP, 690–691
  - ports for, 27, 27
  - print jobs
    - in Windows 9x, 666–667, 667
    - in Windows 2000, 681, 682
    - in Windows NT, 674
    - in Windows XP, 686, 687
  - printheads, 896
    - alignment of, 896
    - in bubble-jet printers, 169–170, 169
    - in daisy-wheel printers, 166, 167
  - printing process, 174–175
  - review question answers, 216–217
  - review questions, 212–215
  - safety for, 409–410
  - sharing, 716, 742–743, 742–744
    - in Windows 9x, 720–721, 720–721
    - in Windows 2000, 735, 735
    - in Windows NT, 727–729, 727–729
    - in Windows XP, 737, 738
  - solid-ink, 186
  - summary, 210
  - supplies, 187, 192
    - consumables, 193–194
    - media, 192–193, 895
    - options and upgrades, 194–197
  - testing, 207
    - error codes, 208–209
    - self-tests, 207–208, 207
  - thermal, 186–187
  - troubleshooting. *See* diagnostics and troubleshooting
- printhead carriages, 896
- printout jams, 197–198
- processes, Task Manager for, 532
- processors. *See* CPUs (central processing units)
- product activation, 618–619, 896
- product keys, 896
  - Windows 98/Me upgrades, 626
  - Windows 2000 upgrades, 633
- profiles, 528, 910
- Program Manager, 896
- program notes in Windows 2000 upgrades, 636
- Programmed I/O (PIO) method, 133–134, 893
- programs, running from command prompt, 506–507, 506
- Programs/All Programs submenu, 489–491, 490–491
- propagation delay, 259, 896
- proprietary designs, 897
  - cases, 11
  - motherboards, 18
- protected mode, 897
- protocol stacks, 897
- protocols, network, 237, 704, 744–745, 897
  - addressing, 239–240
  - AppleTalk, 239

IPX/SPX. *See* IPX/SPX (Internetwork Packet Exchange/Sequenced Packet Exchange) protocol  
 NetBEUI, 238–239  
 TCP/IP. *See* TCP/IP (Transmission Control Protocol/Internet) suite  
 proxy settings, IE, 774–776, 775  
 PS/2 interface, 59–60, 60  
   connectors, 26, 26  
   mouse, 897  
   ports, 52–53, 53  
 pucks, 897  
 punch cards and tape, 118–119  
 push-in standoffs, 305, 306, 897

---

## Q

QDOS (Quick-and-Dirty Disk Operating System), 465, 897  
 QSOP (Quad Small Outline Package), 897  
 quality of construction, laptops vs. desktops, 345

---

## R

radio frequency interference (RFI), 387, 897  
 rag stock, 192, 897  
 RAID (Redundant Array of Inexpensive Disks), 155–156  
 RAM (random access memory), 897.  
   *See also* memory  
 RAM disks, 897  
 Rambus Inline Memory Modules (RIMMs), 74, 74, 897  
 random access storage devices, 119  
 rasterizing process, 180, 897  
 RCA cable, 59, 59  
 RCA jacks, 52, 52  
 Read-Only attribute, 829  
 read-only memory (ROM), 34, 899  
 Read-Only share access, 719  
 Read permissions, 725  
 read/write heads, 119, 120, 898  
 read/write processes, 122–123  
 real mode, 898  
 rebooting computer in troubleshooting, 426  
 recommended hardware in OS installation, 582–585  
 Recovery CDs, 837–838, 898  
 Recycle Bin icon, 501–502, 501  
 redirecting local resources, 701  
 Redundant Array of Inexpensive Disks (RAID), 155–156  
 reference disks, 898  
 refresh rate, 46, 391, 898  
 refresh signals for DRAM, 33  
 REGEDIT.EXE tool, 828–829  
 Regional Settings screen, 614  
 registered jack (RJ) connectors, 49–50, 49, 244, 898  
 registration information, 544  
 registration rollers, 178, 178  
 Registry, 437, 437, 898  
   backups, 831  
   consistency of, 831  
   in Windows 9x, 561, 562  
   in Windows 2000 Professional installation, 614  
 Registry Editor, 544–545, 544, 828–829  
   for modifying Registry, 545  
   for restoring Registry, 545–546  
 regular modems, installing, 380–381  
 reinstalling applications, 428  
 REM statements, 430–432, 898  
 Remote Assistance, 531  
 removable mass storage, 898  
 removable media, 124, 898  
   CD-ROM drives, 124–126, 125  
   floppy disk drives, 124, 124  
   optical disk drives, 126  
   tape drives, 126–127, 126  
 Removable Storage tool, 538  
 removal and replacement procedures, 334  
 removing  
   back-panel punchouts, 307  
   case cover, 304, 304–305  
   motherboard from box, 290–291  
 rendering characters, 42  
 repeaters, 253–254, 898  
 repeating problems, 429  
 repetitive small marks and defects in laser printers, 204, 204  
 reports in Windows 2000 upgrades, 634–636, 635  
 request to send (RTS) signal, 900  
 requirements for OS installation, 582–585  
 resistance measurements, 284–285, 285  
 resistor packs, 898  
 resistors, 898

- resolving names, 749–750, 749–750
  - resource discovery expansion cards, 423, 898
  - resources, 898
    - for hardware troubleshooting, 422–423
    - MSD.EXE for, 834–835, 835
    - network, 225–227
      - client-server model, 228–229, 228
      - peer-to-peer networks, 227, 227
      - sharing resources. *See* sharing files and printers
  - Restart option, 497
  - Restart the Computer in MS-DOS Mode option, 497
  - restarting computer in Windows 98/Me upgrades, 628
  - Restore buttons, 502, 503
  - restore points, 424, 530
  - restore process, 898
  - Restored windows, 505
  - restoring
    - Registry
      - in Windows 9x/Me, 545–546
      - in Windows NT/2000/XP, 546
    - user data files, 621–622
  - Restricted Sites zones, 773
  - Restricted Users in Windows 2000, 731
  - retaining clips, 301, 899
  - review question answers
    - building PCs, 341–342
    - diagnostics and troubleshooting, 845–846
    - disk drive storage, 163–164
    - GUI, 552–553
    - hardware installation, 696–697
    - hardware troubleshooting, 455
    - motherboards, 115–116
    - networking, 268–269, 785–786
    - operating systems, 479–480
      - architectures, 579–580
      - installing and upgrading, 643–644
    - optimization
      - PC, 419–420
      - Windows, 809
    - PC architecture, 67–68
    - portable systems, 364
    - printers, 216–217
    - safety, 419–420
    - upgrading PC components, 397–398
  - review questions
    - building PCs, 337–340
    - diagnostics and troubleshooting, 841–844
    - disk drive storage, 159–162
    - GUI, 548–551
    - hardware installation, 692–695
    - hardware troubleshooting, 452–454
    - motherboards, 111–114
    - networking, 264–267, 780–784
    - operating systems, 475–478
      - architectures, 575–578
      - installing and upgrading, 639–642
    - optimization, 806–808
      - PC, 415–418
      - Windows, 806–808
    - PC architecture, 63–66
    - portable systems, 362–363
    - printers, 212–215
    - safety, 415–418
    - upgrading PC components, 393–396
  - revision numbers, 435, 899
  - RFI (radio frequency interference), 387, 897
  - RG cable type, 242–243
  - ribbon cartridges, 193, 899
  - rights issues in hardware installation, 646–647
  - RIMMs (Rambus Inline Memory Modules), 74, 74, 897
  - ring topologies, 231, 231, 899
  - riser cards, 18, 899
  - RJ (registered jack) connectors, 49–50, 49, 244, 898
  - RJ-11/RJ-45 connectors, 899
  - RLL (Run Length Limited) technology, 122
  - ROM (read-only memory), 34, 899
  - root directory, 512, 899
  - rounded cables, 402, 899
  - routers, 255, 360, 899
  - RS-232-C interface, 899
  - RS-232 cables, 247–248
  - RS-422/423/449 interface, 900
  - RTS (request to send) signal, 900
  - Run Command, 495–496, 496
  - Run Length Limited (RLL) technology, 122
  - running utilities and programs from command prompt, 506–507, 506
- 
- S**
- Safe Modes, 629, 836–837, 900
    - Safe Mode with Command Prompt, 837
    - Safe Mode with Networking, 837
  - safety, 407
    - computers, 407–408

- environmental concerns, 449–450
- key terms, 414
- keyboard and mouse, 410
- monitors, 410
- power supplies, 408–409
- printers, 409–410
- review question answers, 419–420
- review questions, 415–418
- summary, 414
- sags, 900
- satellite connections, 258–259, 900
- SCANDISK tool, 823–825, 824
- scanners, 196–197, 383–385, 384, 900
- SCANREG.EXE tool, 831, 831
- screen savers, 900
- screw-in standoffs, 305, 306, 900
- screwdrivers, 280–282, 280–281
- scripts
  - for IE, 772–774, 772–774
  - WSCRIPT.EXE for, 832
- SCs (subscriber connectors), 246, 247
- SCSI (Small Computer System Interface), 144–145, 900
  - device installation and configuration, 147
    - addressing, 150–152
    - maximum bus length, 149–150
    - termination and cabling, 147–149, 147–149
  - ID conflicts in, 151
  - peripheral connection methods, 659
  - for printers, 189
  - types of, 145
    - proposed implementations, 146–147
    - SCSI-1, 145
    - SCSI-2, 145–146, 146
    - SCSI-3, 146
- SCSI adapters, 145, 900
- SCSI addresses, 144, 900
- SCSI bus, 144, 900
- SCSI chains, 144, 900
- SCSI terminators, 900
- SDRAM (Synchronous DRAM), 105, 905
- SE (single-ended) signaling, 145
- Search submenu, 492, 492–493
- SECC (Single Edge Contact Cartridge) package type, 78, 96–97, 902
- SECC2 package type, 97
- secondary mouse clicks, 484
- sector translation, 143
- sectors, 120, 120–121, 591, 900
- security
  - file permissions, 518–520, 519
  - in hardware installation, 646–647
  - in IE, 772–774, 772–774
  - for video cards, 323
  - in Windows 2000, 681, 681
  - in Windows NT, 674, 674, 725–726, 726, 728–729, 728–729
  - in Windows XP, 686, 686
- selecting files, 513
- Self-Monitoring and Analysis Tool (SMART), 137
- self-tests
  - POST, 438–440, 894–895
  - printer, 207–208, 207
- semiconductors, 901
- sending and controlling NIC data, 250
- SEP (Single Edge Processor) package type, 97
- separator pads, 172, 172, 901
- SEPP (Single Edge Processor Package), 78, 902
- sequential storage devices, 119
- Serial ATA interface, 139, 901
- serial communications, 901
- serial interfaces and ports, 27, 27, 55–56, 901
  - cables, 247–248, 901
  - CMOS settings for, 330–331
  - IEEE 1394, 58, 59
  - for peripheral connections, 658
  - for printers, 188
  - PS/2, 59–60, 60
  - RCA, 59, 59
  - standard, 56–57, 56–57
  - USB, 57–58, 57–58
- serial mouse, 901
- serial printers, 901
- servers, 223–224, 901
- service packs, 624
- services, 901
  - Computer Management Console for, 538
  - in networking, 705
- Services tool, 538
- Session layer in OSI model, 234, 235, 901
- Set Up A Home Or Small Office Network option, 764
- Set Up An Advanced Connection option, 764
- Set Up My Connection Manually option, 764
- Settings submenu, 492
- setup file access in Windows 2000 Professional installation, 610
- shadowing BIOS, 374

- share names, 718, 720, 901
- share permissions, 725–726, 726, 728–729, 728–729, 901
- Shared Folders utility, 537
- sharing files and printers, 716, 738–739, 739–740
  - printer setup for, 742–743, 742–744
  - in Windows 9x, 716–718, 717
    - folders, 718–720, 719
    - printers, 720–721, 720–721
  - in Windows 2000, 729–730
    - folders, 732–734, 732–734
    - options for, 740–741, 740
    - printers, 735, 735
    - user accounts, 730–732, 730–732
  - in Windows NT, 721
    - folders, 724–726, 724–726
    - printers, 727–729, 727–729
    - user accounts, 721–723, 722–724
  - in Windows XP, 735
    - folders, 737, 737
    - options for, 741, 741
    - printers, 737, 738
    - user accounts, 736–737, 736
- shells, 462, 901
- shielded twisted-pair (STP) cable, 904
- shims, 359
- Shut Down command, 496–497
- shutdown, System control panel for, 530
- signal pathways, 72, 902
- signing drivers, 528, 865
- SIMMs (Single Inline Memory Modules), 22, 22, 73, 73, 902
- Simple Mail Transport Protocol (SMTP), 753, 777, 902
- Single Edge Contact Cartridge (SECC) package type, 78, 96–97, 902
- Single Edge Processor (SEP) package type, 97
- Single Edge Processor Package (SEPP), 78, 902
- single-ended (SE) signaling, 145
- Single Inline Memory Modules (SIMMs), 22, 22, 73, 73, 902
- Single Inline Packages (SIPs), 902
- single-purpose servers, 224, 902
- single-sided floppy disks, 130
- single word DMA modes, 134–135, 902
- SIPs (Single Inline Packages), 902
- site licenses, 902
- size, hard disk, 121
- slave drives, 136, 902
- slimline cases, 10–11, 11
- slockets, 80, 902
- Slot 1 processor sockets, 78–79, 78–79, 902
- Slot 2 processor sockets, 80
- Slot A processor sockets, 79, 902
- slots, 83
- Small Computer System Interface. *See* SCSI (Small Computer System Interface)
- Small Outline DIMMs (SoDIMMs), 22, 22, 75, 75
- SMART (Self-Monitoring and Analysis Tool), 137
- SMTP (Simple Mail Transport Protocol), 753, 777, 902
- sneakernet, 220
- social side of troubleshooting, 425–426
- socket identifiers, 756, 903
- Socket Services software, 354, 903
- sockets, CPU, 23–24, 24, 76, 896
  - Slot 1, 78–79, 78–79, 902
  - Slot 2, 80
  - Slot A, 79, 902
  - Socket 7, 76–77, 77, 903
  - Socket 8, 77–78, 78, 903
  - Socket 370, 79–80, 80, 902
  - Socket 423, 81, 81, 902
  - Socket 478, 82, 82, 903
  - Socket A, 81, 81, 903
- SoDIMMs (Small Outline DIMMs), 22, 22, 75, 75
- software, 460, 903
  - for building PCs, 290
  - client, 225
  - for networking, 703
    - NetWare network access clients, 715–716, 716
    - Windows 9x, 703–706, 704–705
    - Windows 2000/XP, 712–714, 712–714
    - Windows NT Workstation, 706–714, 707, 710–714
  - printer interface, 190–191, 879
  - tools, 287
  - for troubleshooting, 423
  - troubleshooting, 428–429
    - in DOS, 430–433
    - in Windows, 433–437, 433–434, 437
  - types of, 461–462, 461
- software drivers, 903
- software reports for upgrades, 635
- soldering irons, 283
- solenoids, 167, 167, 903
- solid-ink printers, 186, 903

- sound cards, 41, 42, 448
- sound pass-through cables, 320, 320
- source code, 462, 903
- Southbridge chipsets, 72, 903
- speaker installation, 332–333, 332–333
- special permissions, 519
- specialized video cards, 403
- speed
  - bus, 95–96
  - clock, 94, 330, 859
  - Overdrive and MMX processors for, 100
  - spin, 121, 903
- spikes, 387, 903
- spin speed, 121, 903
- spindles, 119, 120, 903
- spooling
  - in Windows 9x, 666, 666
  - in Windows 2000, 680, 680
  - in Windows NT, 673, 673
  - in Windows XP, 685–686, 685
- SPSs (standby power supplies), 388, 389, 904
- square connectors, 246
- SRAM (static RAM), 33, 104, 904
- ST (straight tip) connectors, 246, 247
- ST506 interface, 904
- stabilizer bars, 171, 171, 904
- stacks, 904
- Stand By option, 497
- standard desktop icons, 498
  - My Computer, 498–500, 499–500
  - Network Neighborhood/My Network Places, 500–501, 501
  - Recycle Bin, 501–502, 501
- standard parallel ports, 54
- standard peripheral power connectors, 15, 15, 904
- standard permissions, 519
- standard screwdrivers, 280, 280
- standard serial cable, 904
- standard serial interfaces, 56–57, 56–57
- Standard Users, 731
- standards, CD, 125
- standby power supplies (SPSs), 388, 389, 904
- standoffs, 305–307, 306, 904
- star topologies, 230, 230, 904
- start bits, 904
- Start menu, 483, 487–489, 488, 904
  - Documents/My Recent Documents submenu, 491
  - Help/Help And Support command, 493–495, 493–495
  - Programs/All Programs submenu, 489–491, 490–491
  - Run Command, 495–496, 496
  - Search submenu, 492, 492–493
  - Settings submenu, 492
  - Shut Down/Turn Off Computer command, 496–497, 496
  - in Windows 2000 Professional installation, 614
- startup and recovery, System control panel for, 530
- startup disks and emergency repair disks, 569, 589
  - Automated System Recovery, 573
  - for formatting, 591
  - for optimization, 591–592
  - for partitioning, 589–591, 590
  - using, 593
  - Windows 98/Me, 569–570, 570
  - Windows 2000, 571–573, 572
  - Windows NT Workstation, 571
- startup files in Windows 9x, 557–558
- states in GUI windows, 504–505, 504
- static-charge eliminator strips, 178, 179, 904
- static IP addressing, 747
- static RAM (SRAM), 33, 104, 904
- station IPX addresses, 756
- Step by Step/Single Step Mode, 837
- stepper motors, 904
  - in bubble-jet printers, 170–172, 171
  - in dot-matrix printers, 199
  - in laser printers, 178
- sticks of memory, 301, 302, 904
- stop bits, 904
- storage devices, 34, 118. *See also* specific
  - storage devices by name
  - CD-R and CD-RW drives, 37–38
  - CD-ROM drives, 37, 37
  - Computer Management Console for, 538
  - DVD burners, 38
  - DVD-ROM drives, 38
  - floppy drives, 35–36, 36
  - hard disk drives, 35, 35
  - installing
    - CD/DVD devices, 318–321, 319–320
    - expansion cards, 321–324, 322, 324
    - external peripherals, 325, 325–326
    - floppy disk drives, 311–314, 312–314
    - hard disk drives, 314–316, 314–317
    - optical drives, 39

- for portable systems, 347–348, 348–349, 356–357
- punch cards and tape, 118–119
- tape backup, 39
- Zip drives and Jaz drives, 38
- storage pyramid, 127, 127
- STP (shielded twisted-pair) cable, 904
- straight tip (ST) connectors, 246, 247
- striping, 154–155, 154
- stylus, 904
- submarining effect, 47
- subnet masks, 240, 747, 905
- subscriber connectors (SCs), 246, 247
- summary sections, 139–140
  - building PCs, 335
  - diagnostics and troubleshooting, 839–840
  - disk drive storage, 156
  - GUI, 546–547
  - hardware installation, 691
  - hardware troubleshooting, 450–451
  - motherboards, 108
  - networking, 261, 778
  - operating systems, 474
    - architectures, 573–574
    - installing and upgrading, 638
  - optimization
    - PC, 414
    - Windows, 804
  - PC architecture, 60
  - portable systems, 360
  - printers, 210
  - safety, 414
  - upgrading PC components, 391
- superscalar processing, 99
- SuperVGA (SVGA) standard, 44, 905
- supplies, printer, 192
  - consumables, 193–194
  - options and upgrades, 194–197
  - print media, 193
- surge suppressors, 905
- surges, 387, 905
- SVGA ports, 910
- SVGA (SuperVGA) standard, 44, 905
- swap files, 539, 788, 816, 905
- switches
  - DIP, 274, 274
  - network, 254
  - in star topologies, 230
  - in text commands, 509
- synchronization, 905
- Synchronous DRAM (SDRAM), 105, 905

- synchronous transmissions, 905
- syntax, 509, 905
- SYSEDIT tool, 559, 559, 830–831, 831, 906
- System attribute, 829, 905
- system boards. *See* motherboards
- system bus, 94
- system configuration, ConfigSafe for, 838
- System Configuration Utility, 828
- System control panel, 526–527, 527
  - Advanced tab, 529–530
  - Automatic Updates tab, 531
  - Device Manager tab, 528
  - Hardware/Computer Name tab, 527–528
  - Hardware Profiles tab, 528
  - Network Identification/Computer Name tab, 527
  - Remote Assistance tab, 531
  - System Restore tab, 530
  - User Profiles tab, 528
- system disks, 906
- system editor, 559, 559, 830–831, 831, 906
- System Failure option, 530
- system files
  - configuration tools for, 558–559
    - MSCONFIG, 559–561, 560
    - SYSEDIT, 559, 559
    - Windows NT/2000/XP, 563–564
  - missing, 815
    - in Windows NT/2000/XP, 563
- System Information utility, 537
- SYSTEM.INI file, 558, 906
- system limitations, upgrades for, 368
- system lock-ups, 819
- system properties, 500, 500
- system resources, 433–434, 433–434, 906
- system restore, 530
- system settings in Windows 9x, 597, 598
- system software, 906
- System Startup option, 530
- system tools, 520–523, 521, 537–538
- system variables, 530

---

## T

- tablet PCs, 352, 906
- tabs, 906
- tape cartridges, 906
- tape drives, 39, 126–127, 126, 906
- Task Manager, 531–533, 531

- Taskbar, 483, 486–487, 486, 906
- Taskbar Properties Screen, 490
- TCP (Transmission Control Protocol), 238
- TCP/IP (Transmission Control Protocol/Internet) suite, 237–238, 745–746, 753–754, 906
  - addressing, 746–748
  - computer name resolution, 748–750, 749–750
  - managing, 751–753, 752
  - protocols for, 753–754
  - settings for, 750–751
- Tejas processor, 102
- Telnet protocol, 754
- temporary files, 906
  - managing, 803–804
  - swap, 906
  - in Windows 2000 Professional installation, 614
- Temporary Internet Files directory, 802–803, 906
- terminals, 907
- Terminate and Stay Resident (TSR) programs, 820, 907
- terminating resistor packs, 145, 907
- termination in SCSI installation, 147–149, 147–149
- terminators, 144, 907
- testing
  - PCs, 327–328
  - printers, 207, 210
    - error codes, 208–209
    - self-tests, 207–208, 207
- text-based installation phase
  - Windows NT Workstation, 600–603, 601–602
  - Windows XP, 616
- text commands, 507–510, 509
- text mode, 43, 907
- thermal contact patches, 294, 907
- thermal grease, 907
- thermal interface material (TIM), 294, 907
- thermal printers, 186–187, 907
- thick Ethernet cable, 907
- thickness, paper, 192
- thin Ethernet cable, 907
- thrashing, 795, 816, 907
- 3½-inch diskettes, 128, 128
- three-pin fan connectors, 299, 848
- 386 enhanced mode, 848
- TIM (thermal interface material), 294, 907
- time zone setting, 526, 526
- title bars, 502, 503
- token passing, 253, 907
- Token Ring networks, 240–241, 907–908
- tolerance bands, 908
- toner and toner cartridges, 908
  - in laser printers, 175–177, 176
  - in LED page printers, 185
  - refill kits, 194
  - requirements, 194
  - troubleshooting, 203
- tools, 823
  - for building PCs
    - hardware. *See* hardware
    - software, 287
  - for troubleshooting, 823
    - ASD.EXE, 833, 833
    - ATTRIB.EXE, 829
    - Computer Management, 826, 827
    - ConfigSafe, 838
    - CVT1.EXE, 833, 834
    - Device Manager, 825–826, 825–826
    - EDIT.COM, 829–830
    - Event Viewer, 827
    - EXTRACT.EXE, 829
    - FDISK.EXE, 830
    - HWINFO.EXE, 832
    - MSCONFIG.EXE, 828, 828
    - MSD.EXE, 834–835, 835
    - Recovery CD, 837–838
    - REGEDIT.EXE, 828–829
    - Safe Modes, 836–837
    - SCANDISK, 823–825, 824
    - SCANREG.EXE, 831, 831
    - SYSEDIT.EXE, 830–831, 831
    - WinMSD, 835–836, 836
    - WSCRIPT.EXE, 832
- topologies, network, 229, 908
  - bus, 229–230, 229
  - hybrid, 232
  - mesh, 231–232, 232
  - ring, 231, 231
  - star, 230, 230
  - summary, 232–233
- Torx screwdrivers, 281–282, 281, 908
- touch screens, 352–353, 352, 908
- touchpads, 351, 908
- Touchpoints, 351–352, 352, 908
- Tracert utility, 752, 908
- trackballs, 351, 908
- tracks, 120, 120–121, 908
- training materials, 839

transfer corona assembly, 178–179, 179, 908  
 transferring step, 183, 183, 908  
 transistors, 909  
 Transmission Control Protocol (TCP), 238  
 Transmission Control Protocol/Internet Protocol.  
     *See* TCP/IP (Transmission Control  
     Protocol/Internet) suite  
 transparencies, 192–193  
 Transport layer in OSI model, 234, 235, 909  
 trays, paper, 172–173, 173, 196  
 trees, 716  
 troubleshooting. *See* diagnostics and  
     troubleshooting  
 Trusted Sites zone, 773  
 TSR (Terminate and Stay Resident) programs,  
     820, 907  
 Turn Off Computer command, 496–497, 496  
 Turn On Internet Connection Firewall For This  
     Connection option, 767  
 tweaker tool, 286  
 twisted-pair cabling, 244–245, 244–245, 909  
 typical installation type, 586, 626, 909

## U

UARTs (Universal Asynchronous Receiver/  
 Transmitter), 909  
 UDCs (universal data connectors), 245, 245, 909  
 UDP (User Datagram Protocol), 238, 910  
 UltraDMA modes, 135, 909  
     in ATA/ATAPI-4, 138  
     in ATA/ATAPI-5, 138  
     in ATA/ATAPI-6, 139  
 UMBs (upper memory blocks), 910  
 undervoltage power problems, 388–389, 389  
 unidirectional satellite connections, 258, 909  
 uninstall process, 909  
 Uninterruptible Power Supplies (UPSs) and  
     suppressors, 387, 909  
     for power overage problems, 387–388  
     for power quality problems, 387  
     for undervoltage power problems,  
         388–389, 389  
 Universal Asynchronous Receiver/Transmitter  
     (UARTs), 909  
 universal data connectors (UDCs),  
     245, 245, 909  
 Universal Serial Bus. *See* USB (Universal  
     Serial Bus)

Unix operating system, 909  
 unshielded twisted pair (UTP) cable, 910  
 updating drivers, 534–536, 535–536, 621  
 upgrade packs, 634  
 upgrade paths, 622–623  
 upgrade reports, 634–636, 635  
 Upgrade to Windows 2000 (Recommended)  
     screen, 632  
 upgrade utilities, 624  
 Upgrade Wizard, 632  
 upgrading  
     operating system. *See* operating systems (OSs)  
     PC components, 366  
         BIOS, 374–375  
         CPU, 367–368, 371–372  
         expansion cards, 375–377, 376  
         external storage, 383  
         hard disk drives, 373–374, 373  
         infrared devices, 386  
         key terms, 392  
         memory, 372  
         modems and transceivers, 379–383, 382  
         monitors, 390–391, 390  
         motherboards, 370–371, 371  
         PDAs, 385  
         portables, 377–379  
         possibility of, 367–369  
         printers, 386–387  
         purpose of, 366–367  
         review question answers, 397–398  
         review questions, 393–396  
         scanners and cameras, 383–384, 384–385  
         summary, 391  
         UPSs and suppressors, 387–389, 389  
         wireless access points, 385–386, 386  
 Upgrading to the Windows 2000 NTFS File-  
     system option, 634  
 upper memory blocks (UMBs), 910  
 UPSs (Uninterruptible Power Supplies) and  
     suppressors, 387, 909  
     for power overage problems, 387–388  
     for power quality problems, 387  
     for undervoltage power problems,  
         388–389, 389  
 USB (Universal Serial Bus), 50–51, 50, 57–58,  
     57–58, 910  
     bus, 91  
     for peripheral connection methods, 659  
     for portables, 354  
     ports, 27, 28  
     for printers, 188

Use The CD I Got From An ISP option, 764–765  
 Use This Account Name And Password When Anyone Connects To The Internet From This Computer option, 767  
 user accounts  
   in Windows 2000, 730–732, 730–732  
   in Windows NT, 721–723, 722–724  
   in Windows XP, 736–737, 736  
 User Cannot Change Password option, 723  
 user data files, restoring, 621–622  
 User Datagram Protocol (UDP), 238, 910  
 USER.EXE file, 910  
 user groups, 723, 910  
 user manuals, 838  
 User Must Change Password At Next Logon option, 722  
 user variables, 529  
 usernames, 713, 910  
 users  
   profiles for, 528, 910  
   Task Manager for, 532  
   in troubleshooting, 813  
 utilities, running from command prompt, 506–507, 506  
 UTP (unshielded twisted pair) cable, 910

---

## V

vacuum tubes, 910  
 vampire taps, 243, 243  
 variable resistors, 910  
 VCACHE program, 910  
 version-specific hardware installation issues, 649  
   Windows 9x, 649–651, 650–652  
   Windows 2000, 655–657, 656  
   Windows NT, 652–655, 652–655  
   Windows XP, 657–658, 657  
 versions, 910  
   MS-DOS, 466–468  
   operating system, 462  
   software, 435  
   Windows  
     Windows 1, 471  
     Windows 2, 471  
     Windows 3.x, 471–472  
     Windows 95, 472–473  
     Windows 98/Me/NT/2000/XP, 473  
 vertical black lines on printer pages, 205  
 vertical scan frequency, 46, 391  
 vertical white lines on printer pages, 205  
 Very Large Scale Integration (VLSI)  
   technology, 911  
 VFAT (virtual FAT) filesystem, 587, 911  
 VGA (Video Graphics Array) video, 43, 910  
 VID (voltage ID) programmable processors, 96, 911  
 video  
   ports for, 27, 28, 910  
   troubleshooting, 328  
 video cards, 39, 40, 42, 321, 911  
   case preparation for, 321–322, 322  
   inserting, 322–323, 322  
   securing, 323  
   specialized, 403  
 Video Graphics Array (VGA) video, 43, 910  
 Video RAM (VRAM), 106, 911  
 video technologies, 42–43  
   comparison, 44–45  
   EGA and CGA, 43  
   monochrome, 43  
   SuperVGA, 44  
   VGA, 43  
   XGA, 44  
 view types, 513  
 virtual device drivers (VxDs), 911  
 virtual FAT (VFAT) filesystem, 587, 911  
 virtual memory, 539–540, 539,  
   788–789, 911  
   in Windows 3.x, 471  
   in Windows 9x, 789–790, 790  
   in Windows 2000, 792–793, 792  
   in Windows NT, 790–792, 791  
   in Windows XP, 793–795, 794–795  
 viruses, 821–822, 911  
 VL bus, 86, 911  
 VLSI (Very Large Scale Integration)  
   technology, 911  
 voltage ID (VID) programmable processors, 96, 911  
 Voltage Regulator Modules (VRMs), 96, 911  
 voltage vs. current, 409  
 voltages  
   CPU, 96  
   measuring, 285, 285  
 volts, 911  
 volumes, 152, 911  
 VRAM (Video RAM), 106, 911  
 VRMs (Voltage Regulator Modules), 96, 911  
 VxDs (virtual device drivers), 911

**W**

- wait states, 912
- WANs (wide area networks), 222, 223, 912
- warm boots, 912
- water blocks, 294, 912
- water cooling, 294, 912
- watts, 13, 912
- weight, paper, 192
- Welcome to the Windows 2000 Setup Wizard screen, 632
- wide area networks (WANs), 222, 223, 912
- WIN.COM file, 558
- WIN.INI file, 558, 912
- windows, GUI, 482, 912
  - elements of, 502–503, 502–503
  - states of, 504–505, 504
- Windows 1 operating system, 471
- Windows 2 operating system, 471
- Windows 3.x operating system, 471–472
- Windows 9x/Me operating systems, 472–473, 912
  - advanced startup options in, 567
  - boot disk for, 593
  - boot sequence, 564–565
  - defragmenting disks in, 796
  - disk caches in, 800–801
  - DUN connections, 757–760, 757–758
  - FILES= and BUFFERS= settings in, 799
  - important files, 557
    - startup files, 557–558
    - system file configuration tools, 558–561, 559–560
  - installing, 593
    - enumeration/detection phase, 596–597, 596
    - file-copy phase, 595–596, 596
    - hardware issues, 649–651, 650–652
    - Internet Explorer settings, 598, 598
    - prefile copy phase, 595
    - starting, 593–595, 595
    - system settings, 597, 598
  - as network client, 703–704
    - network components, 704–706, 704–705
    - primary network logons, 706
  - network printing in, 687–690, 688–690
  - networking in, 702
  - printers in, 660
    - adding, 660–663, 661–663
    - existing, 664–665, 664–665
    - print jobs, 666–667, 667
    - spooling, 666, 666
  - for Registry, 545–546, 561, 562
  - sharing in, 716–718, 717
    - folders, 718–720, 719
    - printers, 720–721, 720–721
  - startup and emergency repair disks, 569–570, 570
  - system file configuration tools
    - MSCONFIG, 559–561, 560
    - SYSEDIT, 559, 559
  - upgrading, 624–625
    - collecting computer information, 626–628, 627
    - copying Windows 98 files to computer, 628
    - preparing for Windows 98 Setup, 625–626
    - restarting computer, 628
    - setting up hardware and finalizing settings, 628
    - starting, 625, 625
    - Windows 98 setup, 628–629
  - virtual memory in, 789–790, 790
- Windows 2000 operating system, 912
  - advanced startup options in, 567–568
  - boot sequence, 565–566
  - defragmenting disks in, 796, 797
  - disk caches in, 801–802, 801
  - DUN connections, 760–762, 761
  - FILES= and BUFFERS= settings in, 799–800
  - important files, 563
    - boot files, 563
    - system file configuration tools, 563–564
  - installing, 610
    - formatting partitions, 612–613
    - graphical phase, 613–615, 613
    - issues, 655–657, 656
    - partitioning drives, 612
    - prerequisites, 610
    - setup file access, 610
    - starting, 610–612
  - as network client, 712–714, 712–714
  - network printing in, 690–691
  - printers in, 674
    - adding, 675–678, 675–678
    - existing, 678–680, 679
    - print jobs, 681, 682
    - security, 681, 681
    - spooling, 680, 680

- restoring Registry in, 546
- sharing in, 729–730
  - folders, 732–734, 732–734
  - options, 740–741, 740
  - printers, 735, 735
  - user accounts, 730–732, 730–732
- startup disks and emergency repair disks, 571–573, 572
- upgrading, 631–636, 631–633, 635
- virtual memory in, 792–793, 792
- Windows configuration, 436
  - INI files for, 436–437
  - Registry for, 437, 437
- Windows Explorer
  - capabilities, 512–513, 512
  - navigating, 513–516, 513–515
- Windows Installer method, 912
- Windows interface. *See* GUIs (graphical user interfaces)
- Windows Internet Name Service (WINS), 746, 913
  - Windows Me operating system. *See* Windows 9x/Me operating systems
- Windows NT operating system, 913
  - advanced startup options in, 568–569
  - boot sequence, 565–566
  - disk caches in, 801–802, 801
  - FILES= and BUFFERS= settings in, 799–800
  - important files, 563
    - boot files, 563
    - system file configuration tools, 563–564
  - network printing in, 690–691
  - printers in, 667
    - adding, 667–670, 668–671
    - existing, 672–673
    - print jobs, 674
    - security, 674, 674
    - spooling, 673, 673
  - restoring Registry in, 546
  - sharing in, 721
    - folders, 724–726, 724–726
    - printers, 727–729, 727–729
    - user accounts, 721–723
  - version-specific hardware installation
    - issues, 652–655, 652–655
  - virtual memory in, 790–792, 791
- Windows NT Workstation
  - defragmenting disks in, 796
  - installing, 599
    - first login, 608–609, 609
    - graphical configuration and file-copy phase, 603–608, 603–608
    - starting, 599–600, 600
    - text-based file-copy phase, 600–603, 601–602
  - as network client, 706, 707
    - logging on, 710–711, 711
    - network components, 708–710, 708–710
  - startup disks and emergency repair disks, 571
  - upgrading to, 629–631, 630
- Windows Product Key, 597, 913
- Windows protection errors, 818–819
- Windows startup disks, 589
  - for formatting, 591
  - for optimization, 591–592
  - for partitioning, 589–591, 590
  - using, 593
- Windows troubleshooting, 433
  - General Protection Faults, 434–435
  - system resources, 433–434, 433–434
  - Windows configuration, 436
    - INI files, 436–437
    - Registry, 437, 437
- Windows XP operating system, 913
  - advanced startup options in, 567–568
  - Automated System Recovery in, 573
  - boot sequence, 565–566
  - defragmenting disks in, 797–798, 798
  - dial-up connections in, 762–767, 762–768
  - disk caches in, 801–802, 801
  - FILES= and BUFFERS= settings in, 799–800
  - firewall protection under, 768–770, 769
  - important files in, 563
    - boot files, 563
    - system file configuration tools, 563–564
  - installing, 615
    - graphical phase, 616–620, 617–620
    - hardware issues, 657–658, 657
    - starting, 615–616, 616
    - text-based phase, 616
  - as network client, 712–714, 712
  - network printing in, 690–691
  - printers in, 682
    - adding, 682–684, 683
    - existing, 684–685, 684
    - print jobs, 686, 687
    - security, 686, 686
    - spooling, 685–686, 685
  - restoring Registry in, 546

- sharing in, 735
  - folders, 737, 737
  - options in, 741, 741
  - printers, 737, 738
  - user accounts, 736–737
- upgrading to, 636–638, 637
- virtual memory in, 793–795, 794–795
- WINIPCFG utility, 752, 913
- WinMSD tool, 835–836, 836
- WINNT.EXE file, 610–611
- WINNT32.EXE file, 610–612
- WINS (Windows Internet Name Service)
  - protocol, 746, 913
- wire strippers, 283, 283
- wireless access points (APs), 259, 360, 385–386, 386, 848
- wireless communication for printers, 189–190
- wireless gateways, 360
- wireless Internet technology, 913
- wireless networks, 259–260
  - cabling, 248
  - portables, 359–360
- wizards, 490, 913
- WMI Control, 538
- words, DMA, 134–135, 913
- workgroups, 527, 627, 913
- working directories, 821, 913

- workspace for building PCs, 279–280, 279
- workstations, 224–225, 913
- World Wide Web (WWW), 746, 839, 914
- write-protect tabs, 128, 914
- write-protecting floppy disks, 128, 914
- writing in laser printer process, 181–182, 182, 914
- WSCRIPT.EXE tool, 832
- WWW (World Wide Web), 746, 839, 914

---

## X

- x86 series CPUs, 914
- XGA (Extended Graphics Array) video, 44, 914
- XMS (Extended Memory System), 870

---

## Z

- zero wait states, 914
- ZIF (Zero Insertion Force) processor sockets, 291, 914
- Zip drives and Jaz drives, 38
- zones in IE, 773