

# Index

## Symbols and Numerics

- \* (asterisk) character, 118, 211
- \ (backslash) character, 139
- ? (question mark) character, 118
- 802.11 standard, 211

## A

### A drive

- copying file to, 97
- description of, 92

### Accelerated Graphics Port (AGP), 211

### accelerator key, 190

### accessing

- floppy disk, 99
- Internet, 19–20
- menus with keyboard, 190
- Public folder, 173
- shared folder, 162
- wireless network, 163

### Accessories submenu (All Programs menu), 65

### account folder, 62–63

### ad hoc network connection, 163, 211

### A/D port, 27

### Add Hardware icon (Windows), 34–35

### Address bar (Windows Explorer)

- description of, 126, 128–129
- pathname, 120

### Address toolbar, 83

### Advanced Search panel, 110

### AGP (Accelerated Graphics Port), 211

### AGP expansion slot, 16, 37

### air mouse, 208

### air vent

- back of console, 6, 7
- front of console, 4, 5

### All Programs menu (Windows), 47, 64–68, 211

### all-in-one printer, 159

### Alt key, 190, 193, 211

### Alt+F4 (close program), 122, 191

### Alt+spacebar, C (Close), 191

### Alt+spacebar (Control menu), 191

### Alt+spacebar, M (Move), 191

### Alt+spacebar, N (Minimize), 191

### Alt+spacebar, R (Restore), 191

### Alt+spacebar, S (Size), 191

### Alt+spacebar, X (Maximize), 191

### animated mouse pointer, using, 207

### Any key, 190–191

### application. *See also* software

- automatically starting, 66
- closing, 65, 122

defined, 211

desktop shortcut to, creating, 66

pinning to Start menu, 67

putting on Quick Launch bar, 67

running, 64

starting, 65, 66

### Application key, 200

### Apply button, 211

### arrow keys, 211

### asterisk (\*) character, 118, 211

### audio, 24–25

### Auto-hide feature, 82

### automatically starting program, 66

### AutoPlay, 87–88

## B

### B drive, 92

### Back button, 129

### back of console, 6–7

### background, 211

### backslash (\) character, 139

### Backspace key, 211

### ball mouse, 208

### BMP file, 105

### bold, 211

### boot, 211

### boot disk, 211

### Break key, 192

### braided, 211

### bug, 211

### burn, 212

### Burn a Disc dialog box, 186

### Burn button, 130, 187

### burning CD, 180–182

### buttons. *See also* specific buttons

on console, 4–5

defined, 212

on mouse, 204

on printer, 154

### buying

memory, 42–43

paper for printer, 151–152

### byte, 88, 212

## C

### C drive, 92, 99

### cable modem, 212

### cables. *See also* connector; ports

description of, 4, 212

networking, 24, 29, 167

power, 29

printer, 142

### camera, digital

connecting, 25

description of, 18

### Cancel button, 212

### cancelling print job, 158–159

### Caps Lock key, 194

### card reader, inserting media into, 100

### case. *See* console

### Cat-5 cable, 24, 167

### Category view (Control Panel), 69, 70

### CD

description of, 183

destroying, 182

ejecting, 95

erasing, 185

formats, 182–183

inserting, 100

installing software from, 45

musical, creating, 180–182

playing, 91

writing to, 185–188

### CD icon, 92

### CD-R, 90–91, 184, 212

### CD-ROM recordable drive, 180

### CD-ROM/DVD drive

description of, 4, 15, 180, 212

location of, 5, 14

storage, 89–90, 101

### CD-RW, 91, 184, 212

### Celeron, 212

### central processing unit (CPU), 12, 212

### Change Drive Letter or Path dialog box, 94

### Change settings for the plan: Balanced

### window, 57

### changing

double-click rate, 203

drive letter, 93–94

folder icon, 136

look of Start menu, 78

Power button function, 50–51

speed of mouse pointer, 206

text, 198

### character, 212

### child folder, 212

### chipset, 14, 15, 212

### Classic view (Control Panel), 34, 69–70

### clear, 212

### clicking with mouse, 202

### Clipboard, 212

### Close command, 191

### closing

defined, 212

document, 121–122

program, 65, 122

### COM port

connecting to, 31

description of, 8, 10

**commands**

- Close, 191
- Control Panel, 69, 71
- Copy to Folder, 113
- Cut, 113
- to edit, change, or modify text, 198
- Lock, 54
- Maximize, 191
- Minimize, 191
- Move, 191
- Paste, 113
- Paste Shortcut, 114
- Print, 155–156
- Print Preview, 154–155
- Restore, 191
- Save As, 109
- Select All, 122
- Shut Down, 51, 54
- Size, 191
- Sleep, 56
- Undo, 118
- Uninstall, 47
- Unpin from Start Menu, 79
- CompactFlash memory reader, 25**
- compressed folder, 131–133, 212**
- Computer icon (Windows), 68, 212**
- Computer window (Windows), 68–69**
- configuring**
  - network, 167
  - Windows Vista for network discovery, 162
- connecting to network, 166–167**
- connector**
  - audio, 24–25
  - on console, 4, 5
  - defined, 212
  - digital camera, 25
  - digital media player, 26
  - IEEE 1394 port, 26–27
  - I/O symbols for, 10–11
  - joystick port, 27
  - keyboard, 27
  - mini-DIN, 24–25
  - mini-IEEE, 26
  - modem, external, 28
  - monitor, 28
  - mouse, 28, 203–204
  - optical audio, 29
  - power, 6, 7, 11, 29
  - printer, 30
  - scanner, 31
  - speaker, 31
  - S-Video, 30
  - USB port, 31–32
  - wireless device, 32
- console**
  - back of, 6–7
  - description of, 2, 3, 212
  - front of, 4–6
  - inside of, 14–17
  - I/O panel, 7–9
  - opening, 17, 35
- Contacts folder, 63, 136**

**Control menu, 191****control panel for printer, 154****Control Panel (Windows)**

- Add Hardware icon, 34–35
- AutoPlay options, 87–88
- Classic view, 34, 69–70
- defined, 213
- Folder Options, 133–136
- Game Controllers, 36
- Keyboard icon, 199–200
- Mouse, 203
- Network and Sharing Center, 166, 167–168, 171, 177
- overview of, 69–71
- Personalization, 71
- Phone and Modem Options, 36
- Power Options, 56
- Printers icon, 176
- Programs and Features, 47
- System icon, 172
- User Accounts, 77

**controlling window with keyboard, 191****Copy to Folder command, 113****copying file**

- to Drive A, 97
- to Live File System disc, 187
- overview of, 112–113

**copying folder, 138****CPU (central processing unit), 12, 212****CRT monitor, 213****crucial.com Web site, 42****Ctrl key**

- description of, 194, 213
- selecting, 122
- waking computer with, 57

**Ctrl+A (Select All), 122****Ctrl+C (Copy), 113****Ctrl+click, 122, 123, 202****Ctrl+Esc (Start menu), 77****Ctrl+P (Print), 155****Ctrl+S (Save), 121****Ctrl+V (Paste), 113****Ctrl+W (Close), 122****Ctrl+X (Cut), 113****cursor, 213****cursor keys, 213****cursor-control key, 193****Customize Notification Icons dialog box, 74, 75****Customize Start Menu dialog box, 78, 79****customizing**

- Details view (Windows Explorer), 107
- mouse pointer, 206–208
- notification area, 73–75
- Start menu, 78–79

**Cut command, 113****D****D drive, 93****daisy-chaining, 26****data, 104, 213****dead keys, 192****decompressing file, 133****default, 213****default printer, choosing, 146–147****Define power buttons and turn on password protection window, 50****delay rate, 213****deleting. *See also* removing**

- defined, 213
- file, 75–76, 114–115
- file from recordable disc, 187
- folder, 138
- shortcut icon, 101
- software manually, 47

**deselecting icon from group, 123****desktop, 213****desktop computer, 13****Desktop folder, 63, 136****desktop interface, 19, 71–72****desktop shortcut, creating**

- to drive, 100–101
- to file, 114
- to program, 66

**destroying disc, 182****Details pane (Windows Explorer), 106, 128****Details view (Windows Explorer), 107****digital camera**

- connecting, 25
- description of, 18

**digital media player**

- connecting, 26
- description of, 18

**digital video port, 10****DIMM (Dual In-line Memory Module)**

- description of, 15, 213
- installing memory, 40, 41

**directory. *See* folder****disabling AutoPlay, 87****disc. *See* CD; DVD****disk drive**

- letters for, 92–94
- mapping folder to, 164–165

**disk drive cage, 14, 15****disk storage, 86–87****display, 213****displaying. *See also* hiding**

- filename extension, 117
- folder in Windows Explorer, 127
- notification area icon, 75
- Quick Launch bar, 83–84
- thumbnail preview window, 80

**DLL file, 105****document, closing, 121–122****Documents folder, 63, 137, 213****door, secret, on console, 4, 5****dot-matrix printer, 159****double-click rate, changing, 203****double-clicking with mouse, 202, 213****downloading and installing software, 45–46****Downloads folder, 63, 137**

**dragging**

- defined, 213
- file, 113–114
- with mouse, 202

**drive. See CD-ROM/DVD drive; disk drive;****flash drive; floppy drive; hard drive****drive icon, 91–92****drive letter**

- changing, 93–94
- overview of, 92–93

**driver, 213****DSL modem, 213****Dual In-line Memory Module (DIMM)**

- description of, 15, 213
- installing memory, 40, 41

**duplicating file, 113****DVD**

- description of, 183, 213
- destroying, 182
- ejecting, 95
- erasing, 185
- formats, 182–183
- inserting, 100
- installing software from, 45
- playing, 91
- writing to, 185–188

**DVD combo or super drive, 180****DVD DL, 183****DVD drive. See CD-ROM/DVD drive****DVD drive icon, 92****DVD recordable, 214****DVD+R, 91, 184****DVD-R, 91, 184****DVD-RAM, 91, 184****DVD+RW, 91, 184****DVD-RW, 91, 184****E****editing text, 198****802.11 standard, 211****eject, 214****eject symbol, 100****ejecting removable disk, 94–95****e-mail, 20****Email button, 130****Enter key, 191, 200, 214****envelope, printing, 147–149****erase, 214****erasing RW disc, 185****error message, 214****Esc key, 190, 200****Ethernet, 214****Ethernet adapter, 162****Ethernet port, 9, 10****EXE file, 45, 105****expansion card**

- adding hardware, 17
- description of, 6, 7, 214
- inserting, 36–39
- location of, 15–16

**expansion slot**

- description of, 6, 7, 214
- location of, 14, 15–16

**Explore button, 131****external dialup modem, adding, 36****external expansion, 17–18****Extract All Files button, 131****extracting file, 133****F****F Lock key, 194****F1 key (Help), 192****F2 key (Rename), 118****F3 key (Search window), 110****F10 key (show hidden menu), 190****fan, 6, 7, 14****favorite folders, 129****Favorites folder, 63, 137****file. See also folder**

- adding to compressed folder, 132
- attributes of, 104–105
- copying, 112–113
- copying to Drive A, 97
- creating, 109
- defined, 214
- deleting, 114–115
- duplicating, 113
- extracting or decompressing, 133
- finding lost, 109–112
- hidden, 134
- icons, 21, 22, 104–105
- making compressed folder from, 132
- managing, 112–116
- moving, 113–114
- naming and renaming, 117–118
- opening, 87, 119
- operating system, 19
- organizing, 22
- overview of, 20–21, 104
- pathnames, 119–120
- Properties dialog box, 107–108
- recovering previous version of, 115–116
- saving, 121–122
- selecting icons, 122–123
- shortcut to, creating, 114
- transferring, 20
- types of, 105
- undeleting, 115
- Windows Explorer, 106–107
- working with, in Windows, 21–22
- writing to disc, 185–188
- Zip, 46, 131

**file sharing, 168****file type, 104, 112****filename**

- description of, 21, 104
- elements of, 117

**filename extension, 104, 117****finding lost file, 109–112****FireWire, 27****fixed disk, 99, 214****flash drive**

- ejecting, 95
- storing files on, 86, 101

**floating palette window, 84****floppy disk**

- care and use of, 98
- copying file to, 97
- description of, 96, 214
- ejecting, 94
- formatting, 96
- inserting, 99

**floppy drive**

- description of, 4, 5, 95–96, 214
- icon for, 91
- letter for, 92
- location of, 14, 15
- storing files on, 101
- uses of, 97

**FN (function) key, 192, 200, 214****folder. See also file**

- compressed (Zip), 131–133
- creating, 138
- description of, 22, 126, 214
- managing, 137–138
- modifying with template, 134–135
- pre-created, 136–137
- root, 138–139, 175
- shared, accessing, 162
- shared, adding to disk system, 164–165
- sharing, 175–176, 177
- subfolder, 139
- terminology for, 133–134
- unsharing, 176
- Windows Explorer, 126–131
- Zip, 131–133

**Folder Options (Control Panel), 133–136****font, 214****footprint, 13****forcing computer off, 51–52****Format dialog box, 96, 97****format of CD or DVD, 182–183****formatting floppy disk, 96****Forward button, 129****FreeCell, 203****front I/O, 14****front of console, 4–6****full pathname, 120****function (FN) key, 192, 200, 214****G****Game Controllers (Control Panel), 36****Games submenu (All Programs menu), 65****General tab (Folder Options dialog box), 134****gigabyte (GB, G), 88, 214****glitch, 214****Gookin, Dan (*Troubleshooting Your PC For Dummies*), 55, 57****graphics, 214**

**H**

**handle of toolbar, 84**  
**hard copy, 214**  
**hard disk, 98, 214**  
**hard drive**  
 description of, 98–99, 214  
 icon for, 92  
 letters for, 92–93  
 location of, 14, 15  
 setting timeout for, 57  
 storing files on, 21, 101

**Hard drive light, 5****hardware**

adding, 17–18, 35–36  
 defined, 214  
 networking, 162  
 operating system, 19  
 overview of, 2–4, 12

**headphone jack, 9, 11****Help key, 192****Help system, 214****Hibernation option, 52****hidden file, 134****hiding. *See also* displaying**

filename extension, 117  
 notification area icon, 75

**history of PC, 11–12****HTM or HTML file, 105****I****IBM, 11–12****icon**

Add Hardware, 34–35  
 adding picture to folder, 135  
 Back button, 129  
 CD, 92  
 changing folder, 136  
 Computer, 68  
 defined, 214  
 deselecting from group, 123  
 drive, 91–92  
 DVD drive, 92  
 file, 21, 22, 104–105  
 floppy drive, 91  
 folder, 126  
 Forward button, 129  
 hard drive, 92  
 lassoing group of, 123  
 Mouse, 203  
 Network, 72  
 Network and Sharing Center, 171  
 network drive, 92  
 networking, 166  
 notification area, 73, 74–75  
 padlock, 54  
 pin-on area of Start menu, 79  
 Printers, 176  
 Quick Launch bar, 84

range of, selecting, 123  
 Refresh button, 129  
 removable drive, 92  
 Safely Remove Hardware, 44  
 selecting, 122–123  
 sharing buddies, 92, 176  
 shortcut, appearance of, 114  
 shortcut, deleting, 101  
 System, 172

**IEEE 1394 port**

connecting to, 26–27  
 description of, 9, 10

**impact printer, 159****Industry Standard Architecture (ISA)**

expansion slot, 16, 37, 38, 215

**infrared mouse, 209****infrared port, 6, 10****initializing recordable or rewritable disc, 185–186****ink cartridge, 215****ink for printer, 150, 151****inkjet printer, 160, 215****input, 3****input and output (I/O), 215****inserting**

expansion card, 36–39  
 removable disk, 99–100

**insertion pointer, 215****installing**

memory, 40–43  
 software, 44–46

**internal expansion, 17****internal modem, 28****Internet, 19–20****Internet Protocol (IP), 215****Internet service provider (ISP), 20****I/O (input and output), 215****I/O panel, 7–9****I/O symbol table, 10–11****IP address, 170–171, 215****IP (Internet Protocol), 215****iPod, 26****ISA (Industry Standard Architecture)**

expansion slot, 16, 37, 38, 215

**ISP (Internet service provider), 20****italic, 215****J****jack, 215****joining workgroup, 177–178****joystick, non-USB, adding, 36****joystick port**

connecting to, 27  
 description of, 9, 10

**K**

**KB, K (Kilobyte), 88, 215**  
**key, 215**

**key word, searching on, 112****keyboard. *See also* keys**

accessing menus with, 190  
 commands to edit, change, or modify text, 198  
 connecting, 27  
 controlling window with, 191  
 description of, 3, 215  
 layout of, 192  
 lock keys, 194  
 names for symbols on, 199  
 numeric keypad, 193  
 shift keys, 193–194  
 special keys, 200  
 types of, 197–198

**keyboard connector, 8, 10****Keyboard icon (Control Panel), 199–200****keyboard shortcut, 190, 195–197, 215****keys**

accelerator, 190  
 Alt, 190, 193  
 Any, 190–191  
 Application, 200  
 arrow, 211  
 Backspace, 211  
 Break, 192  
 Caps Lock, 194  
 Ctrl, 57, 122, 194  
 cursor-control, 193  
 dead, 192  
 definition of, 215  
 Enter, 191, 200  
 Esc, 190, 200  
 F Lock, 194  
 F1 (Help), 192  
 F2 (Rename), 118  
 F3 (Search window), 110  
 F10 (show hidden menu), 190  
 FN, 192, 200  
 Help, 192  
 lock, 194  
 modifier, 194  
 Num Lock, 194  
 Pause, 192  
 Print Screen, 200  
 Scroll Lock, 194  
 Shift key, 194, 218  
 Shift keys, three sets of, 193–194  
 SysRq, 192  
 Tab, 200  
 typewriter, 192  
 Win, 77, 194, 200

**Kilobyte (KB, K), 88, 215****L****labeling**

CD, 182  
 floppy disk, 98

**Landscape mode, 215**

laptop computer, 13, 215  
 laser printer, 160, 215  
 lassoing group of icons, 123  
 LCD monitor, 215  
 left-handed mouse, 205  
 lights
 

- on console, 4–5
- on printer, 154

 Line In jack, 9, 10, 25  
 Line Out jack, 25  
 Links folder, 63, 129, 137  
 Live File System, 182, 187, 215  
 loading set of mouse pointers, 207  
 Lock command, 54  
 lock keys, 194  
 locking taskbar, 80  
 logging on and off, 52–54  
 logical hard drive, 99  
 login, 52–53  
 lost file, finding, 109–112  
 LPT1 port, 30

## M

MAC address, 171, 215  
 magnet and floppy disk, 98  
 mainframe system, 11  
 managing. *See also* organizing
 

- files, 112–116
- folders, 137–138

 Map Network Drive button, 131  
 Map Network Drive dialog box, 164  
 mapping
 

- defined, 215
- folder to disk drive, 164–165
- mouse button to key combination, 204

 Mastered disc format, 182–183, 187–188, 216  
 mathematical symbols, 193  
 Maximize button, 216  
 Maximize command, 191  
 mechanical mouse, 208  
 media card
 

- ejecting, 95
- inserting into card reader, 100
- storing files on, 86, 101

 media player, digital
 

- connecting, 26
- description of, 18

 media sharing, 169  
 megabyte (MB, M), 88, 216  
 memory
 

- buying, 42–43
- defined, 216
- files, 21
- installing, 40–43
- quantity of, 16
- RAM banks, 14, 15
- removing, 43
- selling, 43
- as temporary, 86

memory bank, 40  
 memory card, 25  
 menu, accessing with keyboard, 190, 216  
 Menu bar (Windows Explorer), 128  
 microcomputer, 11  
 microphone jack
 

- connection to, 27
- description of, 9
- symbol for, 10

 microprocessor
 

- description of, 12, 15, 216
- location of, 14
- name and power of, 16

 Minesweeper, 203  
 mini-DIN connector, 24–25  
 mini-IEEE connector, 26  
 Minimize button, 216  
 Minimize command, 191  
 minitower PC, 13, 216  
 models of PCs, 13–14  
 modem
 

- accessing Internet, 20
- connecting, 28
- defined, 216
- external dialup, adding, 36
- types of, 213

 modem jack, 9, 10  
 modifier key, 194  
 modifying text, 198  
 monitor
 

- connecting, 28
- description of, 3, 216

 monitor connector, 10  
 motherboard, 12, 14, 15, 216  
 mount, 216  
 mouse
 

- basic activities of, 202–203
- buttons on, 204
- connecting, 28, 203–204
- description of, 3, 216
- double-click rate, changing, 203
- left-handed, 205
- pointer features, activating, 204–205
- types of, 208–209

 mouse connector, 8, 10  
 mouse pad, 206  
 mouse pointer, 206–208, 216  
 Move command, 191  
 Move to Folder window, 114  
 moving
 

- file, 113–114
- folder, 138
- taskbar, 81
- toolbar, 84

 MP3 file, 105  
 multiple copies, printing, 156  
 Music CD, CD-R sold as, 184  
 Music folder, 63, 137  
 musical CD, creating, 180–182

## N

naming file, 117–118  
 Navigation pane (Windows Explorer), 128, 129  
 network
 

- connecting to, 166–167
- defined, 216
- peer-to-peer, 177

 Network and Sharing Center (Windows)
 

- checking network connection, 166
- options, 167–169
- Show Me All the Shared Network Folders on This Computer, 177
- View Status link, 171

 network connection
 

- ad hoc, 163
- checking, 165–166
- repairing, 174

 Network Connections window, 169  
 network discovery
 

- configuring Windows Vista for, 162
- description of, 168

 network drive icon, 92  
 network drive letter, 93  
 Network icon (Windows), 72  
 network interface card (NIC), 162, 166, 216  
 network name, 172  
 network path, 120  
 network printer
 

- adding, 145
- connecting, 142–143

 Network window, 166, 169–170  
 networking
 

- accessing shared folder, 162
- defined, 216
- IP address, 170–171
- overview of, 162
- Public folder, 173–174
- shared folder, adding to disk system, 164–165
- workgroup, 177–178

 networking cable, 24, 29  
 networking icon, 166  
 NIC (network interface card), 162, 166, 216  
 notebook computer, 13  
 Notepad, 216  
 notification area
 

- customizing, 73–75
- defined, 216
- Safely Remove Hardware icon, 44

 Num Lock key, 194  
 numeric keypad, 193, 216

## O

On switch for printer, 143  
 online, 216  
 Open button, 131

**Open Control Panel button, 131**  
**opening**

- defined, 217
- file, 87, 119
- PC, 17, 35
- Windows Explorer, 126

**operating system, 12, 18–19, 217. See also Windows operating system**

**optical audio, 29**

**optical mouse, 208**

**organizing**

- All Programs menu, 68
- files, 22

**output, 3**

## P

**padlock icon, 54**

**Page Setup dialog box, 147–148**

**paper for printer, 151–153**

**parent folder, 139, 217**

**partial pathname, 120**

**password-protected sharing, 168–169**

**Paste command, 113**

**Paste Shortcut command, 114**

**pathname, 119–120, 128, 217**

**Pause key, 192**

**PC (personal computer), 217**

**PCI expansion slot, 16, 37, 38**

**PCI (Peripheral Component Interconnect), 217**

**PCI-Express expansion slot, 16, 217**

**PCI-X expansion slot, 16, 217**

**PDF file, 105**

**peer-to-peer network, 177, 217**

**Pentium, 217**

**peripherals, 2, 4. See also printer**

**Personalization (Control Panel), 71**

**Phone and Modem Options (Control Panel), 36**

**phone jack, 9**

**picture, adding to folder icon, 135**

**Pictures folder, 63, 137**

**pinning program to Start menu, 67**

**pin-on area of Start menu, 77, 79**

**placement of printer, 142**

**playing CD or DVD, 91**

**playlist, 181**

**pointer**

- insertion, 215
- mouse, 206–208

**Pointer Trails option (mouse), 205**

**printing with mouse, 202**

**Portrait mode, 217**

**ports**

- A/D, 27
- COM, 8, 10, 31
- digital video, 10
- Ethernet, 9, 10
- IEEE 1394, 9, 10, 26–27
- infrared, 6, 10

joystick, 9, 10, 27

LPT1, 30

overview of, 8–9

printer, 9, 11

RJ-45, 9, 10, 29, 167

serial, 8, 10, 31

SPDIF in/out, 9, 11

S-Video out, 9, 11

USB, 8, 11, 18, 31–32

**Power button**

- changing function of, 50–51
- description of, 4, 5, 217

**power cable, 29**

**Power connector, 6, 7, 11**

**Power light, 5**

**Power Options (Control Panel), 56**

**power strip, 58, 217**

**power supply, 14, 15**

**powered hub, 32**

**Preview pane (Windows Explorer), 106, 128**

**Previous Versions feature, 115–116**

**Print button, 131**

**Print command, 155–156**

**Print dialog box, 155, 156**

**Print Preview command, 154–155**

**Print Screen key, 200**

**printer. See also printing**

- adding, 142–143, 146
- choosing, 156
- connecting, 30
- control panel for, 154
- default, setting, 146–147
- description of, 3, 217
- forcing Windows to recognize, 144–145
- ink and toner for, 150–151
- network, adding, 145–146
- paper for, 151–153
- placement of, 142
- setting up, 143–144
- sharing, 168, 176
- stopping, 158–159
- turning on and off, 159
- types of, 159–160
- uninstalling, 160
- unsharing, 177

**printer port, 9, 11**

**printing. See also printer**

- envelopes, 147–149
- multiple copies, 156
- screen, 157
- single page or range of pages, 156–157
- test page, 157–158

**program. See also software**

- automatically starting, 66
- closing, 65, 122
- desktop shortcut to, creating, 66
- pinning to Start menu, 67
- putting on Quick Launch bar, 67
- running, 64
- starting, 65, 66

**Programs and Features (Control Panel), 47**

**Properties dialog box**

- files, 107–108
- Previous Versions tab, 116

**Public folder, 168, 173–174, 217**

## Q

**question mark (?) character, 118**

**Quick Launch bar**

- displaying, 83–84
- putting program on, 67

**quitting Windows, 54–55, 58–59**

## R

**radio frequency mouse, 209**

**RAM**

- banks, 14, 15
- defined, 217
- files, 21
- quantity of, 16

**range of icons, selecting, 123**

**range of pages, printing, 156–157**

**reactivating Windows, 36, 39**

**read-only, 183**

**Read-Only Memory (ROM), 217**

**rear I/O, 14**

**Recent Pages triangle (Windows Explorer), 129**

**recordable CD or DVD**

- deleting file from, 187
- initializing, 185–186
- types of, 90–91, 183

**recordable drive, 180**

**recording sound, 25**

**recovering**

- file from Recycle Bin, 115
- previous version of file, 115–116

**Recycle Bin**

- description of, 75–76
- recovering file from, 115

**reformatting floppy disk, 96**

**Refresh button, 129**

**removable disk**

- ejecting, 94–95
- inserting, 99–100

**removable drive icon, 92**

**removable drive letter, 93**

**removing. See also deleting**

- floppy disk, 98
- folder from list of favorite folders, 129
- icon from pin-on area of Start menu, 79
- icon from Quick Launch bar, 84
- memory, 43
- toolbar from taskbar, 84
- USB drive, 102
- USB storage device, 44

**renaming**

- file, 117–118
- folder, 138

**repairing network connection, 174**  
**repeat delay, 199**  
**repeat rate, 199, 217**  
**replacing mouse pointer, 207**  
**Reset button, 5, 55**  
**resizing taskbar, 81–82**  
**resolution, 71**  
**resource, 217**  
**restarting**  
     after installation, 35  
     Windows, 55  
**Restore button, 217**  
**Restore command, 191**  
**Restore Default button, 135**  
**restoring file to folder, 115**  
**rewritable CD or DVD**  
     description of, 183  
     erasing, 185  
     initializing, 185–187  
     writing to, 187–188  
**right-clicking with mouse, 202**  
**rip, 217**  
**RJ-45 port**  
     connecting to, 29, 167  
     description of, 9, 10  
**ROM (Read-Only Memory), 217**  
**root folder, 138–139, 175**  
**running program, 64, 66**

## S

**Safely Remove Hardware icon, 44**  
**Save As command, 109**  
**Saved Games folder, 63, 137**  
**saving**  
     collection as scheme, 208  
     defined, 217  
     file, 121–122  
     file to disc, 187  
     information, 87  
**scanner**  
     connecting, 31  
     description of, 18  
**screen**  
     defined, 218  
     printing, 157  
**screen saver, 57, 218**  
**Scroll Lock key, 194**  
**Search window, 110–111**  
**Searches folder, 63, 137**  
**searching for file**  
     by file type, 112  
     by name, 111  
     recently created, 112  
     with Search window, 110–111  
     from Start menu, 109–110  
     by word, 112  
**Select All command, 122**  
**select switch for printer, 143**

**selecting**  
     icon, 122–123  
     with mouse, 203  
**serial port**  
     connecting to, 31  
     description of, 8, 10  
**Service Set Identifier (SSID), 218**  
**Share button, 131**  
**shared folder**  
     accessing, 162  
     adding to disk system, 164–165  
**sharing**  
     defined, 218  
     folder, 175–176, 177  
     printer, 176  
     Public folder, 173–174  
     types of, 168–169  
**sharing buddies icon, 92, 176**  
**Shift key, 194, 218**  
**shift key, three sets of, 193–194**  
**Shift+Delete (permanent deletion), 115**  
**shortcut, creating**  
     to drive, 100–101  
     to file, 114  
     to program, 66  
**shortcut, keyboard, 190, 195–197**  
**Show Location option (mouse), 205**  
**Show Me All the Shared Network Folders on This Computer option, 177**  
**Show More chevron, 131**  
**showing. *See* displaying**  
**Shut Down command (Start menu), 51, 54**  
**shutting down Windows, 54–55**  
**single page, printing, 156–157**  
**Size command, 191**  
**Sleep button, 5**  
**Sleep mode, 55–57**  
**slot design of CD/DVD drive, 100**  
**software**  
     description of, 12–13, 218  
     installing, 44–46  
     networking, 162  
     for new hardware, 35  
     operating system, 19  
     for printer, 143  
     uninstalling, 46–47  
**Solitaire, 203**  
**SPDIF in/out port, 9, 11**  
**speaker jack, 9, 11**  
**speakers**  
     connecting, 31  
     description of, 3  
**speed of mouse pointer, changing, 206**  
**spooling, 159**  
**SSID (Service Set Identifier), 218**  
**Stand By mode, 55–57**  
**Start button, 77, 218**  
**Start menu**  
     All Programs option, 64  
     changing look of, 78  
     Control Panel command, 69, 71  
     customizing, 78–79  
     defined, 218  
     Lock command, 54  
     overview of, 76–78  
     pinning program to, 67  
     Power button function, changing, 151  
     searching for file from, 109–110  
     Shut Down command, 51, 54  
     Sleep command, 56  
     Switch User option, 53, 57–58  
**starting program, 65, 66**  
**Startup submenu (All Programs menu), 66**  
**static electricity, 38, 41**  
**stopping printer, 158–159**  
**storage**  
     bytes, 88–89  
     CD-ROM/DVD drive, 89–90  
     disk drives, 86  
     drive letters, 92–94  
     external, 18  
     permanent, 21  
**storage media**  
     AutoPlay, 87–88  
     drive icons, 91–92  
     types of, 101–102  
**subdirectory, 218**  
**subfolder, 139, 218**  
**submenu, 218**  
**surge suppressor, 218**  
**S-Video connector, 30**  
**S-Video out port, 9, 11**  
**Switch User option (Start menu), 53, 57–58**  
**SYS file, 105**  
**SysRq key, 192**  
**System Properties button, 131**  
**System Properties dialog box, 172**  
**System Tools submenu (All Programs menu), 66**  
**system tray, 73–75, 216, 218**  
**system unit, 3**

## T

**Tab key, 200**  
**taskbar**  
     description of, 79–80, 218  
     locking and unlocking, 80  
     moving, 81  
     options, setting, 82  
     resizing, 81–82  
     toolbars, 83–84  
**Taskbar and Start Menu Properties dialog box**  
     Customize button, 71, 75  
     Notification Area tab, 74  
     Start Menu tab, 78  
     Taskbar tab, 82

template, modifying folder with, 134–135  
 terabyte (TB, T), 88, 218  
 test page, printing, 157–158  
 text  
   commands to edit, change, or modify, 198  
   defined, 218  
 TEXT file, 105  
 theme, 207  
 thumbnail preview window, 80  
 toner cartridge, 218  
 toner for printer, 150–151  
 toolbar  
   defined, 218  
   taskbar, 83–84  
   Windows Explorer, 130–131  
 tower PC, 14, 218  
 trackball, 208  
 transferring file, 20  
 tray design of CD/DVD drive, 100  
 tree structure of Windows Explorer, 130  
*Troubleshooting Your PC For Dummies*  
 (Gookin), 55, 57  
 turning off  
   computer, 51–52, 58–59  
   power strip, 58  
   printer, 159  
 turning on  
   computer, 59  
   printer, 159  
 TXT file, 105  
 types  
   of files, 105  
   of keyboards, 197–198  
   of mice, 208–209  
   of modems, 213  
   of PCs, 13–14  
   of printers, 159–160  
   of recordable CDs or DVDs, 90–91, 183  
   of sharing, 168–169  
   of storage media, 101–102  
 typewriter keys, 192

**U**

UAC (User Account Control), 219  
 undelete, 218  
 undeleting file, 115  
 underline, 218  
 undo, 218  
 Undo command, restoring original name  
 with, 118  
 Uninstall command, 47  
 Uninstall or Change a Program button, 131  
 uninstalling  
   printer, 160  
   software, 46–47  
 uninterruptible power supply (UPS),  
 59–60, 219  
 unlocking taskbar, 80

unmapping folder, 165  
 unmount, 219  
 Unpin from Start Menu command, 79  
 unplugging computer, 59  
 unsharing  
   folder, 176  
   printer, 177  
   Public folder, 174  
 UPS (uninterruptible power supply),  
 59–60, 219  
 USB cable, 142  
 USB drive, removing, 102  
 USB port  
   description of, 8, 31–32  
   expansion, 18  
   symbol for, 11  
 USB printer, setting up, 143–144  
 USB storage device, removing, 44  
 User Account Control dialog box, 219  
 User Account Control (UAC), 219  
 User Accounts (Control Panel), 77  
 user ID, 77  
 User Profile folder, 62–63, 219  
 user, switching, 53, 57–58  
 utility, 219

**V**

VGA jack, 28  
 video connector, 6, 7, 8  
 video transfer, 26  
 videocamera, 18  
 Videos folder, 63, 137  
 View tab (Folder Options dialog box), 134  
 viewing file details, 106  
 voltage switch, 6, 7

**W**

waking computer, 57  
 wallpaper, 71, 219  
 warm boot, 55  
 webcam, 18  
 wheel button on mouse, 204  
 wildcard character, 118  
 Win key, 77, 194, 200  
 window  
   controlling with keyboard, 191  
   defined, 219  
 Windows Explorer  
   Address bar, 120, 126, 128–129  
   Control Panel, 69  
   Details pane, 128  
   files, 106–107  
   folders, 126–131  
   Menu bar, 128  
   Navigation pane, 128, 129  
   Preview pane, 128

Public folder, 173  
 toolbar, 130–131  
 tree structure, 130

**Windows key, 77, 194, 200**

**Windows Media Player, 180–182**

**Windows operating system. *See also***

**Control Panel (Windows); Start menu;**

**Windows Explorer**

account folder, 62–63  
 Add Hardware icon, 34–35  
 All Programs menu, 47, 64–68  
 Computer icon, 68–69  
 described, 219  
 desktop interface, 19, 71–72  
 Folder Options, 133–136  
 forcing to recognize printer, 144–145  
 Game Controllers, 36  
 Keyboard, 199–200  
 Network and Sharing Center, 166, 167–169,  
 171, 177  
 Network icon, 72  
 notification area, 44, 73–75  
 overview of, 12, 18–19  
 Phone and Modem Options, 36  
 Power Options, 56  
 Previous Versions feature, 115–116  
 Programs and Features, 47  
 quitting, 54–55, 58–59  
 reactivating, 36, 39  
 Recycle Bin, 75–76, 115  
 restarting, 35, 55  
 Save As command, 109  
 taskbar, 79–82  
 toolbars, 83–84  
 Uninstall command, 47  
 working with files in, 21–22  
 writing to disc in, 185–188

**Win+E (Windows Explorer), 126**

**Win+L (Lock), 54**

**wireless device, 32**

**wireless mouse, 209**

**wireless network**

accessing, 163  
 defined, 219

**WMV file, 105**

**workgroup, 177–178**

**working with file, in Windows, 22**

**World Wide Web, 20**

**writing to disc, 185–188**

**Z**

**Zip drive, storing files on, 101**

**Zip file**

description of, 131, 219  
 installing software from, 46

**Zip folder, 131–133**

**zoom, 219**