

# Index

1-800-BATTERY, 135  
3M Laptop Privacy Filter, 255  
802.11a standard, 180  
802.11b standard, 180  
802.11g standard, 179–180  
802.11n standard, 179–180  
1394 port, 65

## • A •

abacus, 8  
abrasive powder, avoiding, 307  
Absolute.com, 271  
AC adapter, 15, 253, 258, 321  
AC power, 257  
accessories  
    cooling pad, 318–319  
    external mouse, 320  
    ID card, 320  
    keyboard, 319  
    laptop bags, 317  
    minivac, 319  
    return service sticker, 320  
    spare batteries, 317–318  
    theft-prevention system, 320  
    travel case, 317  
    USB lamp, 319  
    Webcam, 318  
account image, changing, 112–113  
account password, 268  
Accounts dialog box, 270  
Acrobat Reader, 146  
Acrobat Writer, 146  
Action Center window, 211–212  
activation, 46  
Add a Printer button, 143  
Adjust Commonly Used Mobility Settings link, 88  
administrator account, 45  
Adobe Acrobat, 146  
airline computing. *See also* travel  
    low battery warnings, 257  
    power adapters, 258  
    storing laptop on plane, 255  
    switching off wireless network adapter, 256  
    tray table for, 257  
    wall sockets, 257  
Airplane mode, 256  
airport inspections, 254–255  
alkaline battery, 126  
All Programs menu, 79  
alphanumeric keys, 69–70

AMD Mobile Platform, 29  
America Online, 190  
ammonia-based cleaner, 308  
antivirus software  
    checking for, 213–214  
    disabling, 214–215  
    overview, 213  
    paid subscriptions, 214  
    scanning for viruses, 214  
    updating, 214  
    using two programs, 214  
area code, dialing, 206–207  
asset tag, 265  
audio out jack, 65  
audio port, 288  
Automatically Connection option, 181  
AutoPlay dialog box, 116–117  
auto-responder, 236  
Avast! Antivirus, 214  
AVG Anti-Virus, 213–214

## • B •

Back Up Files button (Windows Vista), 225  
background, 49, 224–226  
backpack, 252  
backup  
    finding program for, 224  
    manual, 226  
    overview, 222  
    PowerPoint presentations, 287  
    preparing for, 223  
    restoring, 226–227  
    scheduling, 223, 225  
    USB drives for, 223  
    Windows Backup, 223  
        before you go, 252–253  
Backup and Restore window, 224–225  
Backup Status and Configuration window  
    (Windows Vista), 224  
BASIC programming language, 11  
BAT files, 215  
Batteries.com, 135  
battery. *See also* battery life; power  
    management  
        alkaline, 126  
        buying, 135  
        charging, 38–39, 134  
        dead, 131  
        defined, 126  
        drained, 315–316

- battery (*continued*)
  - extreme temperatures, avoiding, 315
  - fuel cell, 20, 128
  - history, 126
  - hot, dangers of, 262
  - icon, 129
  - labeling, 135
  - lead acid, 126
  - light, 130
  - lithium-ion, 127, 313
  - locating, 128
  - low-battery warnings, 131–133, 316
  - memory effect, 127
  - monitoring, 129–130
  - nickel-cadmium, 126–127
  - nickel-metal hydride, 127
  - overview, 126
  - proper disposal of, 127, 131
  - removing when using AC power, 130
  - secondary, 127
  - shorting to drain, avoiding, 315
  - smart, 131, 316
  - spare, 127, 130, 134–135, 317–318, 322
  - storing, 130, 315
  - terminals, 314–315
  - troubleshooting, 302
  - types of, 126–127
  - unapproved, 127
- battery life. *See also* power management
  - audible warning, 131
  - buying a laptop and, 25
  - cooling pad and, 136
  - devices that consume power, 135–136
  - disabling unused devices and, 316
  - fuel cells and, 20
  - gadgets, 130
  - hard drives and, 312
  - Hibernation mode and, 316
  - LCD display and, 316
  - low-battery warnings, 316
  - manufacturer's claims, 25
  - monitoring, 129–130
  - of netbooks, 25
  - overview, 17, 125
  - RAM and, 314
  - screen resolution and, 115
  - timeouts and, 316
  - turning down monitor's brightness, 312
  - virtual memory disk swapping and, 313–314
- Battery Status area, 130
- Bell, Alexander Graham, 194
- biometric device, 49
- Biometric Devices category, 89
- BIOS Setup program, 46
- Bluetooth. *See also* wireless networking
  - battery life and, 136
  - disabling, 136
  - light, 68
  - overview, 180
- boot, 45
- brand name, 24–25
- broadband Internet
  - disconnecting from, 193
  - in hotels, 260
  - modems, 200
  - network location, 193
  - overview, 191
  - routers, 191–192
  - setup for, 192
- Browse dialog box, 113
- Browse for More Picture link, 113
- browsing
  - checking suspect Web pages in, 220
  - history, deleting, 221
  - InPrivate Browsing window, 219
  - InPrivate Filtering, 220
  - passwords, 269–270
  - saving web pages in, 232
  - working offline, 232
- buying laptop
  - battery life and, 25
  - brand name and, 24
  - credit card, 29
  - expansion options, 24
  - hard drive storage and, 27
  - hardware and, 27–28
  - LCD display and, 25
  - low/high prices and, 24
  - marketing campaigns and, 24
  - materials used and, 29
  - memory and, 27
  - modems and, 28
  - networking and, 27–28
  - optical drive and, 27–28
  - power usage and, 28–29
  - prices and, 29
  - processor and, 27
  - random access memory and, 27
  - reasons for, 21–22
  - service contract and, 29–30
  - size and, 24
  - technical support and, 29–30
  - technical terms, 29
  - things to ignore in, 24
  - warranty and, 29–30
  - weight and, 24
  - wireless Ethernet adapter and, 28
  - wireless networking and, 27

## • C •

C: drive, 223  
 cables, 323–324  
 café computing. *See also* travel  
   choosing a place to sit, 259  
   finding wall sockets, 259  
   overview, 258–260  
   preventing theft of laptop, 260  
   tips, 260  
 call waiting, disabling, 206  
 calling card information, 208  
 canceling slide show, keyboard shortcut for, 287  
 Cap Lock state, 68  
 Caps Lock key, 70  
 car adapter, 140  
 carrier code, 202  
 case, laptop  
   backpacks as, 252  
   as carry-on luggage, 254  
   cleaning, 307  
   features to look for, 250–251  
   need for, 249  
   recommended brands, 251–252  
   things to pack, 253, 321–324  
 Category view, 87–88  
 CD  
   playing, 276  
   ripping, 277–278  
 cellphones, 253  
 cellular modems, 200  
 Centrino, 29  
 Change Advanced Power Settings link, 132  
 Change My Picture (Windows XP), 112  
 Change What the Power Buttons Do option, 59  
 charging battery  
   before you go, 252  
   overcharging, 312  
   tips, 134  
   troubleshooting, 301  
 Choose What Closing the Lid Does option, 58  
 cigarette lighter, 257  
 city code, 202  
 clamshell design, 13  
 Clarke, Arthur C., 8  
 cleaner, 322  
 cleaning  
   case, 307  
   keyboard, 308  
   LCD screen, 307  
   lint-free cloth for, 308  
 cleaning your laptop, 307  
 cold boot, 45  
 COM files, 215  
 Compact Flash, 64  
 Compaq 1 portable computer, 10–11  
 Compaq III portable computer, 12–13

Compaq SLT, 13–14  
 compatibility, hardware, 17  
 computer games, 26  
 Computer window, 81–82  
 Connect to a Projector command, 288, 294  
 Control Panel window  
   Appearance and Personalization, 89  
   Biometric Devices category, 89  
   Category view, 87–88  
   Devices and Printers window, 90–91  
   Icon view, 87  
   Network and Sharing Center window, 90  
   opening, 87  
   overview, 79  
   Personalization window, 89  
   Phone and Modem window, 90  
   Power Options window, 90  
   Tablet PC settings, 89, 99  
   User Accounts window, 91  
   Windows Mobility Center, 88–89  
 convertible Tablet PCs, 95–96  
 cooling fan, 262  
 cooling pad  
   connecting to USB port, 158  
   as laptop accessory, 318–319  
   laptop temperature and, 262  
   power-saving with, 136  
   as USB hub, 319  
 Create a Password for Your Account, 268  
 Create a Power Plan window, 137  
 Create Password button, 268  
 credit card, 29  
 Critical battery action, 133  
 Critical battery level, 133  
 cursor-control keys, 69–70  
 cybercafés, 235  
 cycle power, 45

## • D •

data backup  
   finding program for, 224  
   manual, 226  
   overview, 222  
   PowerPoint presentations, 287  
   preparing for, 223  
   restoring, 226–227  
   scheduling, 223, 225  
   USB drives for, 223  
   Windows Backup, 223  
   before you go, 252, 253  
 DC power, 257  
 dead battery, 131  
 default printer, 144  
 Delete Browsing History command, 221  
 Dell 320LT power brick, 15

- desktop (Windows)
    - background, 114
    - gadgets, 49
    - icons, 49
    - notification area, 49
    - overview, 78
    - screen saver, 114
    - showing, 49
    - Start button, 49
    - taskbar, 49
    - wallpaper, 49
  - desktop computer
    - vs. laptop, 21
    - laptop as, 160–162
  - desktop-laptop connection
    - cable connection, 240
    - Ethernet, 241
    - overview, 239
    - sneakernet, 239–240
    - synchronizing files, 241–245
    - device driver, 54
  - Devices and Printers window, 90–91, 140–141
  - devices, USB
    - cooling pad, 158, 318–319
    - digital camera, 157
    - external hard drives, 157
    - game controllers, 158
    - headphones, 157
    - keyboard, 319
    - lamp, 319
    - laptop cooler, 158
    - laptop lamp, 158
    - legacy adapters, 158
    - minivac, 319
    - mobile phone recharger, 158
    - mouse, 319
    - network adapters, 157
    - numeric keypad, 158
    - printers, 157
    - scanners, 158
    - security device, 158
    - sound hardware, 158
    - speakers, 158
    - video camera, 158
    - Webcam, 158, 318
  - Dialing Rules tab, 202, 205
  - dial-up Internet access
    - creating connection, 194
    - disconnecting connection, 196
    - e-mail tips, 236–237
    - in hotels, 260
    - making connection, 195–196
    - managing connection, 196–197
    - modems, 200–201
    - services, 190
    - toll-free phone number, 190
  - digital camera
    - computer cable, 253
    - connecting to USB port, 157
    - packing for travel, 253
  - digital video port, 65, 288
  - digitizer, 98
  - dining out, theft prevention and, 265–266
  - Disable Call Waiting Dial check box, 206
  - Disconnect button, 187
  - disconnecting
    - from broadband access, 193
    - dial-up connection, 196
    - from wireless network, 186–187
  - display
    - background, 114
    - battery life and, 316
    - buying a laptop and, 25
    - cleaning, 308
    - configuring, 113–115
    - cover, 255
    - external, connecting, 65
    - resolution, lowering, 316
    - resolution, setting, 113–114
    - screen saver, 114
    - turning down brightness, 312
  - DOS operating system, 14
  - downstream end, 155
  - drained battery, 315–316
  - dreaded memory effect, 127
  - Drive C, 223
  - driver, 54, 298, 306
  - dual-monitor setup, 288
  - DVD movie, playing, 279
  - Dynabook, 8–9, 94
- E ●**
- Earthlink, 190
  - Ebags.com, 252
  - e-book, 282–283
  - e-book reader, 20, 282–283
  - EddieBauer.com, 252
  - Edit Location dialog box, 208
  - Eject button, 11
  - e-mail
    - accessing from friend's computer, 235
    - accessing on the road, 233–234
    - attachments, 215–216
    - auto-responder, 236
    - disabling automatic checking, 237–238
    - disconnecting after picking up, 237
    - forwarding messages, 235–236
    - passwords, 270

- sending messages in one batch, 238
- Web-based, 190, 234
- EmPower DC power, 257
- engraving tool, 264
- Enter Initialization Commands, 204
- entertainment
  - phone calls, 280–281
  - playing music CDs, 276
  - playing music with Media Player, 276–278
  - reading e-books, 282–283
  - ripping music with Media Player, 278
  - using Webcam, 280
  - video chats, 281–282
  - viewing video files, 279
  - watching DVD movies, 279
- escalator, theft prevention and, 266
- Ethernet, 164, 241
- Ethernet cable, 164, 253, 261, 323
- Ethernet hubs, 164
- Ethernet port, 28, 66
- evolution of portable computer
  - abacus, 8
  - Compaq 1, 10–11
  - Compaq III, 12–13
  - Compaq SLT, 13–14
  - NEC UltraLite, 15–16
  - netbook, 18–19
  - Osborne 1, 9
  - Radio Shack Model 100, 11–12
  - Tablet PC, 17–18
  - Xerox Dynabook, 8–9
- EXE files, 122, 215
- executable files, 120, 122
- expansion options, 24
- external hard drive. *See also* hard drive storage
  - adding, 116
  - for backups, 223
  - connecting to USB port, 157
  - packing for travel, 253
  - removing, 116, 119
- external monitor, 161
- external mouse, 76, 320, 322

## ● **F** ●

- Facebook, 215
- fax, 140
  - as image file, 149
  - receiving, 149
  - sending, 147–148
- Fax and Scan window, 149
- fax printer, 147
- FedEx Kinko's, 146
- file backup
  - finding program for, 224
  - manual, 226

- overview, 222
- PowerPoint presentations, 287
- preparing for, 223
- restoring, 226–227
- scheduling, 223, 225
- USB drives for, 223
- Windows Backup, 223
  - before you go, 252–253
- File Download Security Warning dialog box, 121
- file synchronization
  - accessing synced files, 244
  - ending sync partnership, 245
  - opening files for, 242
  - reviewing sync partnership, 243
  - setting up sync partnership, 242–243
  - synchronizing files, 243–244
  - syncing new files, 244–245
  - using, 242
    - before you go, 252
- files, 82
- Find a Program Online button, 213
- Find and Fix Problems, 296
- fingerprint login, 48–49
- fingerprint reader, 48–49, 96, 272
- firewall
  - hardware, 216
  - Internet threats and, 216
  - overview, 216
  - warning, 218
  - Windows 7 Firewall, 217
- FireWire port, 65
- folders
  - closing, 175
  - defined, 82
  - finding shared folders, 174–175
  - My Documents, 83
  - My Music, 83
  - My Pictures, 83
  - My Videos, 83
  - password-protected, 175
  - Program Files, 85
  - read-only, 175
  - sharing from laptop, 175–176
  - sharing with HomeGroup, 173–174
  - subfolders, 84
  - unsharing, 173, 176
  - User Profile, 82–84
- Franklin, Benjamin, 126
- fuel cell, 20, 128
- function keys, 69, 72

## ● **G** ●

- gadgets, 49
- game controller, connecting to USB port, 158

gateway, 165  
 Get a Picture from Camera or Scanner, 112  
 Get Picture button, 112  
 gigabyte (GB), 29  
 gigahertz (GHz), 29  
 Gmail, 234  
 Go to My PC, 290  
 going back to first slide (PowerPoint), keyboard shortcut for, 287  
 going to specific slide number (PowerPoint), keyboard shortcut for, 287  
 Google Books, 282–283  
 Google Talk, 282  
 graphics editing program, 26  
 GRiDPad, 94  
 Guest account, disabling, 270–271  
 GZ file, 120, 122

## • H •

handyman kit, 323  
 Hang Up After Sending and Receiving option, 237  
 hard drive storage  
   battery life and, 312  
   buying a laptop and, 26–28  
   external, 116, 119, 157, 223, 253  
   Hibernation mode and, 57  
   uninstalling software and, 123  
   upgrading, 304  
   viewing, 81–82  
   virtual memory swapping, 313–314  
   Windows operating system and, 81–83  
 hardware  
   buying laptop and, 27–28  
   hard drive storage, 27  
   memory, 27  
   modems, 27  
   optical drive, 27  
   processor, 27  
   upgrading, 303–304  
   wired networking, 164–165  
   wireless networking, 178–179  
 Hardware and Sound category  
   Biometric Devices category, 89  
   Pen and Touch dialog box, 99  
   Power Options window, 58–59, 90  
   Tablet PC settings, 89  
 hardware compatibility, 17  
 hardware firewall, 216  
 headphone port, 65  
 headphones  
   connecting to USB port, 157  
   listening to music with, 278  
   packing, 253, 323  
 Help menu, 79

Hibernation mode, 56–57, 316  
 hiding pointer/navigation box, keyboard shortcut for, 287  
 high price, 24–25  
 history  
   abacus, 8  
   Compaq I, 10–11  
   Compaq III, 12–13  
   Compaq SLT, 13–14  
   NEC UltraLite, 15–16  
   netbook, 18–19  
   Osborne I, 9  
   Radio Shack Model 100, 11–12  
   Tablet PC, 17–18  
   Xerox Dynabook, 8–9  
 home folder, 82–83  
 Home Network option, 165, 193  
 HomeGroup  
   accessing, 87  
   choosing, 170  
   creating, 170  
   joining, 171–172  
   overview, 170  
   sharing folder with, 173–174  
   using, 172–173  
 hot swapping, 156  
 hotel room computing. *See also* travel  
   broadband Internet, 261  
   dial-up connection, 260  
   power sockets, 261  
   theft prevention in, 261, 265–266  
   wireless security, 261  
 Hotmail, 234  
 HTM files, 215  
 HTML files, 215  
 hubs, 156–157, 319  
 Hulu, 279  
 human engineering, 213

## • I •

Icon view, 87  
 icons, 49  
 ID card, 320  
 IEEE port, 65, 67  
 InkBall program, 107  
 InPrivate Browsing window, 219  
 InPrivate Filtering feature, 220  
 Input Panel (Tablet PC), 99, 102–103  
 installing software  
   from Internet, 120–121  
   from optical disc, 120  
   for printer, 142  
   quitting other running programs, 122  
   restarting Windows and, 122  
 internal expansion, 24–25

**Internet**

- broadband access, 191–193
- connecting to, 190
- dial-up access, 190, 194–197
- free access to, 190
- installing software from, 120–121
- overview, 189
- passwords, 269–270
- saving Web pages in, 232
- Web browsing, 219–221, 232, 269–270
- wireless networking, 190

**Internet access, broadband**

- disconnecting from, 193
- in hotels, 260
- modems, 200
- network location, 193
- overview, 191
- routers, 191–192
- setup for, 192

**Internet access, dial-up**

- creating connection, 194
- disconnecting connection, 196
- e-mail tips, 236–237
- in hotels, 260
- making connection, 195–196
- managing connection, 196–197
- modems, 200–201
- services, 190
- toll-free phone number, 190

**Internet Explorer**

- InPrivate Browsing window, 219
- InPrivate Filtering feature, 220
- SmartScreen Filter, 220

**Internet Options dialog box, 209****Internet Properties dialog box, 197****Internet service providers (ISPs), 190, 194–195*****Into the Comet* (Clarke), 8****Invite button (Meeting Space), 293****iPhone, 74****iPod, 278****isopropyl alcohol, 307****iTunes, 278**● **K** ●**Kaspersky antivirus protection, 214****Kensington Security Slot, 64****keyboard**

- alphanumeric keys, 69–70
- cleaning, 308
- cursor-control keys, 69–70
- external, 161, 319
- full-size, 161, 319
- function keys, 69, 72
- general layout, 69

**numeric keypad, 70–71**

- overview, 68
- packing for travel, 253
- shift keys, 69
- specific keys, 73
- troubleshooting, 300

**Keyboard mode (Input Panel), 102–103****Kindle, 7****Kinko's, 146****Klear Screen, 308****Knowledge Base, 299****K-slot, 64**● **L** ●**LAN parties, 167****landscape mode (Tablet PCs), 114****laptop**

- battery life, 17
- in college, 22
- connecting second monitor to, 161
- as desktop, 160–162
- disadvantages of, 22
- future innovations, 20
- hardware compatibility, 17
- history, 7–20
- inspection of, 254–255
- as main computer, 21
- maintenance of, 306–308
- portability, 4
- reasons for getting, 21–22
- on the road, 22
- running with lid closed, 162
- saving space with, 21
- as second computer, 21
- software for, 25–26
- weight, 17

**laptop as desktop**

- full-size keyboard and mouse, 161
- running with lid closed, 162
- second monitor, 161

**laptop bags, 317****laptop case. *See also* accessories**

- backpacks as, 252
- as carry-on luggage, 254
- cleaning, 307
- features to look for, 250–251
- need for, 249
- recommended brands, 251–252
- things to pack, 253, 321–324

**laptop cooler, connecting to USB port, 158****laptop lamp, connecting to USB port, 158****laptop lights, 67–68****laptop shopping**

- battery life and, 25
- brand name and, 24

- laptop shopping (*continued*)
    - credit card, 29
    - expansion options, 24
    - hard drive storage and, 27
    - hardware and, 27–28
    - key items, 24–25
    - LCD display and, 25
    - low/high prices and, 24
    - marketing campaigns and, 24
    - materials used and, 29
    - memory and, 27
    - modems and, 28
    - networking and, 27–28
    - optical drive and, 27–28
    - power usage and, 28–29
    - prices and, 29
    - processor and, 27
    - random access memory and, 27
    - reasons for, 21–22
    - service contract and, 29–30
    - size and, 24
    - technical support and, 29–30
    - technical terms, 29
    - things to ignore in, 24
    - warranty and, 29–30
    - weight and, 24
    - wireless Ethernet adapter and, 28
    - wireless networking and, 27
  - laptop theft, prevention of
    - being mindful of environment, 265–266
    - in cafés, 260
    - dining out and, 265–266
    - in hotels, 261
    - marking laptop, 264–265
    - overview, 263–264
    - registering and, 265
    - serial number, 265
    - statistics on laptop theft, 263–264
    - universal security slot, 64, 266
  - laptop-desktop connection
    - cable connection, 240
    - Ethernet, 241
    - overview, 239
    - sneakernet, 239–240
    - synchronizing files, 241–245
  - Last Know Good Configuration, 298
  - latches, 41–42
  - LCD display
    - background, 114
    - battery life and, 316
    - buying a laptop and, 25
    - cleaning, 308
    - configuring, 113–115
    - cover, 255
    - external, connecting, 65
    - resolution, lowering, 316
    - resolution, setting, 113–114
    - screen saver, 114
    - turning down brightness, 312
  - LCD displaying black screen, keyboard shortcut for, 287
  - LCD displaying next slide (PowerPoint), keyboard shortcut for, 287
  - lead acid battery, 126
  - lease, 186
  - Leave Meeting command (Meeting Space), 294
  - legacy adapter, connecting to USB port, 158
  - Lenovo laptops, 75
  - Libraries
    - overview, 84
    - sharing, 173–174
    - unsharing, 173
  - lid
    - adjusting for best viewing, 42
    - latches, 41–42
    - opening, 41–42, 186
    - shutting, 58
  - lights, 67–68
  - line in port, 65
  - line out port, 65
  - lint-free cloth, 308
  - lithium-ion (Li-ion) battery, 127, 313
  - Live Mail, 270
  - local area network (LAN), 167
  - Local Information dialog box, 202
  - local printer, 143
  - Location Information dialog box, 202
  - lock, 322
  - locking Windows, 57, 270–271
  - logging in, 46–48
  - logging off, 57
  - login, 48
  - logon, 48
  - Low battery action, 133
  - Low battery level, 133
  - Low battery notification, 133
  - low battery warnings, 131–133
  - low price, 24–25
  - low-battery warnings, 316
- M •
- MAC address, 184–185
  - MacBook Air laptop, 74
  - mail
    - accessing from friend’s computer, 235
    - accessing on the road, 233–234
    - attachments, 215–216
    - auto-responder, 236
    - disabling automatic checking, 237–238

- disconnecting after picking up, 237
  - forwarding messages, 235–236
  - passwords, 270
  - sending messages in one batch, 238
  - Web-based, 190, 234
- maintenance
  - cleaning the case, 307
  - cleaning the keyboard, 308
  - cleaning the LCD screen, 307
  - cleaning your laptop, 307
  - lint-free cloth for, 308
  - software, 306
- Make My Picture Available (Meeting Space), 294
- malware, 213, 218
- Manually Connect to a Wireless Network
  - option, 183
- manuals, 35
- marketing campaign, 24–25
- marking laptop, 264–265
- McAfee VirusScan, 213
- media card reader, adding, 116
- media card storage. *See also* backup
  - inserting, 117–118
  - locating, 62
  - packing, 322–323
  - removing from laptop, 118–119
- Media Library, 278
- Media Player
  - playing CD with, 276
  - ripping CD with, 277–278
  - viewing video files with, 279
  - watching DVD movie with, 279
- Meeting Space
  - account picture, 291
  - creating meeting, 292
  - ending meetings in, 294
  - inviting people to meetings in, 293
  - leaving meetings in, 294
  - overview, 290
  - public name, 291
  - setting up, 290–291
  - signing in, 291
  - starting, 291–292
  - starting meetings in, 293–294
  - startup screen, 292
- megabyte (MB), 29
- memory
  - adding, 313
  - battery life and, 314
  - buying a laptop and, 27–28
  - upgrading, 304
  - virtual memory disk swapping and, 313–314
- memory card
  - inserting, 117–118
  - locating, 62
  - packing, 322–323
- reader, 253
  - removing from laptop, 118–119
- memory chips
  - adding, 313
  - battery life and, 314
  - buying a laptop and, 28
  - upgrading, 304
  - virtual memory disk swapping and, 313–314
- memory effect, 127
- Meucci, Antonio, 194
- microphone
  - port for, 66
  - in Tablet PCs, 97
- Microsoft Knowledge Base, 299
- Microsoft XPS Document Writer, 141, 146
- Microsoft.com, 286
- minivac, 319
- mobile phone recharger, connecting to USB
  - port, 158
- Model 100 portable computer, 11
- modem
  - broadband, 200
  - buying a laptop and, 28
  - call waiting and, 206
  - calling card information, 208
  - cellular, 200
  - connecting to phone jacks, 195
  - dialing area codes, 206–207
  - dialing from other locations, 205–206
  - dialing rules, 203, 205
  - dial-up, 200–201
  - digital phone systems and, 196
  - jack, 201
  - long-distance charges and, 201
  - manual connections with, 197
  - muting, 204
  - options, 90
  - overview, 199–200
  - phone calls and, 201
  - port for, 66
  - properties, 203–204
  - receiving fax and, 149
  - sending fax and, 147
  - setting up, 202–203
  - smartphone tethering, 201
  - special commands, 204–205
  - timeouts, 208–209
  - as USB peripheral, 201
- modem/phone port, 66
- Modems tab, 202
- monitor
  - background, 114
  - battery life and, 316
  - buying a laptop and, 25
  - cleaning, 308

- monitor (*continued*)
    - configuring, 113–115
    - cover, 255
    - external, connecting, 65, 161, 288
    - resolution, lowering, 316
    - resolution, setting, 113–114
    - screen saver, 114
    - turning down brightness, 312
  - motherboard, 303
  - mouse
    - for café computing, 260
    - external, 76, 161, 320, 322
    - making the pointer more visible, 301
    - overview, 76
    - packing, 322
  - Mouse Properties dialog box, 300–301
  - MP3 players, 241, 275
  - multiple accounts, 48
  - music
    - overview, 275–276
    - playing CD, 276
    - ripping, 277–278
    - Windows Media Player, 276–278
  - music CD
    - playing, 276
    - ripping, 277–278
  - My Documents folder, 83
  - My Music folder, 83
  - My Network Places (Windows XP), 169
  - My Pictures folder, 83
  - My Videos folder, 83
  - MyBook external hard drive, 223
  - MySpace, 215
  - MyWay Mail, 234
- **N** •
- NEC UltraLite, 15–16
  - need for laptop, 21–22
  - netbook
    - battery life, 25
    - operating system, 26
    - overview, 18–19
  - network adapter, connecting to USB port, 157
  - Network and Sharing Center window, 90, 165–166, 193
  - Network Connection Status dialog box, 185
  - Network Discovery (Windows Vista), 176
  - network interface card (NIC), 164
  - network names, 183
  - network printers, 142–143
  - Network window, 86, 169
  - networking, wired
    - buying a laptop and, 28
    - computer names, 167–168
    - Ethernet, 164
    - finding other computers, 168–169
    - gateways, 165
    - hardware, 164–165
    - HomeGroup sharing, 170–174
    - hubs, 164
    - local area network, 167
    - network name, 167–168
    - overview, 163
    - ports, 164
    - routers, 164
    - shared resources, 170–173
    - software, 165–166
    - typical setup, 165
    - workgroup, 167–168
  - networking, wireless
    - adapter, 180
    - Bluetooth, 180
    - connecting to network, 181–184
    - disabling, 136, 256
    - disconnecting from network, 186–187
    - hardware, 178
    - in hotels, 261
    - light, 68
    - MAC address, 184–185
    - network names, 183
    - overview, 177
    - pay-service, accessing, 186
    - protocols, 179–180
    - public network, 182
    - renewing lease in, 186
    - software, 179
  - NetZero, 190
  - Never Dial a Connection option, 197
  - New Area Code Rule dialog box, 206–207
  - New Fax window, 148
  - New Location dialog box, 205
  - nickel-cadmium (NiCad) battery, 126–127
  - nickel-metal hydride (NiMH) battery, 127
  - Norton AntiVirus, 213
  - notification area, 49, 80
  - Num Lock key, 71, 300
  - Num Lock state, 68, 70–71
  - numeric keypad
    - connecting to USB port, 158
    - using, 70–71
- **O** •
- Oakley.com, 252
  - office supplies, 253
  - offline browsing, 232
  - on-the-road computing. *See* travel
  - operating system
    - Linux, 26
    - in netbooks, 26

- overview, 25–26
  - reinstalling, 296
  - updating, 306
  - upgrading, 305–306
  - operating system (Windows 7)
    - activating, 46
    - Computer window, 81–82
    - Control Panel window, 87–91
    - desktop, 78
    - finding printers in, 141
    - fingerprint login, 48–49
    - libraries, 84
    - locking, 57
    - logging in to, 46–48
    - login screen, 46–47
    - multiple accounts, 48
    - Network window, 86
    - notification area, 80
    - overview, 44
    - passwords, 47
    - Program Files folder, 85
    - Start button, 78
    - Start button menu, 78
    - troubleshooter, 296–297
    - User Profile folder, 82–84
    - using for the first time, 44–45
    - welcome screen, 47
    - Windows folder, 85
  - optical disc
    - buying a laptop and, 27
    - installing software from, 120
  - optical drive
    - battery life and, 316
    - ejecting discs, 62
    - external, 120–121
    - locating, 61–62
  - Osborne 1 portable computer, 9
  - Osborne, Adam, 9
  - Other Credentials button, 272
  - overcharging the battery, 312
  - overheating of laptop, 262
  - overseas power adapter, 253
- *p* ●
- Page Setup dialog box, 144–145
  - pass-through USB devices, 157
  - passwords
    - creating, 268
    - e-mail, 270
    - Internet, 269–270
    - Setup, 267
    - strong, 269
    - Windows, 47
    - wireless networking, 182
  - patches, 305
  - pay-service wireless network, 186
  - PC card
    - eject button, 63–64
    - inserting, 63, 159
    - overview, 63, 158–159
    - packing for travel, 253
    - removing from laptop, 63, 160
    - slot, 63, 159
    - types of, 159
  - PCs For Dummies* (Gookin), 39, 82, 260
  - PDF files, 146
  - Pen and Input Devices (Windows Vista), 99, 101, 105
  - Pen and Touch dialog box, 99, 105
  - pen tether, 99
  - Pen Windows, 94
  - People Near Me dialog box, 290–291
  - personal information managers (PIMs), 241
  - Personalization window, 89
  - Philips-head screwdriver, 323
  - Phone and Modem dialog box, 203–205
  - Phone and Modem window, 90
  - phone calls, 280–281
  - phone cord, 253
  - physical address, 185
  - picture, for account image, 112–113
  - PIF files, 215
  - pin area, 79
  - pliers, 323
  - Pointer Options tab, 300–301
  - pointer trail, 301
  - port, 65–67
  - port, USB
    - connecting devices, 155–156
    - device limitations, 157
    - hot swapping devices, 156
    - hubs, 156–157
    - overview, 153–154
    - pass-through devices, 157
    - powered hubs, 157
    - root port, 157
    - symbol, 66
    - unpowered hubs, 157
    - USB-powered devices, 156
    - uses for, 157–158
  - portability
    - characteristics of, 7
    - communications and, 12
    - portable printer, 139–140
    - portrait mode (Tablet PC), 114
    - power adapter, 258
    - power brick, 15, 253, 258, 321
    - power button
      - locating, 42–43
      - pressing, 43–44
      - putting red-dot sticker near, 43

- power button (*continued*)
  - setting function of, 58–60
  - symbol, 43
  - in Tablet PCs, 96
  - turning off laptop with, 58
- power conversion kit, 253
- power cord, 253, 321
- power jack, 66–67
- power management. *See also* battery; battery life
  - adjusting low-battery warnings, 132–133
  - cooling pad and, 136
  - devices that consume power, 135–136
  - hard drive storage and, 312–313
  - low battery warnings, 131–133
  - memory and, 313
  - options, 90
  - plan, 136–138
  - power-saving tips, 135–136
  - troubleshooting, 301–302
  - turning down monitor's brightness, 312
  - virtual memory disk swapping and, 313
- Power Options icon, 60
- Power Options Properties dialog box (Windows XP), 60
- Power Options System Settings window, 59
- Power Options window, 90, 136–138
- power sockets
  - in cafés, 259
  - in hotels, 261
  - on planes, 257
- powered USB hubs, 157
- PowerPoint presentation
  - backups, 287
  - creating and playing on same laptop, 286
  - hard copies, 286
  - keyboard shortcuts, 287
  - overview, 285
  - running, 288
  - setting up, 287–290
  - slideshows, 286
  - sound files for, 286
  - tips, 286
  - viewer, 286
- preinstalled software, 124
- presentations
  - backups, 287
  - creating and playing on same laptop, 286
  - fonts for, 286
  - hard copies, 286
  - keyboard shortcuts, 287
  - overview, 285
  - running, 288
  - setting up, 287–290
  - tips, 286
  - viewer, 286
- prices, 29
- Print command, 144–146
- Print dialog box, 144–146
- printer
  - adding to laptop, 142–143
  - canceling jobs in, 145
  - connecting to USB port, 157
  - default, 144
  - fax, 147–148
  - finding in Windows, 140–141
  - installing software for, 142
  - local, 143
  - network, 143
  - paper, 140
  - portable, 139–140
  - turning off, 146
  - wireless, 143
- Printers and Faxes window (Windows XP), 141
- Printers window (Windows Vista), 141
- printing
  - canceling, 145–146
  - when you don't have printer, 146
  - in Windows, 144–145
- processor, buying laptop and, 27
- Program Files folder, 85
- programs
  - computer games, 26
  - graphics, 26
  - installing, 120–122
  - maintaining, 306
  - networking, 165–166
  - operating system, 25–26
  - patches, 305
  - preinstalled, 124
  - Program Files folder, 85
  - questionable, 122
  - uninstalling, 122–123
  - updating, 305
  - upgrading, 304–305
  - Windows folder, 85
  - wireless networking, 179
- Project Gutenberg, 282–283
- protecting laptop
  - account passwords, 268
  - Action Center window, 211–212
  - antivirus software, 213
  - backing up data, 221–222
  - data protection, 266
  - deleting Web browsing history, 221
  - fingerprint reader, 272
  - firewall, 216–218
  - Guest account, disabling, 270–271
  - having laptop phone home, 271
  - in hotel room computing, 261
  - InPrivate Browsing window, 219
  - InPrivate Filtering feature, 220

Internet passwords, 269–270  
 locking Windows, 270–271  
 Set Up password, avoiding, 267  
 Set Up program, 46  
 SmartScreen Filter, 220  
 spyware, 218–219  
 Windows Defender, 219  
 Windows update, 221–222  
 public network, 182, 193  
 Public Network option, 165, 193  
 pulse dialing, 202

## • R •

Radio Shack Model 100 portable computer, 11–12  
 random access memory (RAM)  
   adding, 313  
   battery life and, 314  
   buying a laptop and, 28  
   upgrading, 304  
   virtual memory disk swapping and, 313–314  
 RAR files, 120, 122  
 reading e-mail  
   accessing from friend's computer, 235  
   accessing on the road, 233–234  
   attachments, 215–216  
   auto-responder, 236  
   disabling automatic checking, 237–238  
   disconnecting after picking up, 237  
   forwarding messages, 235–236  
   passwords, 270  
   sending messages in one batch, 238  
   on the Web, 190, 234  
 Real Virtual Network Computing, 248  
 reboot, 45  
 Receive a Fax Now button, 149  
 Recently Used Programs area, 79  
 redisplaying previous slide (PowerPoint),  
   keyboard shortcut for, 287  
 registering laptop, 265  
 reinstalling Windows, 296  
 Remote Desktop  
   accessing on network, 246–247  
   Full Screen mode, 247  
   setting up for, 246  
 removable storage  
   adding drives, 116  
   external hard drives, 116  
   finding, 119  
   media cards, 117–118  
   options, 62  
   packing, 322–323  
   removing external drive, 119  
 reset, 45  
 resolution, 113–114  
 restart, 45

restarting Windows, 53–54, 295  
 Restore My Files button, 226  
 restoring backup, 226–227  
 return service sticker, 320  
 Rip CD toolbar button, 277–278  
 ripping music, 277–278  
 RJ-45 port, 66, 164  
 root port, 157  
 router, 164, 191–192  
 rubbing alcohol, 307, 314  
 Run button, 121

## • S •

Safe mode  
   entering, 299  
   laptop always starts in, 300  
   overview, 298  
   testing in, 299  
 Safely Remove Hardware icon, 119, 160  
 scanner, connecting to USB port, 158  
 SCR files, 215  
 screen  
   cleaning, 308  
   dimming, 312  
 screen saver, 114  
 screen wipes, 253, 322  
 screwdriver, 323  
 Search text box, 79  
 secondary batteries, 127  
 Secure Digital (SD) card, 64, 323  
 security  
   account passwords, 268  
   Action Center window, 211–212  
   antivirus software, 213  
   backing up data, 221–222  
   data protection, 266  
   deleting Web browsing history, 221  
   fingerprint reader, 272  
   firewall, 216–218  
   Guest account, disabling, 270–271  
   having laptop phone home, 271  
   in hotel room computing, 261  
   InPrivate Browsing window, 219  
   InPrivate Filtering feature, 220  
   Internet passwords, 269–270  
   locking Windows, 270–271  
   Set Up password, avoiding, 267  
   Set Up program, 46  
   SmartScreen Filter, 220  
   spyware, 218–219  
   Windows Defender, 219  
   Windows update, 221–222  
 security cable, 64  
 security device, connecting to USB port, 158  
 Security Tracking of Office Property (STOP), 265  
 Send Invitations button (Meeting Space), 293

- serial number, 265
- service contract, 29–30
- Service Standard Identifier (SSID), 183
- Set Up a Connection or Network, 194
- Set Up a Dial-up Connection, 194
- Set Up a New Connection or Network link, 183
- Set Up password, 267
- Set Up program, 46
- setting up laptop
  - charging the battery, 38–39
  - finding place for laptop, 37–38
  - plugging into UPS, 39
- Setup program, 46
- Share a Program or Your Desktop (Meeting Space), 294
- shared resources, 170–173
- Shield icon, 53
- Show Desktop button, 49
- Shutdown button, 53, 79
- Shutdown command (Windows Vista), 53
- Shutdown menu, 52–53, 79
- shutting down, 53
- size of laptop, 24
- Skype, 281–282
- slate Tablet PC, 96
- sleep button, 43
- Sleep mode
  - light, 67
  - putting to, 53–55
  - waking up from, 55
- slideshows, 286
- smart battery, 131, 316
- smartphone, 20, 201, 241
- SmartScreen Filter, 220
- SMTP server, 233
- sneakernet, 239–240
- social networking, 215
- software
  - computer games, 26
  - graphics, 26
  - installing, 120–122
  - maintaining, 306
  - networking, 165–166
  - operating system, 25–26
  - patches, 305
  - preinstalled, 124
  - questionable, 122
  - registering, 265
  - uninstalling, 122–123
  - updating, 305
  - upgrading, 304–305
  - wireless networking, 179
- solid state drive (SSD), 28
- sound hardware, connecting to USB port, 158
- spare battery
  - as laptop accessory, 317–318
  - packing, 253, 322
  - quick swapping, 134
- speakers
  - battery life and, 316
  - connecting to USB port, 158
  - muting, 136, 316
  - port, 65
  - in Tablet PCs, 97
- spyware, 218–219
- SRC files, 120, 122
- Stand By mode, 301
- Start a New Meeting (Meeting Space), 292
- Start button, 49, 78
- Start button and panel
  - All Programs menu, 79
  - Control Panel, 79
  - Help menu, 79
  - overview, 78
  - pin area, 79
  - Recently Used Programs area, 79
  - Search text box, 79
  - Shutdown menu, 79
- Start menu, Shutdown button, 53
- statistics on laptop theft, 263–264
- Sticky Notes program, 107
- stolen laptop
  - in cafés, 260
  - dining out and, 265–266
  - in hotels, 261
  - marking laptop, 264–265
  - overview, 263–264
  - registering and, 265
  - serial number, 265
  - statistics on, 263–264
  - universal security slot, 64, 266
- STOP program, 265
- storage device
  - battery life and, 312
  - buying a laptop and, 26–28
  - external, 116, 223
  - external hard drives, 116, 119, 157, 223, 253
  - Hibernation mode and, 57
  - memory cards, 62, 117–119, 322–323
  - uninstalling software and, 123
  - upgrading, 304
  - USB drives, 11, 116, 122
  - viewing, 81–82
  - virtual memory swapping, 313–314
  - Windows operating system and, 81–83
- stylus, 97–98
- subfolders, 84
- surge protector, 39
- S-Video connection, 288
- S-Video out port, 66–67
- switches, 164
- Sync Center
  - accessing synced files, 244
  - ending sync partnership, 245
  - opening, 242

- overview, 241
- reviewing sync partnership, 243
- setting up sync partnership, 242–243
- synchronizing files, 243–244
- syncing new files, 244–245
- using, 242
- sync partnership, 242–243
- synchronizing files
  - accessing desktop remotely, 245–248
  - accessing synced files, 244
  - before you go, 252–253
  - ending sync partnership, 245
  - overview, 241
  - setting up sync partnership, 242–243
  - syncing new files, 244–245
- System and Security heading, 296
- System Restore, 297–298

## • T •

Tablet PC

- advantages of, 94–95
- airline computing and, 257
- biometric reader, 96
- cleaning, 308
- convertible, 95
- cursor control pad, 97
- digitizer, 98
- disadvantages of, 94–95
- finger as input device, 105–106
- fingerprint reader, 96
- function buttons, 97
- history, 94
- Inkball program, 107
- Input Panel, 102–103
- landscape mode, 114
- overview, 17–18, 93
- pen and mouse actions, 101
- pen cursor, 100
- pen tether, 99
- portrait mode, 114
- power button, 42–43, 96
- power button lock, 96
- screen orientation, 114
- slate, 96
- speaker/microphone, 97
- status lights, 97
- Sticky Notes program, 107
- stylus, 97–98
- stylus orientation, 100–101
- touch pointer, 106
- types of, 95–96
- webcam, 97
- Windows Journal program, 105–106
- writing text with Input Panel, 103–105

- Tablet PC Pen Training, 101
- Tablet PC settings, 89, 99
- tabulae ceratea, 17–18, 93
- TAR files, 120, 122
- Targus.com, 252
- taskbar, 49
- tech support, 296
- technical support, 28
- temperature, 262, 315
- terminals, 314–315
- theft prevention. *See also* security
  - being mindful of environment, 265–266
  - in cafés, 260
  - dining out and, 265–266
  - in hotels, 261
  - marking laptop, 264–265
  - overview, 263–264
  - registering and, 265
  - serial number, 265
  - statistics on laptop theft, 263–264
  - universal security slot, 64, 266
- TheNorthFace.com, 252
- timeout, 208–209, 316
- tone dialing, 202
- touch pad
  - adjusting, 300–301
  - disabling, 300
  - overview, 73
  - troubleshooting, 300
  - using, 74
- touch pointer, 106
- TrackPoint, 75–76
- travel
  - accessing e-mail, 233–234
  - airline computing, 255–258
  - airport inspections and, 254–255
  - avoiding overheating, 262
  - café computing, 258–260
  - hotel room computing, 260–261
  - laptop case for, 249–252
  - loading up music before, 278
  - low battery warnings, 257
  - printing and, 146
  - storing laptop on plane, 255
  - things to do before, 252–253
  - things to pack, 253
  - using laptop on the plane, 255–258
  - wall sockets, 257, 259, 261
- travel case. *See also* accessories
  - backpacks as, 252
  - as carry-on luggage, 254
  - cleaning, 307
  - features to look for, 250–251
  - need for, 249
  - recommended brands, 251–252
  - things to pack, 253, 321–324
- Trojan horses, 213

- Troubleshooter, 296–297
  - troubleshooting
    - battery won't charge, 302
    - keyboard, 300
    - laptop won't wake up, 301
    - power management, 301
    - reinstalling Windows, 296
    - restarting Windows, 295
    - Safe mode, 298–300
    - System Restore, 297–298
    - touch pad, 300–301
    - Windows 7 Troubleshooter, 296–297
  - Troubleshooting & Maintaining Your PC All-in-One For Dummies* (Gookin), 295, 300
  - Troubleshooting Your PC For Dummies* (Gookin), 223, 306–308
  - Turn Off Computer command (Windows XP), 53–54
  - Turn Off Guest Account link, 270
  - turning off laptop
    - Hibernation mode, 56–57
    - locking Windows, 57
    - logging off, 57
    - options for, 51
    - pressing and holding down power button, 58
    - by pressing power button, 58
    - restarting Windows, 53–54
    - Shutdown menu, 52–53
    - shutting down properly, 53
    - shutting laptop lid, 58
    - Sleep mode, 53–55
  - turning on laptop
    - activating Windows, 46
    - adjusting lid for best viewing, 42
    - after hibernation, 56–57
    - finding the power button, 42–43
    - logging in to Windows, 46–48
    - logging off, 57
    - opening the lid, 41–42
    - in Safe mode, 298–300
    - Set Up program, 46
    - terminologies, 45
    - waking up from Sleep mode, 55
  - Twitter, 215
- U •**
- Uninstall a Program button, 123
  - Uninstall command, 123
  - uninstalling software, 122–123
  - uninterruptible power supply (UPS), 39
  - universal security slot (USS), 64, 266
  - unpacking laptop. *See also* buying laptop
    - containers for spare parts, manuals and documentation, 35
    - how long to keep the box, 36
    - making pile for box contents, 34–35
    - packing materials, 35
    - sending in the warranty, 36
    - step-by-step directions, 34–35
    - tips, 33–35
  - unpowered USB hub, 157
  - updates
    - turning off laptop and, 53
    - vs. upgrades, 305
    - Windows, 221–222
  - upgrading
    - hard drives, 304
    - hardware, 303–304
    - random access memory, 304
    - software, 304–305
    - vs. updates, 305
  - upstream end, 155
  - USB cables
    - A-B ends, 154–155
    - downstream end, 155
    - lengths, 155
    - micro/mini connectors, 155
    - upstream end, 155
  - USB devices. *See also* accessories
    - cooling pad, 158, 318–319
    - digital camera, 157
    - external hard drives, 157
    - game controllers, 158
    - headphones, 157
    - keyboard, 319
    - lamp, 319
    - laptop cooler, 158
    - laptop lamp, 158
    - legacy adapters, 158
    - minivac, 319
    - mobile phone recharger, 158
    - mouse, 319
    - network adapters, 157
    - numeric keypad, 158
    - printers, 157
    - scanners, 158
    - security device, 158
    - sound hardware, 158
    - speakers, 158
    - video camera, 158
    - Webcam, 158, 318
  - USB drives. *See also* backup
    - adding, 116
    - installing software from, 122
    - removing from laptop, 11
  - USB lamp, 319
  - USB ports
    - connecting devices, 155–156
    - device limitations, 157
    - hot swapping devices, 156

- hubs, 156–157
  - overview, 153–154
  - pass-through devices, 157
  - powered hubs, 157
  - root port, 157
  - symbol, 66
  - unpowered hubs, 157
  - USB-powered devices, 156
  - uses for, 157–158
- Use Your Finger As an Input Device option, 105
- User Account Controls (UACs), 115
- User Accounts window, 91, 112–113
- user profile, 45
- User Profile folder, 82–84

## • U •

- VBS files, 215
- vents, 64
- VGA connector, 288
- video camera, connecting to USB port, 158
- video card, buying a laptop and, 26
- video chat, 281–282
- video files, playing, 279
- video LCD display port, 66
- video memory, 316
- video projector, 253, 287–289
- View Devices and Printers link, 91
- View Network and Tasks link, 90, 185
- View Status link (Windows Vista), 185
- virtual memory disk swapping, 313–314
- Virtual Network Computing (VNC), 248
- virus. *See also* security
  - antivirus software, 213–214
  - in e-mail attachments, 215–216
  - protecting laptop from, 215–216
  - scanning for, 214
  - types of, 213
- Voice over Internet Protocol (VoIP), 280–281

## • W •

- waking up. *See also* turning on laptop
  - from Sleep mode, 55
  - from Stand By mode, 301
  - by tapping key on keyboard, 44
  - troubleshooting, 55, 301
- wall socket
  - in cafés, 259
  - in hotels, 261
  - on planes, 257
- wallpaper, 49
- warm boot, 45
- warranty
  - buying a laptop and, 29–30
  - filling and returning, 36
  - tips, 34

- Web browsing
  - checking suspect Web pages in, 220
  - history, deleting, 221
  - InPrivate Browsing window, 219
  - InPrivate Filtering, 220
  - passwords, 269–270
  - saving Web pages in, 232
  - working offline, 232
- Web pages
  - checking, 221
  - saving, 232
- Web-based e-mail, 190, 234
- Webcam
  - capturing still shots with, 280
  - changing account image with, 112
  - connecting to USB port, 158
  - creating videos with, 279
  - as laptop accessory, 318
  - locating, 64–65
    - in Tablet PCs, 97
- weight
  - considering when buying laptop, 24
  - laptop features and, 17
  - power brick and, 15
- Western Digital Passport external hard drives, 223
- wheel button, 74–75
- Win key, 52
- Windows 7 Firewall, 217
- Windows 7 operating system
  - activating, 46
  - Computer window, 81–82
  - Control Panel window, 87–91
  - desktop, 78
  - finding printers in, 141
  - fingerprint login, 48–49
  - libraries, 84
  - locking, 57
  - logging in to, 46–48
  - login screen, 46–47
  - multiple accounts, 48
  - Network window, 86
  - notification area, 80
  - overview, 44
  - passwords, 47
  - Program Files folder, 85
  - Start button, 78
  - Start button menu, 78
  - troubleshooter, 296–297
  - User Profile folder, 82–84
  - using for the first time, 44–45
  - welcome screen, 47
  - Windows folder, 85
- Windows Backup, 223
- Windows Contact folder, 148
- Windows Defender, 219
- Windows Fax and Scan window, 149

- Windows folder, 85
  - Windows for Pen Computing, 94
  - Windows Journal program, 105–106
  - Windows Live, 234
  - Windows Media Center, 278
  - Windows Media Player
    - playing CD with, 276
    - ripping CD with, 277–278
    - viewing video files with, 279
    - watching DVD movie with, 279
  - Windows Meeting Space
    - account picture, 291
    - creating meetings, 292
    - ending meetings in, 294
    - inviting people to meetings in, 293
    - leaving meetings in, 294
    - overview, 290
    - public name, 291
    - setting up, 290–291
    - signing in, 291
    - starting, 291–292
    - starting meetings in, 293–294
    - startup screen, 292
  - Windows Mobility Center
    - accessing, 88
    - accessing finger print reader software, 272
    - accessing Sync Center, 242
    - adjusting touchpad, 301
    - Battery Status area, 130
    - function button, 97
    - keyboard shortcut, 88
    - rotating Tablet PC screen in, 99
  - Windows operating system
    - in netbooks, 26
    - overview, 25–26
    - reinstalling, 296
    - upgrading, 305–306
  - Windows Security Center (Windows Vista), 212
  - Windows update, 221–222
  - Windows Vista operating system, 26
  - Windows XP operating system, 26
  - WinNT folder, 85
  - wire cutter, 323
  - wired networking
    - buying a laptop and, 28
    - computer names, 167–168
    - Ethernet, 164
    - finding other computers, 168–169
    - gateways, 165
    - hardware, 164–165
    - HomeGroup sharing, 170–174
    - hubs, 164
    - local area network, 167
    - network name, 167–168
    - overview, 163
    - ports, 164
    - routers, 164
    - shared resources, 170–173
    - software, 165–166
    - typical setup, 165
    - workgroup, 167–168
  - wireless network adapter
    - battery life and, 136
    - buying a laptop and, 28
    - standards, 180
    - turning off, 256
  - Wireless Network Connection link, 185
  - wireless networking
    - adapter, 180
    - automatically connecting to network, 180
    - Bluetooth, 180
    - connecting to network, 181–184
    - disabling, 136, 256
    - disconnecting from network, 186–187
    - hardware, 178
    - in hotels, 261
    - light, 68
    - MAC address, 184–185
    - network names, 183
    - overview, 177
    - passwords, 182
    - pay-service, accessing, 186
    - protocols, 179–180
    - public network, 182
    - renewing lease in, 186
    - software, 179
  - Wireless Networking Properties dialog box, 184
  - wireless printer, 143
  - Work Network option, 165, 193
  - workgroup, 167–168
  - worms, 213
- 
- X •
  - Xerox Dynabook, 8–9, 94
  - Xerox PARC, 8–9
  - XPS Viewer, 146
  - X-ray machines, 255
- 
- Y •
  - Yahoo! Mail, 234
  - YouTube, 279
- 
- Z •
  - ZIP files, 120, 122
  - ZTrace.com, 271