

# INDEX

**Note to the Reader:** Throughout this index **boldfaced** page numbers indicate primary discussions of a topic. *Italicized* page numbers indicate illustrations.

## A

- Abstract Studio Shadow environment, 555, **556**
- AC power cord. *See* power cord for lamp
- accelerator keys, 37–38, **38**
- ACIS format, 473
- Activate Display State command, 424
- activating display states, 424
- active configuration, 246
- active documents, 519
- Add Configuration command, 358
- Add Configuration PropertyManager, 354
- Add Dimensions option, 121–122
- Add Display State command, 422
- Add File Location icon, 394
- Add Prefix option, 477
- Add Revision command, 194, 369
- Add Suffix option, 477
- Add Symbol button, 528
- Add Symbol command, 370
- Add To Library button, 395, 397
- Add To Library File icon, 394
- Add To Library PropertyManager, 395, 397–398, **397**
- Adobe PDF files, 197–198, 466–469, 467–468
- Advanced Component Selection dialog box, 430
- Advanced Mates, 402–404, **403**
- Advanced Search command, 429
- Advanced tab, 559, **559**
- Aligned button, 357
- alignment
  - angle mates, 357
  - balloons, 460
  - bearing nut, 401, 401
  - breaking, 159
  - components, 332, 406
  - electrical cover, 402
  - mates, 390
  - All Components option, 481
  - All Sheets option, 197
  - Along XYZ option, 442–444, **443**
  - Alt key, 38, 257
  - Alternate Path option, 444
  - American National Standards Institute (ANSI)
    - drafting standards, 512
    - sheet sizes, 511
  - American Society of Mechanical Engineers (ASME) standards, 512
  - anchor points
    - BOMs, 280–282, 281–282, 456
    - revision tables, 537–538, **537**
  - AND search criteria, 430
  - Angle Distance option, 144
  - angle mates
    - adding, 356–357, 356–357
    - modifying, 358–359, 358–359
  - Angle Of The Revolution option, 218
  - angles
    - draft, 237–238
    - thread relief, 227
  - angular dimension, 103, **103**
  - annotations, 59, 162–163
    - centerlines, 186–187, **187**
    - copying, 395

- annotations (*continued*)
  - dimensions. *See* dimensions
  - graphics area, 75, 76
  - importing, 164–167, 165–167
- Annotations flyout, 282, 283
- ANSI (American National Standards Institute)
  - drafting standards, 512
  - sheet sizes, 511
- Ansi Inch thread standard, 221
- Anti-Aligned button, 357
  - bearing nut, 401
  - components, 332, 406
  - electrical cover, 402
- appearances, 67, 67
  - assembly-level, 73, 73
  - editing, 346–347, 347
  - lamp model, 409–410, 409
  - parts, 258
    - color, 258–259
    - materials, 259–260
    - RealView, 260–262, 261–262
  - properties, 558–560, 559
  - rendering, 553–555, 553–554
  - shade model, 344–347, 345–347
- Appearances button
  - PhotoView 360 Selection toolbar, 550
  - PhotoView 360 Tasks toolbar, 548
- Appearances/Scenes tab, 14, 15
  - lamp model, 409
  - materials, 260
  - shade model, 345
- Appearances window, 553–555, 553, 558–559, 559
- Arc PropertyManager, 207
- arcs
  - drawing, 206–207, 206–207
  - transitioning, 291–294, 291–294, 306, 306
- Area Light appearance, 560
- arranging dimensions, 168–170, 169–170
- arrow heads, 173, 174
- arrows (->) for external references, 339, 373–374
- ASME (American Society of Mechanical Engineers) standards, 512
- ASME Y14.2M-1992, Line Conventions and Lettering standard, 514
- assemblies, 2, 51, 51, 234
  - BOMs inserted into, 416–418, 417
  - components inserted into, 254, 254
  - configurations, 353–355, 353–355
  - design approaches, 71
  - display control, 420–424, 420–424
  - exploded views, 435
    - creating, 435–439, 436–438
    - editing, 439–441, 439–441
    - paths to, 442–445, 442–444
  - FeatureManager design tree in, 72–73, 72–74
  - mates in, 73, 74, 255–258, 256–257
  - moving components in, 255
  - opening, 71–72
  - opening parts in, 342, 342
  - over-defining, 353, 353, 360, 360
  - parts appearance in, 258
    - color, 258–259
    - materials, 259–260
    - RealView, 260–262, 261–262
  - parts from, 480–481, 481–482
  - selection tools for, 425–430, 425–428
  - subassemblies inserted into, 351–353, 352–353
  - virtual components, 478–480, 478–480
- Assembly button, 550
- assembly drawings, 264
  - balloons, 282–286
  - BOMs, 276
    - anchor points, 280–282, 281–282

- Bill Of Materials PropertyManager, 277–280
    - finishing, 286–287, 287–288
    - exploded. *See* exploded assembly drawings
    - views. *See* views
  - Assembly tab
    - external references, 374
    - inserting components, 331–332
    - mating components, 332
  - assembly templates
    - creating, 493–494
    - title blocks. *See* title blocks
  - Assembly Transparency For In-Context
    - Editing command, 372
  - assembly visualization, 430–435, 431–432, 434
  - Assembly Visualization button, 431
  - Assembly Visualization mode, 435
  - associativity of documents, 51
  - asterisks (\*) for external references, 373
  - at signs (@) in configuration names, 354
  - Attach To Anchor Point option, 282
  - Auto Collapse button, 19
  - Auto Hatching option, 273
  - Auto-Space Components After Drag option, 441
  - Auto-Start Projected View option, 268, 270
  - AutoBalloon command, 460, 460
  - AutoBalloon PropertyManager, 282–286, 283, 285–286, 460
  - Automatic printing option, 196
  - Automatic setting for tree item visibility, 69
  - autorecovery, 368
  - autotransitioning, 291, 291, 306, 306
  - Axis Of Revolution field, 236
  - axonometric projections, 452
- B**
- Back view, 54–55
  - Back orthographic view, 516–517, 516–517
  - backgrounds, custom, 562–563, 563
  - Backup/Recover command, 368
  - Balloon Edges option, 283
  - Balloon Faces option, 283
  - Balloon Layout section, 283, 460, 460
  - Balloon Settings section, 284
  - Balloon Text option, 284
  - balloons, 282
    - adding, 459–461, 460–461
    - AutoBalloon PropertyManager, 282–286, 283, 285–286
  - Base, Lamp model. *See* lamp model
  - base extrusion sketches
    - creating, 85–87, 87
    - defining, 91–94, 92–94
    - Instant3D, 95–98, 97–98
    - prefixes, 87–88
    - rectangles for, 88–91, 88–90
  - base features, 2
    - creating, 61, 95–96
    - lamp base, 85–86, 88
    - lamp shaft, 218
    - parts, 52
    - shade mounts. *See* shade model and subassembly
  - bearing nut, 399–401, 400–401
  - Begin Assembly PropertyManager, 252
    - assembly templates, 493
    - opening, 388
    - shades, 330
  - Bilateral tolerance type, 181
  - Bill Of Materials PropertyManager, 277–282, 417, 417, 456
  - bills of materials (BOMs), 276
    - anchor points, 280–282, 281–282, 456
    - balloons, 459–461, 460–461
    - filling in, 458–459, 459
    - finishing, 286–287, 287–288
    - format updating, 457–458, 457
    - hiding and showing, 419–420

bill of materials (*continued*)  
 inserting in assemblies, 416–418, 417  
 item number reordering, 461–462, 462  
 linking to, 455–456, 455–456  
 settings, 277–280  
 tables, 418–419, 418–419  
 bisecting parts, 156, 156  
 Black And White printing option, 196  
 Blind end condition, 107, 314  
 blind holes, 230, 314  
 blocks  
   copying, 395  
   title. *See* title blocks  
   tolerance, 528, 528  
 blocks (.sldblk) extension, 395  
 Body button, 550  
 BOM Options section, 456  
 BOM Type section, 277–278  
 BOMs. *See* bills of materials (BOMs)  
 Border section  
   Bill Of Materials PropertyManager, 279  
   Revision Symbol PropertyManager, 370  
   Revision Table PropertyManager, 539  
 Boss-Extrude PropertyManager, 337  
 Boss-Extrude2 feature, 139–140, 139  
 bosses  
   center marks, 184  
   extrusions, 110–115, 110–116  
   filleting, 134–136, 135–136, 139, 139  
   threaded, 219–222, 220–222  
 Bottom orthographic view, 516–517, 516–517  
 bottom-up design, 71  
   drawbacks, 330  
   modifications in, 364, 372  
 Bottom view, 54–55  
 bottom wall thickness, 118, 119  
 Bottoming Tapped Hole option, 311  
 box selection, 40–41, 41  
 Brass directory, 553

Brass materials  
   appearance, 408–409  
   applying, 260, 261  
 Break Alignment command, 159  
 British Standards Institution (BSI), 513  
 broken external references, 373  
 Broken-Out Section PropertyManager,  
   160–162  
 broken-out sections, 159–161, 160–161  
 Browse For Folder window, 152, 341  
 Browse For Template button, 495, 538  
 Browse For Template window, 538  
 Brushed Brass button, 554, 554  
 Brushed Brass material, 555  
 BSI (British Standards Institution), 513  
 buckets, 556  
 bulb subassembly  
   appearance, 560  
   interference between components, 376, 377  
   selecting from, 425–427, 426–427  
   shade model, 350, 352  
 buttons, mouse, 39, 42–44, 43

## C

Calculate command, 381  
 Camera Settings tab, 565–567, 567  
 cameras  
   custom views, 560–561, 561  
   depth of field, 565–567, 567  
   options, 566–567, 567  
 categories for parts, 488–490  
 Categories window, 7, 25  
 cavities, 119–120, 120  
 Center Mark button, 188  
 Center Mark PropertyManager, 188  
 center marks  
   adding, 187–189, 188–189

- bosses, 184
- purpose, 186
- center points
  - arcs, 206
  - circles, 111, *111*
  - rectangles, 90, *90*
- Center Rectangle tool, 90, 117
- Centerline tool, 234
- centerlines
  - dimensions with, 209–211, *209–211*
  - drawing, 203, *203*
  - lamp base, 186–187, *187*
  - modifying, 204–205, *204–205*
  - purpose, 186
  - section views, 274–275, *274–275*
  - thread relief, 224–225, *225*
  - washers, 234
- Centerpoint Arc tool, 206
- Chamfer Dimension button, 177
- Chamfer PropertyManager, 144–145, *144*, 223
- Chamfer tool, 144, 223
- chamfers, 132
  - adding, 143–146, *143–146*
  - dimensions, 177–179, *178*
  - threaded holes, 231, *231*
  - washers, 240–241, *242*
- changes, 364
  - components
    - interference between, 374–378, *375–377*,  
381–382, *381*
    - replacing, 382–385, *383–385*
    - updating, 364–365
  - dimensions
    - with Instant3D, 365, *365*
    - without Instant3D, 365–367, *366–367*
  - document updating, 368–371, *369–371*
  - in-context editing, 372–374
  - linking, 530–532, *531–532*
  - saving, 367–368
  - washer covers, 378–379, *378–379*
  - washers, 379–381, *380*
- Circle command, 214, *214*
- Circle tool, 111
- circles
  - boss extrusions, 111–114, *111–112*
  - concentric, 124–125, *124–125*
  - diameters, 112, *112*, 123–125, *123–125*,  
128, *129*
- Circular Edges field, 315, *315*
- Clearances option for holes, 312
- Clockwise option for helices, 322
- Close Sketch icon, 104, *104*
- closed loops, 134, *134*
- closed spline profiles, 159
- coincident center points, 90, *90*
- Coincident mates
  - creating, 405–406
  - electrical cover, 402
  - Peg-in-hole, 407
- collinear lines, 100–101
- color
  - assembly visualization, 433–434
  - drafts, 239–240
  - parts, 258–259, 489
  - PDF files, 468–469
  - printing, 196
  - rendering, 558–559
  - swept feature, 301
- Color/Gray Scale printing option, 196
- Color window, 559
- Colors category, 489
- Column Header field, 433
- Column Width window, 458
- CommandManager, 16, *16*
  - accessing, 18, *18*
  - angle mates, 356
  - assembly visualization, 431
  - display states, 424

- CommandManager (*continued*)
  - extrusions, 337
  - floating and docking, 18–20, 19–20
  - helices, 324
  - hiding text in, 20, 20
  - holes, 344
  - inserting components, 331–332
  - Instant3D, 366, 366
  - interference detection, 375, 381
  - mating components, 332
  - mirroring, 316
  - mold tools, 237, 237, 240
  - overview, 17–18
  - section views, 271
  - Shell feature, 343
  - tabs, 21, 21
    - adding and removing, 24–26
    - creating, 23–24
    - toolbars, 22–23, 22–23
    - washer covers, 379
  - commands, selecting, 44
  - Commands tab, 7, 7
    - shortcut toolbar, 29
    - tab tools, 24–25
  - Component Properties command
    - exploded views, 439
    - flexible subassemblies, 413, 413
  - Component Properties window, 414–415, 414
  - components
    - concentric, 256, 256
    - Design Library
      - adding, 395–399, 396–398
      - inserting into assemblies, 399–401, 400–401
    - hidden. *See* hidden components
    - inserting into assemblies, 254, 254
    - interference between, 374–378, 375–377, 381–382, 381
    - moving into assemblies, 255
    - replacing, 382–385, 383–385
    - updating, 364–365
    - virtual
      - overview, 339–340
      - saving, 340–341, 340–341
      - virtualizing, 478–480, 478–480
  - compressed files, 477
  - concentric circles
    - drawing, 124–125, 124–125
    - for through holes, 128, 128
  - concentric components, 256, 256
  - Concentric mate, 390–392, 390
    - alignment, 401
    - Peg-in-hole, 407
  - Configuration Name field, 354
  - Configuration section, 358
  - Configuration Properties section, 354
  - configuration-specific title block properties, 518
  - ConfigurationManager, 70, 358
    - active configuration, 360
    - display states
      - activating, 424
      - creating, 422
      - renaming, 423
      - setting, 421, 421
    - exploded lines, 444
    - exploded views, 439
    - with FeatureManager design tree, 245–247, 245–246
    - named views, 452
    - shade model, 353–354, 353
  - configurations
    - for assemblies, 353–355, 353–355
    - Bill Of Materials PropertyManager, 278
    - display state setting, 421, 421
    - mate modifications, 358–359, 358–359
    - names, 244, 245, 354
    - parts
      - configuring, 242–247, 243–246
      - selecting, 253
    - switching between, 244–245, 245, 359–360, 359–360

- Configurations section, 278
- Configure Dimension command, 243, 358
- Configure Feature command, 244
- confirmation corners, 94, 94
- Connect To Start Loop button, 142
- Connected To End Loop button, 133
- Constant Pitch option for helices, 321–322
- Construction Geometry button, 294
- construction lines
  - from lines, 294–295, 295
  - threads, 325, 326
- Consumer Product Design category, 4
- context toolbars, 31–32, 31
- context-sensitive toolbars, 16
- Control Attributes section, 505
- Control Property Attributes option, 504–505
- controls, tab, 505–506, 506
- Convert Entities button, 224
- Convert Entities command, 320
- Convert Entities PropertyManager, 320
- convex arcs, 207, 208
- coordinate display in sketches, 89, 89
- Copy Existing Table option, 456
- Copy Tab To command, 23–24
- copying
  - annotations and blocks, 395
  - features, 395
  - parts and subassemblies, 334
- cords. *See* power cord for lamp
- cores, 116–117, 117–118
  - cutout cavities, 119–120, 120
  - cutout location, 118–119, 119
  - holes for wiring, 123–131, 123–131
- Corner Rectangle command, 89
- Corner Rectangle option, 90
- Corner Rectangle tool, 117
- Corner Trim tool, 215
- Cosmetic Thread Display section, 269–270, 270
- Cosmetic Thread option, 219
- Cosmetic Thread PropertyManager, 221, 221, 315
- cosmetic threads, 219–221, 220, 230
  - settings, 269–270, 270
  - shade retainer, 315, 316
- Counterbore button, 311
- counterbores
  - dimension tolerance, 180
  - extruded cuts for, 125–127, 126–127
  - holes for, 123–125, 123–125
  - shaft nut, 145, 145
- Counterclockwise option for helices, 322
- Countersink button, 311
- countersunk holes, 311
- covers
  - electrical, 402–405, 403–404
  - electronics, 120–122, 122
  - washer. *See* washer covers
- Create Multiple Views option, 266–268
- Create New Folder icon, 395
- criteria for searches, 430
- cross selection, 40–41, 41
- Ctrl key for parts copying, 334
- Current Sheet option, 197
- custom backgrounds, 562–563, 563
- custom bearing nut, 399–401, 400–401
- custom camera views, 560–561, 561
- Custom Column window, 433
- custom properties for title blocks
  - adding, 520–521, 520
  - defining, 518–519, 519
- Custom Properties tab, 14, 15, 504, 504, 519
- Custom Properties window, 253
- custom property tabs
  - controls, 505–506, 506
  - creating, 503–504, 504
  - group boxes, 504–505, 505
  - saving and using, 507, 507
- Custom tab, 499–501, 499, 501
  - revision numbers, 531–532, 532
  - title block properties, 519–521, 519–521
- Custom View Name window, 561
- Custom Views window, 561

Customize CommandManager command, 22  
 Customize Menu command, 42  
 Customize window  
     CommandManager, 23, 23  
     Commands tab, 7, 7  
     keyboard shortcuts, 35  
     shortcut toolbar, 29–31  
 Cut-Extrude command, 116, 230  
 Cut-Extrude tool, 121  
 Cut-Revolve PropertyManager, 227  
 cutouts  
     cavities, 119–120, 120  
     electronics and wiring, 120–122, 122  
     location, 118–119, 119  
 CutSweep PropertyManager, 304  
 cutting threads, 326–328, 327

## D

dates  
     in revision tables, 194  
     in title blocks, 191  
 Default configuration, 359–360  
 defaults  
     shortcut keys, 32–34  
     views, 534  
 Define Search Criteria tab, 430  
 Define Title Block command, 521  
 Defined By section, 320–321  
 defined diameters, circles with, 123–125, 123–125  
 defining  
     anchor points, 537–538, 537  
     custom properties, 518–519, 519  
     mates, 389–391, 389–391  
     shade retainers, 308, 308–309  
     sketches, 91–94, 92–94, 102–104, 102–104  
     degree symbol (°), entering, 528  
     degrees of freedom, 255  
     deleting Design Library items, 399  
     depth  
         broken-out sections, 160, 160  
         drilled holes, 314, 314  
         extrusions, 105, 105, 120, 120  
     depth of field, 565–567, 566–567  
     Depth Of Field options, 565–567  
     Description column and field  
         configurations, 358  
         revision symbols, 371  
         revision tables, 194  
     Description property  
         links, 498  
         tab controls, 505  
     descriptions  
         configurations, 358  
         Design Library items, 398, 398  
         links, 498  
         revision symbols, 371  
         revision tables, 194  
         tab controls, 505  
     design intent, 91, 102–103, 102  
     Design Library, 393  
         components  
             adding, 395–399, 396–398  
             inserting into assemblies, 399–401, 400–401  
             vs. Toolbox, 393–395  
     Design Library tab, 10, 11, 396  
     desk lamp model. *See* lamp model  
     detached drawings, 198, 469–472, 471  
     Detail View button, 162  
     detailed views, 161–162, 162  
     Detailing property, 489  
     Detect Interference Between Components  
         option, 374  
     Deutsches Institut für Normung (DIN), 513

- diameters
  - circles, 112, *112*, 123–125, *123–125*, 128, *129*
  - dimensions, 171–173, *172–173*
  - threads, 222, *222*, 231
- Digital Product Definition Data Practices
  - standard, 494
- dimension lines, 163–164
- Dimension Palette, 179–183, *180–183*
- Dimension PropertyManager, 172, 180
- Dimension Type section, 269
- dimensions
  - arranging, 168–170, *169–170*
  - with centerlines, 209–211, *209–211*
  - chamfers, 177–179, *178*
  - changes
    - with Instant3D, 365, *365*
    - without Instant3D, 365–367, *366–367*
  - circles, 112–113
  - for design intent, 102–103, *102*
  - diameters, 171–173, *172–173*
  - dimension arrows, 173, *174*
  - dimension lines, 163–164
  - Dimension Palette, 179–183, *180–183*
  - extension lines, 163–164, 170–171, *171*
  - hiding and showing, 174–176, *175–176*
  - model, 163
  - moving between views, 167–168, *168*
  - paths, 299, *300*
  - precision, 179, 490, *491*
  - PropertyManager, 70, *70*
  - rectangles, 91–93, *92–93*
  - reference, 163, 179, 183–186, *184–185*
  - Shift key for, 130–131, *131*
  - types, 94–95
  - washers, 243, *243*
- Dimensions section, 165
- Dimetric views, 267, 269, 452
- DimXpert category, 489–490
- DimXpert command, 494
- DimXpertManager, 70–71
- DIN (Deutsches Institut für Normung), 513
- Direct1 section, 229
- Direction Of Pull field, 240
- Direction1 Thickness field, 250
- Direction2 option, 140
- Display Attributes section, 189
- display control
  - display pane, 420, *420*
  - display states
    - activating, 424
    - creating, 422–423, *422–423*
    - mode, 424
    - Model View PropertyManager, 267–268
    - renaming, 423, *424*
    - setting, 421, *421*
    - shade retainers, 309
- Display Filter section, 222
- display mode, 73
- Display Mode column, 66–67, *67*
- Display Mode icon, 422
- display pane, 420, *420*
  - in assemblies, 72–73, *72–73*
  - parts of, 65–68, *66–68*
- Display Reference Triad command, 53
- Display State Name setting, 423
- Display State option, 309
- Display State Properties PropertyManager, 423
- Display State Section, 267–268
- Display Style button, 117
- Display Style section, 268, 270
- displaying. *See* showing
- Distance field, 145
- Do Not Create References To The Model
  - option, 374
- Do Not Show Me Any Dynamic Help option, 4–5
- docking
  - CommandManager, 18–20, *19–20*
  - toolbars, 28

- Document Printer section, 196
- Document Properties dialog box
  - fonts, 192
  - threads, 269
- Document Properties tab, 83–84
  - assembly templates, 493
  - categories, 488–489
  - fonts, 457, 515
  - sheet size, 512
  - standards, 290
  - threads, 222
  - units, 202, 290, 514
- document templates, 82
- Document Templates folder, 151
- document types, 5
- documents
  - properties, 83–85, 84
    - accessing, 487–488, 488
    - assembly templates, 493
    - categories, 488–489
    - fonts, 515
    - saving, 491–492
    - sheet size, 512
    - threads, 222
    - units, 514
  - recovering, 368
  - structure, 50–51, 51
  - units, 83
  - updating, 368–371, 369–371
- Don't Cut All Instances option, 273
- dots (.) in filenames, 50
- downloading drawing templates, 151–152
- Draft Analysis PropertyManager, 239–240
- Draft Analysis tool, 239–240
- Draft Angle setting, 238, 240
- Draft PropertyManager, 237
- Draft tool, 237
- Drafting Standard field, 512
- Drafting Standard option, 489
  - drafting standards
    - selecting, 489
    - setting, 510, 512–513
  - Drafting Standards section, 493, 512
  - drafts for parts, 237–240, 237–239
  - drag handles, 96
  - dragging components, 406
  - Drawing Color section, 196
  - Drawing Commands button, 161, 535
  - Drawing Exchange Format, 473
  - Drawing Interchange Format, 473
  - Drawing Template command, 510
  - drawing templates
    - downloading and installing, 151–152
    - line fonts, 514–516, 515
    - opening, 152–153, 153
    - predefined views, 533–536, 534, 536
    - projection types, 516–517, 516–517
    - revision tables, 536–540, 537
    - saving, 542–543, 543
    - vs. sheet format, 74
    - title blocks. *See* title blocks
    - units, 513–514
- Drawing View Properties window, 451, 451
- Drawing View PropertyManager, 534
  - named views, 452–454, 454–455
  - scales, 269, 450, 450
- drawings, 2
  - annotating. *See* annotations
  - assembly. *See* assembly drawings
  - detached, 198, 469–472, 471
  - FeatureManager design tree in, 77, 78
  - graphics area, 74–75, 75–76
  - notes, 525
  - from parts, 150–151
  - printing, 195–197
  - sharing, 195–198
  - sheet tabs, 76, 77
  - updating, 368–371, 369–371
  - view. *See* views

drill size, 314, *314*  
drilled holes, 310  
DXF file format, 473–474

## E

### edges

filleting, 133, *133*  
lines on, 100–101, *101*  
offsets, 121–122, *122*  
selecting through faces, *141–142, 141–143*  
tangent, 514–515, *515*

Edit 3DSketch mode, 444

Edit Component button, 379, *379*

Edit Feature command, 138–139, *138, 439–441, 439*

Edit Fillet feature, 137–140, *138–140*

Edit menu in PhotoView 360, *547*

Edit Sheet command, 532, *533*

Edit Sheet Format command, 524–525, *525*

Edit Sheet Format mode, 530, *534*

Edit Sketch button, 243

Edit Sketch command, 444

Edit Sketch mode, 366–367, *366, 378–380, 378, 380*

Edit Step command, 440

### editing

appearances, 346–347, *347*  
exploded lines, 444  
exploded views, 439, *439–441*  
fillets, 137–140, *138–140*  
group boxes, 504–505, *505*  
in-context, 372–374  
sheet formats, 524–525, *525*  
title blocks  
    block notes, 525–527, *526–527*  
    block text boxes, 527–530, *527–530*  
    static text, 496–497, *497*

### eDrawings

opening, 482–483, *482–483*  
saving, 472–473

electrical cover, 402–405, *403–404*

electronics cover, 120–122, *122*

Email After Packaging option, 477

Embed Fonts option, 468

Empty Tab command, 24

Enable Symbol When Adding New Revision option, 538

End Cap Style setting, 514

End Condition section, 314

End Condition setting, 106–108, 221–222

### end conditions

counterbores, 126  
extruded cuts, 106–108  
holes, 311–312, 314  
threads, 221–222, 315

### endpoints

arcs, 292  
lines, 293, *293*

Entire Table window, 457

Environment Settings tab

background images, 563, *563*  
floor visibility, 564, *564*  
ground height, 566, *566*

Environments button, 549

Environments window, 556

### errors

mates, 360, *360*  
tooltips, 138

Evaluate tab

assembly visualization, 431, 435  
interference detection, 375, 381

Evaluated Value field, 521

Exclude Fasteners option, 273

Excluded Components/Rib Features option, 273

Exit Isolate button, 381

Exit Sketch mode, 381

- Explode Line Sketch command, 442
  - Explode PropertyManager, 436–441
  - exploded assembly drawings, 448
    - BOMs
      - balloons, 459–461, 460–461
      - filling in, 458–459, 459
      - format updating, 457–458, 457
      - item number reordering, 461–462, 462
      - linking to, 455–456, 455–456
    - isometric views, 448–449
    - named views, 452–454, 453–455
    - sheet scale, 449–451, 450–451
    - showing, 451, 451
  - Exploded View command, 436
  - exploded views, 435. *See also* exploded
    - assembly drawings
      - creating, 435–439, 436–438
      - editing, 439–441, 439–441
      - paths to, 442–445, 442–444
  - Export Options window
    - DXF files, 474
    - eDrawings, 473
    - PDF files, 467–468, 468
  - Export PDF In Color option, 468–469
  - exporting drawings, 473–474
  - Extension Line section, 171
  - extension lines, 163–164, 170–171, 171
  - extensions, file type, 50
  - Exterior Components option, 481
  - External Faces option, 481
  - external files for virtual components, 340–341, 340–341
  - external references, 339, 373–374
  - Extrude PropertyManager
    - bosses, 109
    - cavity, 120, 120
    - shade retainer, 309
    - shaft, 229, 229
  - Extruded Boss/Base command, 95–96, 115, 219, 337
  - Extruded Boss/Base tool, 25, 309
  - Extruded Cut command, 104, 122, 344
  - Extruded Cut icon, 99
  - Extruded Cut tool, 224–225, 228
  - extruded cuts
    - counterbores, 125–127, 126–127
    - defining sketches, 102–104, 102–104
    - mounting holes, 344
    - options, 104–109, 104–109
    - sketches on planar faces, 99–101, 100–102
    - threads, 224–225, 228
  - Extruded Cuts option, 96
  - Extruded PropertyManager, 115, 220
  - extrusions
    - base. *See* base extrusion sketches
    - boss, 110–115, 110–116
    - depth, 105, 105, 120, 120
    - shade, 337–339, 338–339
- ## F
- Face button, 550
  - Face/Plane field, 126
  - faces
    - counterbores, 126
    - drafts, 238–240
    - planar, sketches on, 99–101, 100–102
    - selecting edges through, 141–142, 141–143
  - Faces To Draft field, 238–239
  - Faces To Remove field, 343
  - fasteners, 273, 393
  - Favorite section, 310
  - FeatureManager design tree, 16, 17, 57–58, 58
    - angle mates, 356–358
    - annotations, 59
    - in assemblies, 72–73, 72–74

- base extrusions, 86–87, 87
- BOMs, 420
- with ConfigurationManager, 245–247, 246
- configurations, 354–355
- detached files, 470–471, 471
- display pane, 65–68, 66–68
- display states, 422
- in drawings, 77, 78
- error tooltips in, 138
- exploded views, 437–440
- external references suffixes, 373
- features, 61–64, 62–64
- fillets, 136–137, 136
- filter bar, 58–59
- hidden tree items, 68–69, 68–69
- Instant3D, 366
- mate errors, 360
- materials, 59
- mirroring, 316–317
- new parts in, 336, 336
- origin, 61
- planes, 60–61, 61
- revolved cuts, 224
- rollback bar, 64–65, 65
- sensors, 59
- shade model, 348, 352–353, 352
- shaft, 391–392
- sharing sketches, 303–304, 304–305
- virtual components, 339, 339, 478–479, 478
- features
  - base, 2
  - copying, 395
  - extrusions, 337
  - shelled, 342–343, 343
  - thin, 247, 250–251, 250–251
- Features category, 25
- features (.sldlfp) extension, 395
- Features tab
  - helices, 324
  - holes, 344
  - Instant3D, 366, 366
  - mirroring, 316
  - Shell feature, 343
- Features To Mirror field, 316–317
- File Explorer tab, 11–12, 12
- File Locations section
  - Document Templates folder, 151
  - System Options window, 543
- File Locations tab, 507
- File menu in PhotoView 360, 547
- File Name column header and fields
  - assembly visualization, 433
  - Design Library, 397
  - detached files, 470
  - templates, 542
- file type extensions, 50
- Fillet command, 342
- Fillet PropertyManager, 141–142, 241
- Fillet tool, 132
- fillets, 132
  - edge selection through faces, 141–142, 141–143
  - editing, 137–140, 138–140
  - FilletXpert tool, 132–135, 133–135
  - multiple, 240–242, 241–242
  - reordering features, 135–137, 136–137
  - shade model, 342, 342
  - sketch, 248–249, 249
- FilletXpert tool, 132–135, 133–135, 240–242, 241–242
- filter bar, 58–59
- Final Render button, 549
- Final Render window, 556–558, 557
- final rendering, 556–558, 557
- First Angle projections, 517, 517
- First Reference section, 298
- Fit Text button, 528
- Fit To View tool, 551
- Flat Head Screw With A 82° head option, 311
- Flat Head Screw With A 100° head option, 311

Flat/Nested View button, 432  
 Flat View option, 476, 476  
 flat views  
   assemblies, 432, 432  
   Pack and Go, 476, 476  
 Flatten To Single Folder option, 477  
 Flexible option, 414  
 flexible subassemblies, 412  
   benefits, 412–413  
   description, 352  
   from rigid subassemblies, 413–416,  
     413–416  
 Flip option, 298  
 Flip Dimension option, 357  
 Flip Direction option, 156, 273  
 Flip Side To Cut option, 105, 106  
 flipping  
   arrowheads, 173, 174  
   cutting plane direction, 273  
   offsets, 298  
   section views, 156, 157  
 floating components  
   CommandManager, 18–20, 19  
   moving into assemblies, 255  
   task pane, 10  
   toolbars, 28  
 floor visibility, 563–564, 564  
 Focus Distance field, 567  
 Focus On Mouse button, 567  
 fonts  
   BOMs, 457  
   PDF files, 468  
   revision tables, 539  
   templates, 514–516, 515  
   title blocks, 497, 497, 500, 500  
 footers in PDF files, 468  
 For Construction option, 294  
 Force Assembly Transparency option, 373

formats  
   BOM, updating, 457–458, 457  
   sheet. *See* sheet formats  
 forward slashes (/) in configuration names, 354  
 Frame Style section, 284  
 Front orthographic view, 516–517, 516–517  
 front planes, 60  
 Front view, 54–55, 157–158, 269  
 fully defined sketches, 87–88

## G

Gallery button, 549  
 Gap field, 171  
 gaps  
   extension lines, 171  
   Width mate, 404, 404  
 GB (Guobiao) standards, 513  
 gears in Toolbox, 393  
 generated views, 77, 78  
 geometric tolerance, 528  
 geometric tolerance (.sldgtolstl) extension, 395  
 gestures, mouse, 44–45, 44  
 GOST (Gosudarstvennyy Stardart), 513  
 graphics area, 5, 6, 53, 74  
   annotations, 75, 76  
   origin, 57, 57  
   reference triad, 53–56, 54–56  
   sheet format, 74–75, 75  
   views, 75, 76  
 Green Satin Finish Plastic appearance, 345,  
   345  
 Green Thick Glass button, 558  
 Grid/Snap property, 489  
 ground height, 566  
 group boxes, 504–505, 505  
 Guobiao (GB) standards, 513

**H**

- Hardware folder, 396–397, 397, 399
- hatch patterns, 273
- HDR (high dynamic range) images, 555
- headers in PDF files, 468
- Heads-up View toolbar, 6–7, 6–7
- height
  - ground, 566
  - helices, 320–321
  - rectangles, 93–94, 94
- Height And Pitch option for helices, 320, 322
- Height And Revolution option for helices, 320
- helical paths, 322–323, 323
- Helix/Spiral PropertyManager, 320–322
- Helix/Spiral tool, 320
- Help button, 550
- help customization, 3–5
- Help Customization section, 3–5
- Help menu in PhotoView 360, 548
- hidden components
  - in assemblies, 73
  - lines
    - displaying, 117, 123
    - lamp base, 423
    - section views, 154, 159–161
    - Select Hidden tool, 427
    - shade retainer, 309
  - menu items, 383, 383
  - selecting, 427
  - text boxes, 528–529, 528–529
  - tree items, 68–69, 68–69
- Hidden Lines Removed button, 161, 268, 270, 473
- Hidden Lines Visible command, 117, 423, 427
- Hide/Show Annotations command, 176
- Hide/Show column, 66, 66
- Hide/Show icon, 422
- Hide/Show Tree Items command, 68–69, 68
- hiding
  - BOMs, 419–420
  - dimensions, 175, 175–176
  - menu items, 43, 43
  - menus, 26
  - planes, 60
  - task pane, 9, 9
  - text in CommandManager, 20, 20
  - toolbars, 27–28
- high dynamic range (HDR) images, 555
- High Quality option, 269
- High Quality Lines option, 468
- High Quality PDF option, 197
- Hole button, 311
- Hole Callout button, 165
- Hole Specification PropertyManager, 310–313, 318
- Hole Specifications section, 311
- Hole Type section, 311
- Hole Wizard, 310–313
- Hole Wizard PropertyManager, 310, 313
- holes
  - Hole Wizard, 310–313
  - positions, 312–313
  - power cord
    - chamfers for, 143–146, 143–146
    - circle for, 123–125, 123–125
    - extruded cuts for, 125–127, 126–127
    - through holes for cord, 130–131, 130–131
    - through holes for lamp shaft, 127–129, 128–129
  - shade, 343–344, 344
  - Shade Retainer, 313–315, 313–314
  - types, 310–312
- Horizontal Dimension tool, 95
- Horizontal Ordinate Dimension tool, 95

horizontal split bars, 245–246, 246, 354, 354  
 hotspots, 521–522, 522  
 HSL (Hue, Saturation, Luminance) color values, 560

## I

I Am A New User. Show Quick Tips To Help Me Get Started option, 3  
 I Am New To This Version Of SolidWorks. Show Me Interactive What's New Help option, 3–4  
 IGES format, 473  
 Ignore Multiple Instances option, 283  
 image Quality category, 489  
 Image Quality option, 491  
 Import Options section, 267  
 Import Items Into All Views option, 164, 166–167, 172  
 importing annotations, 164–167, 165–167, 267  
 in-context editing, 372–374  
 in-context models, 335–336, 336–337  
 Inch, Pound, Second (IPS) unit system, 84  
 Include Drawings option, 475  
 Include Items From Hidden Features option, 165  
 increments for on-screen rulers, 97–98, 98  
 Indented option for BOMs, 277–278  
 inference lines, 293, 293  
 inferencing lines, 235  
 injection molding, 237  
 Insert Component PropertyManager, 254  
   mates, 402  
   shade nut, 350  
   subassemblies, 352  
   top-level assemblies, 388–389  
   washers, 331  
 Insert Components command, 388–389  
 Insert Components tool, 254  
 inserting  
   BOMs in assemblies, 416–418, 417  
   components  
   into assemblies, 254, 254  
   into Design Library, 399–401, 400–401  
   subassemblies into assemblies, 351–353, 352–353  
   title blocks, 495–496, 495–496  
   washer subassembly, 331–332, 331, 334, 335  
 Inspection Dimension button, 182  
 installing drawing templates, 151–152  
 Instance/Revolution Count button, 165  
 instances of components, 252–253  
 Instant3D  
   base extrusions, 95–98, 97–98  
   dimension changes with, 365, 365  
   turning on, 64  
 interface, 5  
   CommandManager, 16, 16  
   FeatureManager design tree, 16, 17  
   graphics area, 5, 6  
   Heads-up View toolbar, 6–7, 6–7  
   menu bar, 15–16, 16  
   PhotoView 360, 546, 546  
   status bar, 8–9, 8  
   task pane, 9–14, 9, 11–15  
   toolbars, 16–17, 17  
 interference between components, 374–378, 375–377, 381–382, 381  
 Interference Detection PropertyManager, 375  
 Interference Detection tool, 375, 375, 381  
 International Organization of Standardization (ISO), 511, 513  
 international standards, 393, 512–513  
 Intersection Curve tool, 224–226  
 Intersection Curves PropertyManager, 225, 227  
 IPS (Inch, Pound, Second) unit system, 84  
 ISO (International Organization of Standardization), 511, 513

Isolate command, 379  
 isolating components, 379–380, 380  
 Isometric views, 157, 267, 269, 448–449  
 item channel values, 559  
 Item Numbers section, 278–279  
 Items To Connect setting, 442  
 Items To Fillet section, 133, 342

## J

Japanese Industrial Standards (JIS), 513

## K

Keep Link command, 459  
 keyboard  
   accelerator keys, 37–38, 38  
   shortcuts, 32–37, 36  
 Keyboard tab, 35–36

## L

lamp model  
   appearance, 409–410, 409  
   base  
     BOMs, 459, 459  
     boss extrusions, 110–115, 110–116  
     broken-out sections, 159–161, 160–161  
     center marks, 187–189, 188–189  
     centerlines, 186–187, 187  
     dimensions arrangement, 169–170, 169–170  
     dimensions changes, 365–367, 365–367  
     document updating, 368–371, 369–371  
     exploded views, 438–439, 438–439

  extension lines, 170–171, 171  
   extruded cuts. *See* extruded cuts  
   extrusions. *See* base extrusion sketches  
     opening, 152, 388  
     projected views, 157–159, 158  
     reference dimensions, 183–186, 184–185  
     saving, 153  
     sectioned views, 154–157, 155–157  
   bulb subassembly  
     appearance, 560  
     interference between components, 376, 377  
     selecting from, 425–427, 426–427  
     shade model, 350, 352  
   exploded views, 436–439, 436–439  
   parts from, 481  
   power cord. *See* power cord for lamp  
   rendering. *See* PhotoView 360 application  
   shade. *See* shade model and subassembly  
   shaft, 116–122, 391  
     arcs for, 206–207, 206–207  
     dimension sketches with centerlines, 209–211, 209–211  
     final steps, 228–231, 229–231  
     mates for, 389–392, 389–393  
     mirroring sketches, 211–212, 213  
     revolved cuts, 223–227, 223, 225–228  
     revolving sketches, 217–218, 218  
     sketches for, 202–206, 203–205  
     threaded bosses, 219–222, 220–222  
     through holes for, 127–129, 128–129  
     trimming, 214–216, 214, 217  
 Landscape printing, 196  
 Layer section  
   AutoBalloon PropertyManager, 285–286, 285–286  
   Bill Of Materials PropertyManager, 279  
 Leader Style section, 284

## leaders

- balloons, 284–286, 286
- dimensions, 172–173

## Leaders tab, 172

## Left view, 54–55, 55

## Left Side orthographic view, 516–517, 516–517

## Legacy Hole option, 311

## Length row, 490, 490–491

## license agreement, 3

## lightbulb subassembly

- appearance, 560
- interference between components, 376, 377
- selecting from, 425–427, 426–427
- shade model, 350, 352

## lights, rendering, 560

## Lights directory, 560

## Line command, 100

## Line Conventions and Lettering standard, 514

## line fonts for templates, 514–516, 515

## Line PropertyManager, 294

## line style and weight

- leaders, 284
- PDF files, 469

## lines

- construction lines from, 294–295, 295
- dimension and extension, 163–164, 170–171, 171
- drawing, 205–206
- exploded, 444
- hidden. *See* hidden components
- inference, 293, 293
- inferencing, 235
- section, 272–273, 272
- in sketches, 100–101, 101
- thread relief, 225–226, 226
- transitions between arcs, 291–294, 291–294

## Link Display States To Configurations option, 424

## Link To Property button, 498, 499, 531

## Link To Property window, 499–501, 500, 532, 532

## linking

- BOMs, 455–456, 455–456
- revisions, 530–532, 531–532
- title block text, 497–501, 499–501

## Load Environment Images section, 563

## Load From External File button, 493

## Load Model command, 471

## location

- circles, 113–114, 113–114
- cutouts, 118–119, 119

## Locations tab for title blocks, 496

## Lock/Unlock Note option, 194

## locking notes, 194

## locking nuts, 350–351, 351

## loops, closed, 134, 134

## loss of data prevention, 367–368

**M**

## Machine Design category, 4

## Machine Threads setting, 221, 231, 315

## magnifying glass, 257–258, 257

## Maintain Assembly Transparency option, 373

## major increments for on-screen rulers, 98, 98

## Make Assembly From Part/Assembly command, 252

## Make Drawing From Part/Assembly command, 152

## Make Part From Assembly command, 389

## Make Vertical tool, 115

## Make Virtual command, 478

## manipulators

- exploded views, 436–437, 436
- Rapid Dimension Manipulator, 178, 178, 184–185, 185, 188

- Marked For Drawing button, 165
- Mate command, 348
- Mate PropertyManager
  - Advanced Mates, 402–404, 403
  - angle mates, 357
  - shade model, 348
  - shaft, 389–390
  - tabs, 402
  - washer, 332
- Mate Selections field, 403
- Mate tool, 332
- Mated Entities PropertyManager, 384–385, 385
- Material Properties category, 489
- materials, 59
  - BOMs. *See* bills of materials (BOMs)
  - parts, 259–260
  - PhotoView 360, 553–555, 553–554
  - Polished Brass, 408–409
  - shade model, 345–347, 346
  - title blocks, 191, 501
- mates, 234
  - angle, 356–359, 356–359
  - in assemblies, 73, 74, 255–258, 256–257
  - bearing nut, 400, 400
  - defining, 389–391, 389–391
  - errors, 360, 360
  - folder for, 355, 355
  - modifying, 358–359, 358–359
  - process, 391–392, 392–393
  - shade model, 348–351, 348–349
  - SmartMates, 405–408, 408
  - suppressing, 355–356, 355
  - washer, 332, 332–334
  - Width mate, 401–405, 403–404
- Mates PropertyManager, 258
- Maximum Variance option, 180
- Measure tool, 473
- memory requirements, 3
- menu bar, 15–16, 16
- menus
  - hidden items, 383, 383
  - PhotoView 360, 547–548
  - shortcut, 42–44, 43
  - working with and customizing, 26–27
- Metal directory, 553, 553
- Metal folder, 260
- midpoints
  - centerlines, 204, 204
  - relations, 271–272, 271–272
- minor diameters for threads, 222, 222
- minor increments for on-screen rulers, 98, 98
- minus signs (-)
  - component positions, 255
  - under-defined sketches, 87
- Mirror Entities button, 212
- Mirror Plane/Face option, 316
- Mirror PropertyManager, 212, 316–317, 317
- Mirror tool, 211, 316
- mirroring
  - features, 316–317, 316–317
  - sketches, 211–212, 213
- model dimensions, 163
- Model Items option, 164
- Model Items PropertyManager, 164–167
- Model View command, 264–266, 449
- Model View PropertyManager, 264–266, 265
  - Cosmetic Thread Display section, 269–270, 270
  - Dimension Type section, 269
  - Display State section, 267–268
  - Display Style section, 268
  - Import Options section, 267
  - Options section, 268
  - Orientation section, 266–267, 449, 449
  - Reference Configuration section, 266
  - Scale section, 268–269
- models, 150
  - appearances, 553–555, 553–554
  - in-context, 335–336, 336–337

models (*continued*)

- lamp. *See* lamp model; shade model and subassembly
- opening, 552, 552
- saving, 82
- modifications. *See* changes
- Modify Configurations window
  - angle mates, 359, 359
  - parts, 242–244, 243
- Mold Design category, 4
- Mold Tools tab, 237, 237, 240, 242
- molding, injection, 237
- More Views option, 267
- mounting holes, 343–344, 344
- mouse, 38–39
  - gestures, 44–45, 44
  - right button, 42–44, 43
  - selecting with, 39–41, 40–41
  - for views, 45–46, 45
- moving
  - components in assemblies, 255
  - dimensions between views, 167–168, 168
- multicolor backgrounds, 562–563, 563
- multiple fillets, 240–242, 241–242
- multiuser environments, 382

**N**

- Named View window, 454
- named views, 452–454, 453–455
- names
  - camera views, 561, 561
  - configurations, 244, 245, 354
  - in Design Library, 397
  - detached files, 470
  - display states, 423, 424
  - features, 61
  - printers, 196
  - sheets, 541, 541

- tab controls, 505
- templates, 542
  - in title blocks, 191
  - virtual components, 341, 341
- navigating. *See* interface
- Near Side Countersinks option, 312
- negative drafts, 239–240
- nested views, 432, 432, 476
- networks, sharing templates and sheet
  - formats over, 543
- Neutral Plane option, 237
- neutral planes, 237–239
- New Part command, 335
- New SolidWorks Documents window
  - assembly templates, 252, 388, 493
  - available templates, 543, 543
  - document types, 82
  - drawing templates, 151–153, 153
  - part templates, 487, 487, 492
  - parts, 202
  - subassemblies, 330
  - washers, 234
- New Tab button, 22–23
- No External References button, 374
- No Interference message, 381, 381
- non orthogonal views, 269
- normal sketches, 88
- Note PropertyManager, 526, 526, 532
- notes
  - adding, 192–194, 193
  - title blocks, 522–523, 523, 525–527, 526–527
- notes (.sldnotestl) extension, 395
- Notes PropertyManager, 192–194
- notifications, save, 367–368
- numbers for notes, 193
- nuts
  - adding to assemblies, 399–401, 400–401
  - shade nut, 350–351, 351
  - shaft nut, 143–146, 143–146

**O**

Offset Distance field, 121, 126, *127*

Offset Entities command, 121–122

Offset From Surface option, 126

offsets

edges, 121–122, *122*

reference planes, 298, *298*

surface, 126, *127*

Okay To Measure This eDrawings File option, 473

on-screen rulers, 96–97, *97*, 105, *105*

One-Direction setting, 218

Opaque Assembly option, 372

Open Assembly button, 452

Open File button, 548, 552

Open Image File window, 563

Open Table Template For Bill Of Materials button, 279

Open window

assemblies, 72

BOMs, 279

eDrawings, 483

part models, 52, *52*

opening

assemblies, 71–72

BOMs, 279

drawing templates, 152–153, *153*

eDrawings, 482–483, *482–483*

models, 52, *52*, 552, *552*

parts, 342, *342*

operating systems supported, 2

Optical Properties section, 347

option categories for parts, 488–490

Options section

Add To Library PropertyManager, 398

holes, 312

Model View PropertyManager, 268

Revision Table PropertyManager, 538

Options window

document properties, 488

threads, 222

units, 514

OR search criteria, 430

Ordinate Dimension tool, 95

ordinate dimensions, 95

orientation

displaying, 53

to reference triad, 54

Orientation section

Drawing View PropertyManager, 452, 454, *454–455*, 534

Model View PropertyManager, 266–267, *449*, *449*

Page Setup window, 196

origins

FeatureManager design tree, 61

graphics area, 57, *57*

parallelograms, 91

orthogonal views, 269

orthographic views, 516, *516*

Oval Head option, 311

over-defined sketches, 87

over-defining assemblies, 353, *353*, 360, *360*

Overall Drafting Standard setting, 83, 290, 512

**P**

Pack and Go utility, 474–477, *475–477*

Pack and Go window, 475, *475*

Page Setup window, 196

Pan tool, 551

panes, splitting windows into, 245–246, *246*, *354*, *354*

panning, 46–47

Paper section, 196

paper sizes, 196, 511

- Parallel mate
  - shade model, 349, 353
  - shaft, 392
  - suppressing, 355, 355
- Parallelogram option, 91
- Parameters section
  - Helix/Spiral PropertyManager, 321–322
  - Shell PropertyManager, 343
- parent views, 158
- parentheses () for sketch prefixes, 87
- Part/Assembly To Insert section
  - lamp model, 388
  - shade nut, 350
  - washer, 252, 254, 266, 331
- Part button, 550, 554, 554
- Part Configuration Grouping section, 278
- part files (\*.sldprt), 480
- Part Information setting, 505
- part templates, 486
  - creating, 486–487, 487
  - document properties
    - accessing, 487–488, 488
    - saving, 491–492
  - options, 490–491, 490–491
  - part option categories, 488–490
  - saving, 492–493
- Part Templates (\*.prtdot), 492
- parting lines, 237
- parts
  - anatomy, 52, 52
  - appearance, 258
    - color, 258–259
    - materials, 259–260
    - RealView, 260–262, 261–262
  - from assemblies, 480–481, 481–482
  - configurations
    - configuring, 242–247, 243–246
    - selecting, 253
  - copying, 334
  - drawings from, 150–151
  - opening, 342, 342
  - revolved. *See* revolved parts
- Parts Only option, 277
- paths
  - to exploded views, 442–445, 442–444
  - helical, 322–323, 323
  - swept feature, 299, 300
- PDF (Portable Document Format) files, 197–198, 466–469, 467–468
- Peg-in-hole SmartMate, 406–408, 408
- Perpendicular option, 324, 325
- phantom lines, 514, 515
- PhotoView 360 application, 546
  - appearance properties, 558–560, 559
  - backgrounds, 562–563, 563
  - camera options, 566–567, 567
  - camera views, 560–561, 561
  - creating, 551–552
  - depth of field, 565–567, 566–567
  - environment rotation, 566
  - final rendering, 556–558, 557
  - floor visibility, 563–564, 564
  - ground height, 566
  - lights, 560
  - menus, 547–548
  - models
    - appearances, 553–555, 553–554
    - opening, 552, 552
  - recalling renderings, 564–565, 565
  - scene environment, 555–556
  - toolbars
    - Selection, 550
    - Tasks, 548–550
    - View, 550–551
  - user interface, 546, 546
- pinning task pane, 9, 9

- pitch
  - helices, 323
  - threads, 321
- Pitch And Revolution option, 320
- Pitch field, 323
- placeholder text for tab controls, 506
- planar faces, sketches on, 99–101, 100–102
- Plane Display category, 489
- Plane PropertyManager, 298, 324
- Plane tool, 297
- planes, 60–61, 60
  - neutral, 238–239
  - reference, 297–298, 297–298
- plugs. *See* power cord for lamp
- plus signs (+)
  - BOMs, 280
  - over-defined sketches, 87
- pointers
  - Coincident mates, 405–406
  - Peg-in-hole, 407
- points
  - anchor
    - BOMs, 280–282, 281–282, 456
    - revision tables, 537–538, 537
  - center
    - arcs, 206
    - circles, 111, 111
    - rectangles, 90, 90
  - dimensioning to, 92, 92
- Polished Brass material
  - appearance, 408–409
  - selecting, 260
- Portable Document Format (PDF) files,
  - 197–198, 466–469, 467–468
- Position tab, 312–313
- positioning
  - holes, 312–313
  - shade model, 348–349, 348–349
- positive drafts, 239–240
- power cord for lamp
  - cavity for, 116–117, 117–118
    - cutout location, 118–119, 119
    - cutout process, 119–120, 120
  - holes for
    - chamfers for, 143–146, 143–146
    - circle for, 123–125, 123–125
    - extruded cuts for, 125–127, 126–127
    - through holes for cord, 130–131, 130–131
    - through holes for lamp shaft, 127–129, 128–129
- Power Trim option, 214–215
- precision
  - dimensions, 179, 490, 491
  - units, 84
- predefined views, 533–536, 534, 536
- prefixes
  - sketches, 87–88
  - zip files, 477
- Preview option, 267, 269
- Primary Value section, 378–379
- primary views, 54–55
- Print command, 196
- Print dialog box, 196–197
- Print Header/Footer option, 468
- Print Range setting, 196–197
- Print window, 196
- printing
  - drawings, 195–197
  - keyboard shortcuts, 36–37
- profiles
  - closed spline, 159
  - swept feature, 296, 299–300, 301
- Projected option, 269
- Projected View command, 268
- projected views, 157–159, 158
- projections
  - axonometric, 452
  - templates, 516–517, 516–517

Property Tab Builder program  
 controls, 505–506, 506  
 group boxes, 504–505, 505  
 saving tabs in, 507

PropertyManager, 70, 70, 78–79, 79

\*.prtdot (Part Templates), 492

## Q

quality

images, 489, 491  
 PDF files, 197, 468  
 threads, 269

Quantity column header, 433

question marks (?)

external references, 373  
 sketch prefixes, 87

Quick Tips, 4

## R

radii

circles, 111–112  
 fillets, 133–134, 134, 248–249  
 trimming, 216  
 washers, 240–241

Radius value

fillets, 133, 249  
 washers, 241

random-access memory (RAM)

requirements, 3

Rapid Dimension Manipulator, 178, 178,  
 184–185, 185, 188

RealView graphics, 260–262, 261–262

Reattach Mates command, 384

Recall Last Rendered Image command, 565

recalling

renderings, 564–565, 565  
 saved custom camera views, 561, 562

recent documents thumbnail, 252

recovery, document, 368

rectangles

base extrusions, 88–91, 88–90  
 dimensions, 91–93, 92–93

rectangular coordinate dimensions without  
 dimensions lines, 95

Red, Green, Blue (RGB) color values,  
 559–560

Reference Configuration section, 253, 266

reference dimensions, 163, 179, 183–186,  
 184–185

Reference Geometry button, 324

Reference Geometry flyout, 297

reference planes for swept feature, 297–298,  
 297–298

reference triad, 53–56, 54–56

Referenced Configuration field, 414

references, external, 339, 373–374

Refresh icon, 395

region parameters for helices, 321–322

relations

circle locations, 114  
 midpoints, 271–272, 271–272

relief, thread, 223–227, 223, 225–228

removing tabs, 24–26

Rename Configuration window, 244

renaming

configurations, 244  
 display states, 423, 424  
 features, 61  
 sheets, 541, 541  
 virtual components, 341, 341

Render menu in PhotoView 360, 547

rendering. See PhotoView 360 application

- reordering
  - BOM item numbers, 461–462, 462
  - fillet features, 135–137, 136–137
- Replace Components command, 383
- Replace PropertyManager, 384, 384
- Replace These Component(s) window, 384, 384
- replacing components, 382–385, 383–385
- Reset To Default command, 44
- resizing BOM tables, 419, 419
- Resolution And Scale section, 196
- resolution in image quality, 491, 491
- Results section, 375–376, 381
- Reuse Subassembly Explode button, 440
- Rev box, 530–531
- Reverse Direction button, 106–107, 107, 238, 240, 250
- Reverse Direction option, 322–323
- reverse directions
  - dimension arrows, 173, 174
  - extruded cuts, 106–107, 107
  - helices, 322–323
- Revision Symbol command, 371
- Revision Symbol PropertyManager, 370–371
- revision symbols, 370–371, 370–371
- Revision Table PropertyManager, 538
- revision tables, 536–537
  - anchor points, 537–538, 537
  - inserting, 537–538
  - saving, 539–540
  - updating, 194–195, 195, 369, 369
- revisions. *See* changes
- revolutions for helices, 321
- Revolve Boss/Base tool, 250
- Revolve PropertyManager, 217–218
  - shade mounts base feature, 295–296
  - thin features, 250, 250
  - washers, 236
- Revolve-Thin1 feature, 378
- Revolve tool, 217
- Revolve Type option, 218, 236
- Revolved Boss/Base button, 217
- Revolved Boss/Base feature
  - shade mounts base feature, 295–296, 296
  - washer cover, 247
- revolved parts, 202
  - arcs for, 206–207, 206–207
  - dimension sketches with centerlines, 209–211, 209–211
  - final steps, 228–231, 229–231
  - mirroring sketches, 211–212, 213
  - revolved cuts, 223–227, 223, 225–228
  - revolving sketches, 217–218, 218
  - sketches for, 202–206, 203–205
  - threaded bosses, 219–222, 220–222
  - trimming, 214–216, 214, 217
- revolved thin features, 250–251, 250–251
- revolving sketches, 217–218, 218
- RGB (Red, Green, Blue) color values, 559–560
- ribbon-style menus, 26
- Right alignment button, 460
- right mouse button, 42–44, 43
- right planes, 60
- Right view, 54–55, 157–158, 269
- Right Side orthographic view, 516–517, 516–517
- Rigid option, 414
- rigid subassemblies, 352, 412–416, 413–416
- rollback bar, 64–65, 65, 434, 434
- Rotate tool, 551
- rotation
  - environment, 566
  - models, 551
  - views, 45–46, 45, 54–56, 54–56
- Route Line PropertyManager, 442–444
- rulers, on-screen, 96–97, 97, 105, 105

**S**

- Satin Finish command, 345, 345
- Save As Copy option
  - detached files, 470
  - virtual components, 478
- Save As Type field
  - detached files, 470
  - DXF files, 474
  - eDrawings, 472
  - part templates, 492
  - rendering, 557
- Save As window
  - assembly templates, 494
  - detached drawings, 198
  - document settings, 492
  - DXF files, 474
  - eDrawings, 473
  - models, 82
  - part templates, 492
  - PDF files, 197, 467, 469
  - templates, 542
  - virtual components, 341, 341, 478–479, 480
  - zip files, 477
- Save Auto-Recovery Info command, 368
- Save Custom View command, 560
- Save Externally (Specify Paths) option, 340
- Save Image window, 556
- Save Internally option, 479
- Save Modified Documents window, 340, 340, 479, 479
- Save Notifications, 367–368
- Save Properties window, 541, 542
- Save Shaded Data in Drawings option, 473
- Save Sheet Format window, 541, 541
- Save SolidWorks Properties Template window, 507
- Save To External File option, 492
- Save To Folder option, 476
- Save To Zip File option, 477
- Save Type As field, 542
- saved custom camera views, 561, 562
- saved standards for assembly templates, 493–494
- saving
  - assembly templates, 494
  - camera views, 560–561, 561
  - changes, 367–368
  - custom property tabs, 507, 507
  - Design Library items, 397–398, 398
  - detached files, 198, 470
  - DXF files, 474
  - eDrawings, 472–473
  - models, 82
  - modified document settings, 491–492
  - part templates, 492–493
  - PDF files, 197, 467, 469
  - renderings, 557
  - revision tables, 539–540
  - sheet formats, 540–541, 541–542
  - templates, 542–543, 543
  - title blocks, 502–503, 503
  - virtual components, 340–341, 340–341, 478–479, 480
  - zip files, 477
- scalable assemblies, 51
- Scale section
  - Drawing View PropertyManager, 450, 450
  - Model View PropertyManager, 268–270
- scene environment rendering, 555–556
- scroll wheel, 39
  - magnifying glass, 257
  - for zooming, 46–47
- Search Assistant, 12
- search criteria, 430
- Search tab, 12–13, 13
- section lines, 272–273, 272
- Section PropertyManager, 273–274

- Section View PropertyManager, 156–157, 256, 257
- Section View window, 272–274, 273
- section views, 154–157, 155–157, 271–275, 271–275
- sections, broken-out, 159–161, 160–161
- Select Another Property field, 433
- Select button, 39
- Select Hidden tool, 427
- Select Internal Components tool, 429
- Select Mated To tool, 428–429, 428
- Select/Replace button, 476
- Select Suppress tool, 428
- Select Through Faces option, 141
- Select tool in PhotoView 360, 550
- Select Toolbox tool, 429
- Selected Components section, 375
- selecting
  - commands, 44
  - edges through faces, 141–142, 141–143
  - with mouse, 39–41, 40–41
  - part configurations, 253
- Selection section, 384, 384
- Selection toolbar, 550
- selection tools for assemblies, 425, 425
  - advanced, 429–430
  - Select Hidden, 427
  - Select Internal Components, 429
  - Select Mated To, 428–429, 428
  - Select Suppress, 428
  - Select Toolbox, 429
  - Volume Select tool, 425–427, 426–427
- sensors, 59, 69
- Set Anchor command, 280, 456, 537
- Set Origin On Curve option, 324
- Settings button, 549
- Settings window
  - background images, 563, 563
  - depth of field, 565–566
  - floor visibility, 564, 564
  - ground height, 566, 566
- shade model and subassembly
  - appearances, 344–347, 345–347
  - configurations
    - adding, 353–355, 353–355
    - switching between, 359–360, 359–360
  - creating, 330–331
  - exploded views, 439–445, 439–444
  - extruding, 337–339, 338–339
  - fillets, 342, 342
  - flexible, 413–416, 413–416
  - holes, 343–344, 344
  - in-context modeling, 335–336, 336–337
  - inserting into assemblies, 351–353, 352–353
  - interference between components, 376, 377
  - mates
    - angle, 356–357, 356–357
    - modifying, 358–359, 358–359
    - suppressing, 355–356, 355
  - parts opening, 342, 342
  - Peg-in-hole SmartMate, 407–408, 408
  - positioning, 348–349, 348–349
  - shade mounts base feature, 290–291
    - construction lines from lines, 294–295, 295
    - revolved feature, 295–296, 296
    - swept feature. *See* swept feature
    - transition between lines and arcs, 291–294, 291–294
  - shade nut, 350–351, 351
  - shade retainers, 305–307, 306–307
    - completing, 309–310
    - cosmetic threads, 315, 316
    - fully defining, 308, 308–309
    - holes, 313–315, 313–314
  - shelled features, 342–343, 343
  - virtual components, 340–341, 340–341
  - washer, 331–335, 331–335, 349–350, 350

- Shaded And Draft Quality HLR/HLV Resolution section, 491
- Shaded Cosmetic Thread option, 222
- Shaft, Lamp part. *See* lamp model
- shaft nuts, 143–146, *143–146*
- sharing
  - detached drawings for, 469–472, *471*
  - drawings, 195–198
  - eDrawings for
    - opening, 482–483, *482–483*
    - saving, 472–473
  - exporting for, 473–474
  - Pack and Go for, 474–477, *475–477*
  - parts from assemblies, 480–481, *481–482*
  - PDFs for, 466–469, *467–468*
  - selection tools for, 428–429, *428*
  - sketches, 303–304, *304–305*
  - templates and sheet formats, 543
  - virtual components for, 478–480, *478–480*
- sheet formats
  - editing, 524–525, *525*
  - graphics area, 74–75, *75*
  - saving, 540–541, *541–542*
  - sharing, 543
- Sheet Properties window
  - projection types, 517, *517*
  - sheet scale, 450
  - sheet size, 510, *511*
- sheet scale adjustments, 449–451, *450–451*
- sheet size setting, 510–512, *511*
- sheet tabs, 76, *77*
- sheet templates, 524
- Shell command, 343
- Shell PropertyManager, 343
- shelled features, 342–343, *343*
- Shift key for dimensions, 130–131, *131*
- shortcut keys, 32
  - adding and changing, 34–36, *36*
  - default, 32–34
  - printing, 36–37
- shortcut menus, 42–44, *43*
- shortcut toolbar
  - accessing, 28–31, *29–30*
  - displaying, 88, *88*
- Show Configuration command, 359, *359*
- Show Excluded Fasteners option, 273
- Show Floor option, 564
- Show Folders For field, 151
- Show/Hide Value Bars button, 431
- Show In Exploded State option, 451, *451*
- Show On Custom Tab button, 505, *506*
- Show On Selection option, 32
- Show On Shortcut Menu option, 32
- Show Table command, 420
- showing
  - BOMs, 419–420
  - dimensions, 176, *177*
  - hidden lines, 117
  - hidden menu items, 383, *383*
  - planes, 60
  - toolbars, 27–28
- shown components in assemblies, 73
- Single Center Mark option, 188
- size
  - BOM tables, 419, *419*
  - circles, 112
  - holes, 314, *314*
  - paper, 196, 511
  - sheet, 510–512, *511*
  - thread, 221–222, *221*
  - toolbars, 31
- Size field, 314
- Size label, 196
- Sketch Fillet command, 299
- Sketch Fillet PropertyManager, 248–249, 299
- Sketch Fillet tool, 248
- sketch fillets, 248–249, *249*
- Sketch tab, 212
- Sketch tool, 89

- sketches, 2, 63, 64
  - base extrusions
    - creating, 85–87, 87
    - defining, 91–94, 92–94
    - Instant3D, 95–98, 97–98
    - prefixes, 87–88
    - rectangles for, 88–91, 88–90
  - extruded cuts, 102–104, 102–104
  - mirroring, 211–212, 213
  - on planar faces, 99–101, 100–102
  - revolved parts, 202–206, 203–205
  - revolving, 217–218, 218
  - sharing, 303–304, 304–305
  - swept feature from, 301–302, 302
  - threads, 323–325, 324–326
  - transition between lines and arcs in, 291–294, 291–294
- slashes (/) in configuration names, 354
- .sldblk (blocks) extension, 395
- .sldgtolstl (geometric tolerance) extension, 395
- .sldlfp (features) extension, 395
- .sldnotestl (notes) extension, 395
- .sldprt (part files) extension, 480
- .sldfstl (surface finish symbols) extension, 395
- .sldweldstl (weld symbols) extension, 395
- Smart Dimension mode, 103
- Smart Dimension tool, 91
  - circles, 112–113, 112
  - overview, 94–95
- SmartMates, 405
  - Peg-in-hole, 406–408, 408
  - types, 405–406
- snapping to on-screen ruler increments, 98, 98
- Socket Countersunk Head Cap Screw
  - option, 311
- solid line type, 515, 515
- SolidWorks Content, 393
- SolidWorks License Agreement, 3
- SolidWorks Options window, 3
- SolidWorks Professional and Premium for Toolbox, 393
- SolidWorks Resources tab, 10, 11
- sorting visualization components, 433, 434
- Source/Destination section, 164
- Specify Path button, 341
- Specular Color property, 559
- Spiral option, 320
- spirals for helices, 320–321
- splines, 159
- Split tool, 25
- Standard Views section, 267
- standards, 393
  - saved, 493–494
  - selecting, 489
  - setting, 510, 512–513
- Start Angle setting, 322
- states, display
  - activating, 424
  - creating, 422–423, 422–423
  - mode, 424
  - renaming, 423, 424
  - setting, 421, 421
- static text in title blocks, 496–497, 497
- status bar, 8–9, 8
- Straight Pipe Tapped Hole option, 311
- Straight Tap button, 311
- Style section for balloons, 283
- Style setting for lines, 514
- Style window for tolerance, 182
- subassemblies, 51, 51, 234
  - copying, 334
  - inserting into assemblies, 351–353, 352–353
  - rigid and flexible, 352, 412–416, 413–416
  - washer covers, 251–253
- suffixes
  - external references, 373–374
  - zip files, 477

Summary Information window for  
 properties, 499–501, *499*, *501*  
 revision numbers, 531–532, *532*  
 title block, 519–521, *519–521*  
 suppressing mates, 355–356, *355*  
 surface finish symbols (.sldsfstl), extension, 395  
 Sweep PropertyManager, 301–302  
 Swept Boss/Base button, 301  
 Swept Cut tool, 304, 326  
 swept feature, 296  
 paths, 299, 300  
 profile sketches, 300, 301  
 reference planes, 297–298, *297–298*  
 from sketches, 301–302, *302*  
 swept cut feature, 302–304, *303–305*  
 switching between configurations, 244–245,  
*245*, 359–360, *359–360*  
 symbols  
 parts, 252  
 revision, 370–371, *370–371*  
 symmetric tolerance for dimensions,  
 179–180, *180*  
 System-defined properties for title blocks, 518  
 system-generated values, linking properties  
 to, 500–501, *501*  
 System Options tab and window, 12  
 document properties, 488  
 document recovery, 368  
 Document Templates folder, 151  
 external references, 374  
 in-context editing, 372  
 line fonts, 515  
 reference triad, 53  
 Save Notifications, 368  
 tabs, 507  
 templates, 543  
 title blocks, 496  
 tree item visibility, 69, *69*

system properties  
 file locations, 151  
 linking title block text to, 497–498  
 System Properties window, 151

## T

tab components, 402  
 Tab Selections field, 402, 404  
 Table Position section  
 Bill Of Materials PropertyManager, 277, 456  
 Revision Table PropertyManager, 538  
 Table Template section, 277, 417  
 tables  
 BOMs, 276–277, 418–419, *418–419*  
 fonts, 457  
 revision. *See* revision tables  
 Tables tab, 457  
 tabs  
 adding, 22–23, *22*  
 CommandManager, 21, *21*  
 creating, 23–24  
 custom, 503–507, *504–507*  
 tools in, 24–26  
 Tangent Arc tool, 206–207, *207*  
 tangent edges, 514–515, *515*  
 Tangent Edges command, 515  
 Tangent Edges With Font command, 454, 516  
 Taper Helix section, 322  
 Tapered Tap button, 311  
 Tapped Hole option, 311  
 tapped holes, 310–311  
 task pane, 9–10, *9*  
 Appearances/Scenes tab, 14, *15*  
 Custom Properties tab, 14, *15*  
 Design Library tab, 10, *11*  
 File Explorer tab, 11–12, *12*  
 Search tab, 12–13, *13*

- SolidWorks Resources tab, 10, 11
- View Palette tab, 13–14, 14
- Tasks toolbar in PhotoView 360, 548–550
- templates
  - assembly, 493–494
  - BOMs, 276–277
  - custom property tabs, 503–507, 504–507
  - document, 82
  - drawing. *See* drawing templates
  - parts. *See* part templates
  - sharing, 543
  - sheet formats, 540–541, 541–542
  - sheet size, 510–512, 511
  - tabs, 503–507, 504–507
  - title blocks. *See* title blocks
- text
  - CommandManager, 20, 20
  - tab controls, 505–506
  - title blocks, 522–524, 523–524
    - editing, 496–497, 497
    - linking, 497–501, 499–501
    - text boxes, 527–530, 527–530
- Text Fields area, 522–523, 523
- Thick Gloss directory, 558
- thickness
  - lines, 514
  - wall, 118, 119
  - washer covers, 250
- Thickness setting, 514
- thin features
  - description, 247
  - revolved, 250–251, 250–251
- Third Angle projection type, 516, 516
- Thread Options option, 312
- thread relief, 223–227, 223, 225–228
- threaded bosses, 219–222, 220–222
- threaded feature
  - helical paths, 322–323, 323
  - Helix/Spiral PropertyManager, 320–322
    - modeling, 319–320, 320
- threaded shafts, 305
- threads
  - cosmetic, 219–221, 220, 230
    - settings, 269–270, 270
    - shade retainer, 315, 316
  - cutting, 326–328, 327
  - diameters, 231
  - sketches, 323–325, 324–326
- 3 Point Arc tool, 206–207, 208
- 3 Point Blue environment, 565
- 3 Point Center Rectangle option, 90
- 3 Point Corner Rectangle option, 90–91
- 3D Content Central website, 393
- 3D sketches for holes, 312–313
- 3D space, 255
- Through All end condition, 108, 108, 230, 344
- through holes
  - lamp shaft, 127–129, 128–129
  - power cords, 130–131, 130–131
- thumbnails for recent documents, 252
- Tile Horizontally command, 406
- Tile Vertically command, 406
- Title Block Manager, 190–191, 191, 521–522, 522
- Title Block Table command, 495
- Title Block Table PropertyManager, 496
- title blocks, 494, 518
  - filling out, 190–191, 191
  - finishing, 501–502
  - inserting, 495–496, 495–496
  - saving, 502–503, 503
- templates
  - custom properties, 518–521, 519–520
  - managing, 521–524, 522–524
  - notes, 522–523, 523, 525–527, 526–527
  - revision letters, 530–532, 531–532

title blocks (*continued*)  
 sheet formats, 524–525, 525  
 text boxes, 527–530, 527–530  
 text  
 editing, 496–497, 497  
 linking, 497–501, 499–501  
 tolerance blocks, 528, 528  
 tolerance for dimensions, 179–183, 180–183  
 Tolerance Type setting, 179–180  
 toolbars, 16–17, 17, 27  
 CommandManager, 22–23, 22–23  
 context, 31–32, 31  
 eDrawings, 483, 483  
 hiding and showing, 27–28  
 PhotoView 360, 548–552  
 shortcut, 28–31, 29–30, 88  
 Toolbox, 393–395  
 tooltips for errors, 138  
 top-down design, 71, 372  
 top-level assemblies  
 creating, 388–389  
 Design Library components in, 399–401, 400–401  
 exploded. *See* exploded assembly drawings  
 mates  
 defining, 389–391, 389–391  
 process, 391–392, 392–393  
 SmartMates, 405–408, 408  
 Width mate, 401–405, 403–404  
 Top-Level Only option, 280, 417  
 top planes, 60  
 Top view, 54–55, 157, 267, 269  
 Top orthographic view, 516–517, 516–517  
 Total Weight column, 433  
 transitions, 291–294, 291–294, 306, 306  
 transparency  
 adding, 347  
 in assemblies, 73  
 description, 67–68, 68  
 in-context editing, 372–373

Transparent Color property, 560  
 triads  
 exploded views, 436–437, 436–437  
 reference, 53–56, 54–56  
 Trim tool, 214  
 Trim Away Inside tool, 215  
 Trim Away Outside tool, 215  
 Trim PropertyManager, 214–216  
 Trim To Closest option, 215, 226  
 Trimetric view, 267, 269, 452  
 trimming revolved parts, 214–216, 214, 217  
 trims for thread relief, 226, 226–227  
 True option for views, 269  
 Type field  
 tab controls, 505  
 threads, 221  
 Type Of Draft section, 237  
 Type Of Edge section, 515  
 Type Of Projection section, 517  
 Type tab for holes, 310–312

## U

under-defined sketches, 87  
 Unit Precision settings, 179  
 Unit System option, 290  
 Unit System section, 490  
 Unit System setting, 514  
 units  
 documents, 83–84, 290  
 precision, 179  
 templates, 489–490, 513–514  
 Units options, 489  
 Up To Next end condition, 109, 109  
 cosmetic threads, 315  
 extruded cuts, 230  
 Up To Surface end condition, 108, 109  
 updating  
 BOM format, 457–458, 457

- components, 364–365
- drawing documents, 368–371, 369–371
- revision tables, 194–195, 195, 369, 369, 540
- Use Custom Properties From section, 532
- Use Dimension Placement In Sketch option, 165
- Use Document Defaults option, 189
- Use Document Display option, 284
- Use Document Font button, 457, 457, 500, 500, 539
- Use Document Font option, 192
- Use Document Settings option, 279, 539
- Use Large Buttons With Text option, 20
- Use Reflective Floor option, 564
- Use Shadow Floor option, 564
- Use Sheet Scale option, 268, 270, 450
- Use Specified Printer Line Weights option, 469
- user interface. *See* interface

## V

- Value field, 505
- Value/Text Expression field
  - revision numbers, 531
  - title block properties, 520–521
- Variable Pitch setting for helices, 321
- Vertical Dimension tool, 95
- Vertical Ordinate Dimension tool, 95
- View Layout tab, 271
- View Mate Errors window, 360, 360
- View menu in PhotoView 360, 547
- View Orientation flyout, 454
- View Origins option, 57
- View Palette tab, 13–14, 14
- View toolbar in PhotoView 360, 550–551
- views, 154, 264–265, 265
  - camera, 560–561, 561
  - detailed, 161–162, 162
  - drawings, 75, 76

- exploded, 435
  - creating, 435–439, 436–438
  - editing, 439–441, 439–441
  - paths to, 442–445, 442–444
- generated, 77, 78
- isometric, 448–449
- Model View PropertyManager. *See* Model View PropertyManager
- mouse for, 45–46, 45
- moving dimensions between, 167–168, 168
- named, 452–454, 453–455
- nested, 476
- orthographic, 516, 516
- predefined, 533–536, 534, 536
- primary, 54–55
- projected, 157–159, 158
- rotating, 45–46, 45, 54–56, 54–56
- section, 271–275, 271–275
- sectioned, 154–157, 155–157
- virtual components
  - overview, 339–340
  - saving, 340–341, 340–341
  - virtualizing, 478–480, 478–480
- visibility. *See also* hidden components; hiding
  - floor, 563–564, 564
  - hidden tree items, 68–69, 68–69
- Visibility section, 564
- visualization, assembly, 430–435, 431–432, 434
- Volume Select tool, 425–427, 426–427

## W

- wall thickness for cutouts, 118, 119
- washer covers, 247, 248
  - changes, 378–379, 378–379
  - configurations, 253
  - inserting into assemblies, 254, 254

washer covers (*continued*)  
materials, 259–260  
mates, 255–258, 256–257  
moving into assemblies, 255  
RealView, 260–262, 261–262  
revolved thin features, 250–251, 250–251  
sketch fillets, 248–249, 249  
subassemblies for, 251–253  
washer model and subassembly, 234–236,  
235–236  
changes, 379–381, 380  
color, 258–259  
configurations, 242–247, 243–246  
drafts, 237–240, 237–239  
fillets, 240–242, 241–242  
inserting, 331–332, 331, 334, 335  
mates, 332, 332–334  
section views, 271–275, 271–275  
shade model, 349–350, 350  
Welcome To SolidWorks window, 3–4  
weld symbols (.sldweldstl) extension, 395  
What’s New manual, 4  
Width mate, 401–405, 403–404  
width of rectangles, 93, 93  
wiring. *See* power cord for lamp  
Witness/Leader Display section, 172  
workflow customization, 3–5  
Workflow Customization section, 4–5

## X

x-axes and x direction  
3D space, 255  
origins, 57  
reference triad, 53

## Y

y-axes and y direction  
3D space, 255  
origins, 57  
reference triad, 53

## Z

z-axes and z direction  
3D space, 255  
origins, 57  
reference triad, 53  
zip files, 477  
Zoom To Area button, 154, 275  
Zoom tool, 551  
Zoom Window tool, 551  
zooming  
magnifying glass, 257  
PhotoView 360, 551  
scroll wheel for, 46–47  
section views, 275