

Index

• *Symbols and Numerics* •

< > (angled brackets), 37
' (apostrophe), 38
[] (square brackets), 37
_ (underscore), 38
2D Drafting & Annotation, 21
2D Wireframe visual style, 225
3D Modeling workspace
 files, starting new, 22
 Layers control panel, 221
 Lens Length/Field of View slider, 224
 Lights control panel, 222
 Materials control panel, 222
 overview, 21
 parallel projection, 225
 Render control panel, 222
 3D Make control panel, 221–222
 3D Navigate control panel, 222, 224
 Visual Styles control panel, 222
3D object creation
 conceptual visual style, 226
 Dashboard interface controls, 220–224
 edge settings, 227
 navigation, 228–229
 new file creation, 218–220
 online resources, 232
 parallel projection, 225, 231
 perspective projection, 231
 realistic visual style, 226
 solid and surface modeling techniques, 232
 specialized areas, 217
 3D Make control panel, 221–222
 3D Navigate control panel, 222, 224
 3DORBIT model, 229–232
 views, 228–229

• *A* •

A (ARC) command, 143, 154
absolute coordinates, 131

Accept button, 67
accuracy versus precision, 129
ACI (AutoCAD Color Index), 119
action parameters, blocks, 351–352
adaptive grid, grid and snap interval
 setup, 96
Add Scales to Object dialog box, 247
add-ons, Autodesk, 13
aliases, keyboard shortcuts, 7, 34
aligned dimensions, 267
All Programs command (Start menu), 51
All selection option, 174
Ambrosius, Lee
 *AutoCAD and AutoCAD LT All-In-One Desk
 Reference For Dummies*, 27, 222
 *AutoCAD 2008 3D Modeling Workbook For
 Dummies*, 217
Anchor Bolts layer, 60–61
anchoring Dashboard interface, 58–59, 222
angled brackets (< >), 37
angles, arc, 157
angular dimensions, 267
angular units and precision settings
 drawing setup procedures, 91
 system variables, 88
Annotation Object Scale dialog box, 247
Annotation Scales drop-down list, 30
annotation scaling settings, 88
Annotation Visibility button, 30
annotations, text, 237, 246–248
annotative dimensions, 269, 276–277,
 280–281
annotative hatching, 298–300
annotative objects
 drawing setup procedures, 97
 new features, 17–18
apostrophe ('), 38
applications, version compatibility, 16
AR (ARRAY) command, 65–67, 177, 188–189
ARC (A) command, 143, 154
Architectural units of measure, 80

- arcs
 - angles, 157
 - center point, 157
 - circular, 150–151
 - dimensions, 283
 - elliptical, 159
 - endpoints, 157–158
 - second point, 157–158
 - start point, 157
 - area selections, 174
 - ARRAY (AR) command, 65–67, 177, 188–189
 - Array button (Modify toolbar), 65
 - ARRAY dialog box, 188
 - arrays
 - polar, 188
 - rectangular, 65–67, 188–189
 - arrows, dimensions, 266, 274–275
 - ARX (AutoCAD Runtime), 16
 - Associated Standards File button, 31
 - associative dimensions, 267, 285
 - attribute definitions, blocks, 339, 343–345
 - attribute values, blocks, 346–347
 - authoring, blocks, 334, 352
 - AutoCAD
 - advantages of, 12–13
 - AutoCAD LT comparisons/differences, 15–16
 - early versions, 11
 - growth of, 1
 - installation, 18
 - minimum system requirements, 2–3, 16–17
 - operating system compatibility, 11–12
 - overview, 3–4
 - starting, 51
 - AutoCAD and AutoCAD LT All-In-One Desk Reference For Dummies* (Ambrosius and Byrnes), 27, 222
 - AutoCAD Classic workspace
 - files, starting new, 22
 - opening screen, 23
 - overview, 21
 - AutoCAD Color Index (ACI), 119
 - AutoCAD LT, 15–16
 - AutoCAD Runtime (ARX), 16
 - AutoCAD 2008 3D Modeling Workbook For Dummies* (Ambrosius), 217
 - Autodesk
 - add-ons, 13
 - DWF Viewer utility, 380–381
 - general discussion, 2
 - Autodesk Impression toolbar, 21
 - AutoLISP (LSP) programs, 16
 - automatic update feature, xrefs, 356
 - Automatically Add Scales button, 30
- **B** •
- background masking, 252
 - backups, 388
 - balloon notification, plotting, 75
 - base points, 179, 337–338
 - BEDIT command, 342
 - binding xrefs, 360
 - bitmap (BMP) files, 362, 394
 - block definitions
 - attribute definition, 339
 - base points, 337–338
 - block redefinition, 337, 341
 - creation, 336–339
 - defined, 333
 - descriptions, 339
 - insert units, 338
 - named objects, 125
 - object selection, 338
 - unused, purging, 347–348
 - Block Editor tool, 342
 - blocks
 - action parameters, 351–352
 - advantages of, 335–336
 - attribute definitions, 343–345
 - attribute values, 346–347
 - authoring, 334, 352
 - block inserts, exploding, 347
 - custom grips, 353–354
 - defined, 333
 - dynamic, 334, 348–351
 - editing, 353–354
 - fill-in-the-blank text fields, 342–346
 - inserting, 334, 340–342
 - parameter markers, 352
 - raster image files, 334, 362–365
 - rotation parameters, 352

- tables, 334
 - visibility states, 348–351
 - when to use, 362
 - xrefs (external references), 334, 355–359
 - BMP (bitmap) files, 362, 394
 - boundary specification, hatching, 300–301
 - boxes, crossing, 68–70
 - BREAK (BR) command, 159, 177, 193–194
 - building plans, drawing scales, 82
 - bulleted lists, 254–256
 - buttons
 - Accept, 67
 - Annotation Visibility, 30
 - Array (Modify toolbar), 65
 - Associated Standards File, 31
 - Automatically Add Scales, 30
 - Cancel, 67
 - Clean Screen, 31
 - Close, 24
 - Communication Center, 25
 - Dock, 58–59
 - DUCS (Dynamic User Coordinate System), 29
 - DYN (Dynamic Input), 29
 - Favorites (DesignCenter palette), 129
 - GRID, 28
 - Hatch (Draw toolbar), 71
 - Load (DesignCenter palette), 127
 - Lock/Unlock Toolbar Palette Positions, 31
 - LWT (Lineweight), 29
 - Manage Xrefs, 31
 - Maximize Viewport, 30
 - Maximize/Restore, 24
 - Minimize, 24
 - Minimize Viewport, 30
 - MODEL/PAPER, 29–30
 - Modify, 67
 - New Layer, 55
 - Offset (Modify toolbar), 59
 - ORTHO, 28, 63, 131
 - OSNAP (Object Snap), 29, 63, 131
 - OTRACK (Object Snap Tracking), 29, 131
 - POLAR, 28
 - Properties (Standard toolbar), 112
 - Restore, 24
 - SNAP, 28, 131
 - Status Bar Menu, 31
 - Stretch (Modify toolbar), 68
 - title bar, 24
 - Trusted Autodesk DWG, 31
 - Byrnes, David (*AutoCAD and AutoCAD LT All-In-One Desk Reference For Dummies*), 27, 222
- C •
- C (CIRCLE) command, 60–61, 154–156
 - Cancel button, 67
 - cancel key (Esc key), 37
 - Cartesian coordinates, 131–132
 - cartoon sketches, drawing setup
 - procedures, 87
 - cells, table, 259–260
 - center points
 - arcs, 157
 - circles, 155–156
 - ellipses, 159
 - polygons, 153
 - CHAMFER (CHA) command, 177, 194–195
 - child drawings, 355
 - CIRCLE (C) command, 60–61, 154–156
 - circles
 - center point, 155–156
 - filled, 162
 - radius, 156
 - circular arcs, 150–151
 - Circumscribed option, 62
 - Clean Screen button, 31
 - clipping
 - raster image files, 364
 - xrefs, 361
 - Close button, 24
 - closing
 - Dashboard interface, 223
 - toolbars, 26
 - clouds, 163–164
 - CO (COPY) command, 176, 179, 182
 - color plotting, 74
 - color property, 115
 - Color Table (CTB) styles, 317–318
 - color-based plotting, 114
 - color-dependent plot styles, 316–317

colors

- HSL (Hue Saturation Luminance) option, 119

- layer, 55–56, 119

- plotting, 323–324

- RGB (Red Green Blue) option, 119

- Select Color dialog box, 55–56, 119

column layers, 55–56

Column Offset option, 67

columns

- dynamic, 256–257

- order of, 123

- static, 256–257

- table, 260–261

command line

- blank line indication, 37

- dynamic input system, 19, 32–33

- as primary communication, 33

command window

- default location, 38

- errors, prompts, and warning messages, 33–34

- recently used commands, 38

- right-clicking in, 38

command-first editing, 168

command-first selection options, 173–174

commands

- activating, 37

- aliases, 7

- All Programs (Start menu), 51

- ARC (A), 143, 154

- ARRAY (AR), 65–67, 177, 188–189

- BEDIT, 342

- BREAK (BR), 159, 177, 193–194

- CHAMFER (CHA), 177, 194–195

- CIRCLE (C), 60–61, 143, 154–156

- COPY (CO), 176, 179, 182

- COPYBASE, 183

- COPYCLIP, 182

- CUTCLIP, 182

- DDEDIT, 284

- DIMARC, 283

- DIMBREAK, 18, 281

- DIMDISASSOCIATE, 285

- dimension, 268–269, 281

- DIMINSPECT, 282

- DIMJOGLINE, 282

- DIMREASSOCIATE, 285

- DIMREGEN, 285

- DIMSCALE, 98–99

- DIMSPACE, 18, 282

- DIMSTYLE, 125

- DLINE (DL), 152

- DONUT (D), 143, 155, 162

- Drawing Limits (Format menu), 53

- DRAWORDER, 252

- DTEXT, 244–246

- EATEDIT, 346

- editing, 176–177

- ELLIPSE (EL), 143, 154, 159

- ERASE (E), 174–176

- ETRANSMIT, 370–371

- EXPLODE (X), 148, 177, 386

- EXTEND (EX), 177, 191–192

- FILLET (FI), 58–59, 177, 194–195

- how to enter, 7

- JOIN (J), 177, 195–196

- JPGOUT, 394

- keyboard shortcuts, 34–36

- LATLOCKFADECTL, 124

- LAYER, 125

- LAYERSTATES, 123

- LAYISO, 124

- LAYOUTWIZARD, 100

- LENGTHEN (LEN), 177

- LIMITS, 93

- LINE (L), 36, 132, 142, 144–145

- LINETYPE, 125

- LTSCALE, 98–99

- MIRROR (MI), 177

- MLEADER, 286

- MLEADERALIGN, 288–289

- MLEADERCOLLECT, 288–289

- MLEADEREDIT, 288

- MLEADERSTYLE, 288

- MLINE, 152

- MOVE (M), 177, 179–180

- MSPACE, 104

- MTEXT, 244–246, 248–249

- MVIEW, 104

- New (File menu), 22, 51, 89, 219

- OFFSET (O), 58, 177, 189–190

- Open (File menu), 22

- PASTEBLOCK, 183

- PASTECLIP, 182–183

- PASTEORIG, 183

- PDMODE, 166
- PDSIZE, 166
- PEDIT, 148
- PLINE (PL), 142, 144, 147–149
- PNGOUT, 394
- POINT (PO), 143, 166
- POLYGON (POL), 61–62, 142, 145, 153
- PSPACE, 104
- publishing, 378–380
- PURGE, 347
- QNEW, 89, 107
- RAY, 142, 145
- recalling, 38
- recently used, 38
- RECTANG (REC), 57, 143, 145, 152
- REFEDIT, 359
- REGENALL, 216
- REGENAUTO, 216
- rerunning, 38
- REVLOUD, 143, 155, 163–164
- ROTATE (RO), 177, 186–187
- Save As (File menu), 6, 16, 105
- SCALE (SC), 177, 187–188
- SCALETEXT, 188
- selecting, 34
- SETBYLAYER, 117
- SETBYLAYERMODE, 117
- SETBYLEADER, 18
- SPLINE (SPL), 143, 155, 160–161
- STRETCH (S), 68–70, 177, 179, 183
- TABLESTYLE, 258
- text, 236
- TEXTTOFRONT, 252
- TIFOUT, 394
- tooltips, 144
- transparent, 38
- TRIM (TR), 159, 177, 191–192
- Units (Format menu), 91
- VIEW, 210–211
- VPMAX, 215
- VPMIN, 215
- WBLOCK, 358
- XLINE (XL), 142, 145
- XOPEN, 358
- ZOOM, 64, 93
- Zoom (View menu), 54, 71
- Communication Center button, 25
- compiled shape (SHX) fonts, 239
- conceptual visual style, 3D object creation, 226
- connected lines, 152
- construction lines, 145
- content pane (DesignCenter palette), 126
- Contents tab, 46–47
- control panels, Dashboard interface, 32
- coordinate entry technique, precision practices, 130–133
- coordinates
 - absolute, 131
 - Cartesian, 131–132
 - grid and snap interval setup, 96
 - locations, viewing, 132
 - polar, 132
 - relative, 57, 131
- COPY (CO) command, 176, 179, 182
- COPYBASE command, 183
- COPYCLIP command, 182
- copying
 - between drawings, 182
 - hatch properties, 295
 - layers between drawings, 128–129
 - layouts, 103
 - named objects, 127
 - objects, 182, 201–202
 - tables, 262
- corner points
 - rectangles, 152
 - rounded corners, 58
- CP/M operating system, 11–12
- CPolygon selection option, 174
- Create Layout Wizard feature, 100–102
- Create New Visual Style dialog box, 227
- crosshairs coordinates, 28
- crosshatching, 70–71
- crossing boxes, 68–70
- crossing object selection, 171–172
- Crossing selection option, 174
- CTB (Color Table) styles, 317–318
- curved segments, polylines, 148, 150–151
- custom fonts, 239
- custom grips, 353–354
- Custom installation option, 18
- customizing
 - Dashboard interface, 32
 - toolbars, 27
- CUTCLIP command, 182

• D •

- D (DONUT) command, 143, 155, 162
- Dashboard interface
 - anchoring, 58–59, 222
 - closing, 223
 - control panels, 32
 - customizing, 32
 - Layer Properties Manager button, 55
 - opening, 223
 - overview, 31–32
 - 3D object creation controls, 220–224
 - toolbars, 32
 - workspace features, 17
- dash-dot patterns, 97–98
- dashed rectangles, 68
- data extraction, tables, 262
- data sharing features, 4–5
- dbConnect palette, 42
- DC Online tab (DesignCenter palette), 127
- DDEDIT command, 284
- Decimal units of measure, 80
- deleting layouts, 103
- descriptions
 - block definitions, 339
 - layer, 121
- Design Web Format. *See also* Internet features
 - Autodesk DWF Viewer utility, 380–381
- digital signatures, 381
 - as exchange format, 392
 - general discussion, 365–366, 376
 - password protection, 381–382
 - plotting scenarios, 376–377
 - publishing commands, 378–380
- DesignCenter palette
 - content pane, 126
 - DC Online tab, 127
 - description of, 42, 125
 - Favorites button, 129
 - features, 126
 - Folders tab, 126
 - History tab, 127
 - Load button, 127
 - named objects, copying, 127
 - Open Drawings tab, 126
 - opening, 127
 - tree view pane, 126
- detaching xrefs, 360
- device configuration, plotting, 305–306
- dialog boxes
 - Add Scales to Object, 247
 - Annotation Object Scale, 247
 - ARRAY, 188
 - Create New Visual Style, 227
 - Dimension Style Manager, 272
 - Drafting Settings, 53, 95–96
 - Drawing Properties, 99
 - Drawing Units, 91–92
 - Find and Replace, 258
 - Hatch and Gradient, 70–71, 292–294
 - Insert Table, 260
 - Layer Properties Manager, 118
 - LineType Manager, 98
 - Lineweight, 121
 - Migrate Settings, 24
 - New Dimension Style, 273
 - New Table Style, 259
 - New View, 210–211
 - Plot, 73–74, 326–327
 - Plot Scale Confirm, 74–75
 - Plotter Configuration Editor, 326
 - Point Style, 165–166
 - Reference Manager, 374–375
 - Save As, 105
 - Save Drawing As, 54, 105
 - Select Color, 55–56, 119
 - Select Linetype, 120
 - Select Template, 22, 52, 219
 - Template Options, 107
 - Text Style, 240
 - View Manager, 210–211
 - View Transitions, 210
- diameter, layer, 61
- diazoblueline machines, 304
- digital signatures, DWF, 381
- DIMARC command, 283
- DIMBREAK command, 18, 281
- DIMDISASSOCIATE command, 285
- Dimension Style Manager dialog box, 272
- dimensions
 - aligned, 267
 - angular, 267
 - annotative, 269, 276–277, 280–281
 - arc, 283
 - arrows, 266, 274–275

- associative, 267, 285
- commands, 18, 268–269, 281
- discussed, 263
- editing, 283–285
- exploded, 267
- extension lines, 266
- geometric tolerances, 277–278
- linear, 267, 278–280
- lines, 265–266, 274–275
- multileaders, 286–289
- origins, 278
- overriding, 283
- primary units, 277
- radial, 267
- scale settings, 88, 97–99
- side-by-side, 281–282
- styles, 269–273
- substyles, 273
- terminology, 264
- text, 265, 275, 284
- traditional, 265
- variables, 269
- DIMINSPECT dimension, 282
- DIMJOGLINE dimension, 282
- DIMREASSOCIATE command, 285
- DIMREGEN command, 285
- DIMSCALE command, 98–99
- DIMSPACE command, 18, 282
- DIMSTYLE command, 125
- direct distance entry technique, precision
 - practices, 130, 138
- direct manipulation editing, 168
- displacement method, 179
- display area, plotting, 327
- DLINE (DL) command, 152
- Dock button, 58–59
- DONUT (D) command, 143, 155, 162
- double lines, 152
- double-floating point precision, 215
- drafting practice, 49–51
- Drafting Settings dialog box, 53, 95–96
- Draw Order toolbar, 26
- Draw toolbar
 - description and location of, 26
 - Hatch button, 71
- drawing area
 - clicking in, 41
 - efficient use of, 41
 - layout tabs, 39
 - Model tab, 39
 - right-clicking in, 41
- Drawing Exchange Format (DXF), 392
- drawing limit settings, 88, 92–93
- Drawing Limits command (Format menu), 53
- Drawing Properties dialog box, 99
- drawing scales
 - appropriate selection importance, 386
 - description and uses of, 82
 - drawing scale factor versus, 82
 - drawing setup procedures, 81–83
 - text height, 242–243
- drawing setup procedures
 - annotative objects, 97
 - cartoon sketches, 87
 - dimension scale settings, 97–99
 - drawing limit settings, 92–93
 - drawing properties, entering, 99
 - drawing scale selection, 81–83
 - grid and snap interval setup, 94–97
 - layouts, 100–104
 - linetype scale settings, 97–99
 - model space, 90–94
 - overview, 77
 - reasons for, 78–79
 - sheet size considerations, 83–87
 - sketches, 87
 - system variables, 87–88
 - template drawings, 88–90
 - units of measure, 79–81, 91–92
- Drawing Units dialog box, 91–92
- drawings
 - child, 355
 - copying between, 182
 - copying layers between, 128–129
 - corner points, 57–58
 - drafting practice, 49–51
 - grid dots, 54
 - hexagonal shapes, 61–63
 - in imperial units, 52
 - layer creation, 55–57
 - in metric units, 52
 - naming, 54
 - new blank drawing, 52
 - parent, 355
 - previewing, 67
 - printed, 72–75

- drawings (*continued*)
 - proper setup importance, 50
 - reusing, 79
 - rounded corners, 58
 - saving as template, 105
 - saving often, 387–388
 - scale factors, 53
 - simple setup, 51–54
 - sketches, 87
 - system variables saved in, 45
 - DRAWORDER command, 252
 - DTEXT command, 244–246
 - DUCS (Dynamic User Coordinate System)
 - button, 29
 - DWF (Design Web Format). *See also*
 - Internet features
 - Autodesk DWF Viewer utility, 380–381
 - digital signatures, 381
 - as exchange format, 392
 - general discussion, 365–366, 376
 - password protection, 381–382
 - plotting scenarios, 376–377
 - publishing commands, 378–380
 - DWG file formats
 - as exchange format, 390–391
 - general discussion, 13
 - new features, 16
 - version compatibility, 14–16
 - DXF (Drawing Exchange Format), 392
 - dynamic blocks, 334, 348–351
 - dynamic columns, 256–257
 - Dynamic Input (DYN) button, 29
 - dynamic input system
 - command line, 19, 32–33
 - tooltips, 33
 - warnings, 35
 - Dynamic User Coordinate System (DUCS)
 - button, 29
- E •**
- E (ERASE) command, 174–176
 - early versions of AutoCAD, 11
 - EATEDIT command, 346
 - edge settings, 3D object creation, 227
 - editing
 - ARRAY command, 65–67
 - base points, 179
 - blocks, 353–354
 - command-first, 168
 - commands, 176–177
 - crosshatching, 70–71
 - dimensions, 283–285
 - direct manipulation, 168
 - displacement method, 179
 - grip, 148, 162, 168, 197–198
 - hatch patterns, 302
 - how to, 67
 - noun-verb, 168
 - offset distance, 189–190
 - precision practices, 178
 - selection settings, 169
 - selection-first, 168
 - STRETCH command, 68–70
 - tables, 260–262
 - text, 257–258
 - verb-noun, 168
 - xrefs (external references), 358–359
 - efficiency advantages, AutoCAD use, 12
 - ELLIPSE (EL) command, 143, 154, 159
 - ellipses, 159
 - elliptical arcs, 159
 - e-mail, sending and receiving files, 369–370
 - endpoints
 - arcs, 157–158
 - grips, 199
 - lines, 146
 - splines, 161
 - Engineering units of measure, 80
 - ERASE (E) command, 174–176
 - errors
 - command window messages, 33–34
 - lack of precision problems, 129
 - Esc key (cancel key), 37
 - ETTRANSMIT command, 370–371
 - EX (EXTEND) command, 177, 191–192
 - exchange formats
 - BMP files, 394
 - DWF files, 392
 - DWG files, 390–391
 - DXF files, 392
 - general discussion, 389
 - JPEG files, 394–395
 - OLE feature, 395–397
 - PDF files, 392–393
 - recommended formats, 390

round-trip transfer, 391
 RTF files, 398
 screen capture, 397–398
 TIFF files, 394–395
 TXT files, 398
 Windows Clipboard, 395
 WMF files, 393
 EXPLODE (X) command, 148, 177, 386
 exploded dimensions, 267
 exploding block inserts, 347
 Express Tools, 18
 EXTEND (EX) command, 177, 191–192
 extending objects, 191–192
 extension lines, 266
 extents area, plotting, 327
 external references (xrefs)
 advantages of, 355–356
 attaching, 356–358
 automatic update features, 356
 binding, 360
 blocks, 355–359
 child/parent drawings, 355
 clipping, 361
 detaching, 360
 discussed, 334
 editing, 358–359
 file creation, 358–359
 full path settings, 359–360
 maintenance, 360–361
 opening, 361
 overlays, 358
 relative path settings, 360
 reloading, 360
 unloading, 360
 views, switching between, 360
 when to use, 361
 External References palette
 description of, 42
 new features, 17

● **F** ●

fading layers, 124
 Favorites button (DesignCenter palette), 129
 Fence selection option, 174
 FI (FILLET) command, 58–59, 177, 194–195
 file conversion warnings, 15

file creation, xrefs, 358–359
 File menu
 New command, 22, 51, 89, 219
 Open command, 22
 Save As command, 6, 16, 105
 file size considerations, raster image files,
 365
 File Transfer Protocol (FTP), 369–370, 373
 files, plotting to, 327
 filled circles, 162
 FILLET (FI) command, 58–59, 177, 194–195
 fill-in-the-blank text fields, blocks, 342–346
 filters, layer, 124
 Find and Replace dialog box, 258
 Folders tab (DesignCenter palette), 126
 fonts
 custom, 239
 SHX (compiled shape), 239
 TTF (TrueType), 238–239
 Format menu
 Drawing Limits command, 53
 Units command, 91
 Fractional units of measure, 80
 freezing layers, 123
 FTP (File Transfer Protocol), 369–370, 373
 full path settings, xrefs, 359–360

● **G** ●

geometric tolerances, 277–278
 grid and snap interval setup, 94–97
 GRID button, 28
 grid dots, 54
 grid spacing and visibility settings, 88
 grip editing, 148, 162, 168, 197–198
 grips
 defined, 197
 end points, 199
 as visible object snaps, 197–200
 grosser precision setting, 92
 group filters, layers, 124

● **H** ●

hard-copy output. *See* plotting
 Hatch and Gradient dialog box, 70–71,
 292–294

Hatch button (Draw toolbar), 71
 hatching
 annotative, 298–300
 boundary specification, 300–301
 hatch palettes, 302
 hatch patterns, editing, 302
 overuse warning, 292
 overview, 291
 pick points method, 293–294
 predefined hatch patterns, 295–296
 properties, copying, 295
 scaling, 298
 user-defined hatches, 296, 298
 height, text, 242–243
 help options
 Communication Center button, 25
 Contents tab, 46–47
 Help menu, 46–47
 InfoCenter feature, 25
 new features, 25
 New Features Workshop option, 46, 232
 newsgroup-based discussion groups, 46
 online resources, 46–47
 Product Support option, 46
 hexagonal shapes, 61–63
 hiding layer objects, 123
 History tab (DesignCenter palette), 127
 hot spots, 94
 house plans, drawing scales, 82–83
 HSL (Hue Saturation Luminance) color
 option, 119
 hyperlinks, 380

• I •

imperial units of measure, 52, 79, 81
 implied windowing, 171
 importing tables, 262
 inches, units of measure, 133
 infinite lines, 145
 InfoCenter feature, 25
 In-Place Text Editor, 250–251
 Inscribed option, 62
 insert fields, text, 252–253
 Insert Table dialog box, 260
 insert units, block definitions, 338
 inserting blocks, 340–342

insertion point, tables, 260
 installing AutoCAD, 18
 Internet features. *See also* DWF
 ETTRANSMIT command, 370–371
 FTP (File Transfer Protocol), 369–370, 373
 general discussion, 367
 hyperlinks, 380
 list of, 368–369
 rapid transmission, 371–372
 sending and receiving files, 369–370
 isometric views, 228–229

• J •

jitter edges, 227
 JOIN (J) command, 177, 195–196
 joining objects, 195–196
 JPEG files, 394–395
 JPGOUT command, 394
 justification options, text, 243–244

• K •

keyboard shortcuts
 aliases, 7, 34
 commands, 34–36
 Esc key (cancel key), 37

• L •

L (LINE) command, 36, 132, 142, 144–145
 large building plans, drawing scales, 82
 Last selection option, 174
 LAYER command, 125
 Layer Properties Manager dialog box, 118
 layers
 Anchor Bolts, 60–61
 colors, 55–56, 119
 column, 55–56
 column order, rearranging, 123
 controlling object properties by, 115–117
 copying between drawings, 128–129
 creating new, 118–122
 current layer display, 112–114, 122
 descriptions, 121
 diameter, 61
 fading, 124

- filters, 124
- freezing, 123
- group filters, 124
- hiding objects in, 123
- linetype name, 120
- lineweight, 121
- locking/unlocking, 123
- named objects, 125
- naming, 55, 118
- new features, 18
- New Layer button, 55
- Plate, 57
- properties, 112–115
- property filters, 124
- selecting, 57
- state, 123
- turning on/off, 123
- Layers control panel (3D Modeling workspace), 221
- Layers toolbar, 26
- LAYERSTATES command, 123
- LAYISO command, 124
- LAYLOCKFADECTL command, 124
- layout tabs, 39
- layouts
 - copying, 103
 - creation, 100–102
 - deleting, 103
 - drawing setup procedures, 100–104
 - moving, 104
 - named objects, 125
 - orientation, 102
 - panning, 212–215
 - paper size, 102
 - paper space, 100–102, 212
 - plotter setup, 101
 - plotting, 312–315
 - renaming, 103
 - sheet sets, 104
 - title blocks, 102
 - viewport arrangement, 102
 - zooming, 212–215
- LAYOUTWIZARD command, 100
- leaders
 - multileaders, 286–289
 - old-style, 285–286
- LENGTHEN (LEN) command, 177
- Lens Length/Field of View slider (3D Modeling workspace), 224
- Leonhard, Woody (*Windows Vista Timesaving Techniques For Dummies*), 397
- Lights control panel (3D Modeling workspace), 222
- LIMITS command, 93
- LINE (L) command, 36, 132, 142, 144–145
- linear dimensions, 267, 278–280
- linear units and precision settings
 - drawing setup procedures, 91
 - system variables, 88
- lines
 - AutoCAD discussion, 4
 - connected, 152
 - construction, 145
 - dimensions, 265–266, 274–275
 - double, 152
 - endpoints, 146
 - extension, 266
 - infinite, 145
 - multilines, 152
 - parallel, 152
 - polylines, 147–151
 - precision practices, 146
 - semi-infinite, 145
 - stretching, 184–185
- LINETYPE command, 125
- LineType Manager dialog box, 98
- linetype name, layer, 120
- linetype property, 115
- linetypes
 - loading, 122
 - named objects, 125
 - scale settings, 88, 97–99
 - Select Linetype dialog box, 120
- Lineweight (LWT) button, 29
- Lineweight dialog box, 121
- lineweight property, 115
- lineweights
 - layer creation, 121
 - plotting, 321–323
- Load button (DesignCenter palette), 127
- location points, 164
- locking layers, 123
- Lock/Unlock Toolbar Palette Positions button, 31

LSP (AutoLISP) programs, 16
 LTSCALE command, 98–99
 LWT (Lineweight) button, 29

• M •

M (MOVE) command, 177, 179–180
 magnifying glass cursor, 65
 maintenance

- raster image files, 364–365
- xrefs, 360–361

 Manage Xrefs button, 31
 Markup Set Manager palette, 42
 matching properties, 202
 Materials control panel (3D Modeling workspace), 222
 Maximize Viewport button, 30
 Maximize/Restore button, 24
 maximizing

- screen space, 39
- windows, 24

 MBUTTONPAN variable, 207
 MEASUREMENT system variable, 81
 memory, minimum system requirements, 16–17
 menu bar features, 25
 metric units of measure, 52, 81
 Migrate Settings dialog box, 24
 migration custom settings, 24
 Minimize button, 24
 Minimize Viewport button, 30
 minimum system requirements, 2–3, 16–17
 MIRROR (MI) command, 177
 MLEADER command, 286
 MLEADERALIGN command, 288–289
 MLEADERCOLLECT command, 288–289
 MLEADEREDIT command, 288
 MLEADERSTYLE command, 288
 MLINE command, 152
 model space

- description of, 30, 39
- drawing setup procedures, 90–94
- example, 40
- full screen model space, returning to, 52
- limits, resetting, 53
- plotting, 307–310

 Model tab, 39
 modeless dialog boxes. *See* palettes

MODEL/PAPER button, 29–30
 modifiability advantages, AutoCAD use, 12
 Modify button, 67
 Modify toolbar

- Array button, 65
- description and location of, 26
- Offset button, 59
- Stretch button, 68

 monochrome dithering, 323
 monochrome plotting, 74, 307–310
 MOVE (M) command, 177, 179–180
 moving

- layouts, 104
- objects, 180–181, 200–201
- toolbars, 26

 MS-DOS operating system, 12
 MSPACE command, 104
 MTEXT command, 244–246, 248–249
 multileaders

- dimensions, 286–289
- new features, 18
- styles, 288–289

 multiline text, 248–252
 multilines, 152
 MVIEW command, 104

• N •

named objects, 124–125, 127
 named plot styles, 316–317
 named views, 210–211
 naming

- drawings, 54
- layers, 55, 118
- templates, 106

 navigation, 3D object creation, 228–229
 New command (File menu), 22, 51, 89, 219
 New Dimension Style dialog box, 273
 new features

- annotative objects, 17–18
- AutoCAD discussion, 6
- dimension commands, 18
- DWG file formats, 16
- External References palette, 17
- help options, 25
- layers, 18
- multileaders, 18
- workspaces, 17

- New Features Workshop help option, 46, 232
 - New Layer button, 55
 - New Table Style dialog box, 259
 - New View dialog box, 210–211
 - newsgroup-based discussion groups, 46
 - non-system drivers, 304
 - noun-verb editing, 168
 - numbered lists, 254–256
 - NURBS (NonUniform Relational B-Spline)
 - curves, 160
- 0 ●**
- O (OFFSET) command, 58, 177, 189–190
 - Object Linking and Embedding (OLE), 395–397
 - object points, 164–165
 - Object Snap (OSNAP) button, 29, 63, 131
 - object snap overrides technique, precision practices, 130, 133–135
 - Object Snap Tracking (OTRACK) button, 29, 131
 - object snap tracking technique, precision practices, 130
 - Object zooming option, 209
 - objects
 - block definitions, 338
 - color property, 115–116
 - controlling object properties by, 115
 - copying, 182, 201–202
 - creating from existing, 65–67
 - extending, 191–192
 - joining, 195–196
 - linetype property, 115
 - lineweight property, 115–116
 - moving, 180–181, 200–201
 - named, 124–125
 - one-by-one selections, 170–171
 - plot style property, 115
 - properties, 115–117
 - rotating, 186–187
 - scaling, 187–188
 - splitting, 193–194
 - stretching, 183–186, 202–204
 - trimming, 191–192
 - OFFSET (O) command, 58, 177, 189–190
 - offset, plotting, 329
 - Offset button (Modify toolbar), 59
 - offset distance, 189–190
 - OLE (Object Linking and Embedding), 395–397
 - one-by-one selections, 170–171
 - online resources
 - as help option, 46–47
 - 3D object creation, 232
 - Open command (File menu), 22
 - Open Drawings tab (DesignCenter palette), 126
 - opening
 - Dashboard interface, 223
 - toolbars, 26
 - xrefs, 361
 - opening screen
 - appearance of, changing, 20
 - AutoCAD Classic workspace, 23
 - operating systems, AutoCAD compatible, 11–12
 - orientation, layouts, 102
 - origins, dimensions, 278
 - ORTHO button, 28, 63, 131
 - ortho technique, precision practices, 130, 138
 - orthographic views, 228–229
 - OSNAP (Object Snap) button, 29, 63, 131
 - OTRACK (Object Snap Tracking) button, 29, 131
 - overhanging edges, 227
 - overlays, xrefs, 358
 - overriding dimensions, 283
- p ●**
- page setups, plotting, 324–325
 - palettes
 - accessing, 42
 - dbConnect, 42
 - DesignCenter, 42, 125–128
 - discussed, 41
 - example of, 43
 - External References, 42
 - hatch, 302
 - Markup Set Manager, 42
 - Properties, 42, 112
 - QuickCalc, 42
 - Sheet Set Manager, 42
 - tools, 42
 - Visual Styles Manager, 226–227

- panning
 - how to, 64–65
 - layouts, 212–215
 - MBUTTONPAN variable, 207
 - real-time, 205–207
 - reasons for, 64
 - using scroll wheel, 207
 - zooming, 205
- paper size
 - layouts, 102
 - plotting, 73–74
 - sheet size considerations, 83–87
- Paper size option (Plot dialog box), 73
- paper source layout, 30
- paper space
 - active space between, switching, 104–105
 - description of, 39
 - efficient use, 386
 - example, 40
 - layouts, 100–102, 212
- paragraph text, 243
- parallel lines, 152
- parallel projection, 3D object creation,
 - 225, 231
- parameter markers, blocks, 352
- parent drawings, 355
- password protection, DWF, 381–382
- PASTEBLOCK command, 183
- PASTECLIP command, 182–183
- PASTEORIG command, 183
- PDF (Portable Document Format), 392–393
- PDMODE command, 166
- PDSIZE command, 166
- PEDIT command, 148
- perspective projection, 3D object creation,
 - 231
- PGP (Program Parameters) file, 34
- pick points method, hatching, 293–294
- plan details, drawing scales, 82–83
- Plate layer, 57
- PLINE (PL) command, 142, 144, 147–149
- Plot dialog box, 73–74, 326–327
- Plot Scale Confirm dialog box, 74–75
- plot style properties, 115
- Plotter Configuration Editor dialog box, 326
- plotter setup, layouts, 101
- plotting
 - area specification, 327
 - balloon notification, 75
 - color-based, 114
 - color-dependent plot styles, 316–317
 - colors, 74, 323–324
 - CTB (Color Table) styles, 317–318
 - defined, 303
 - device configuration, 305–306
 - display area, 327
 - DWF (Design Web Format), 376–377
 - extents area, 327
 - to files, 327
 - general discussion, 4
 - layouts, 312–315
 - lineweights, 321–323
 - model space, 307–310
 - monochrome, 74, 307–310
 - named plot styles, 316–317
 - offset, 329
 - overview, 72
 - page setups, 324–325
 - paper size, 73–74
 - plot stamp, 327
 - plot style tables, 74
 - previewing, 74, 310–311
 - printable area, 74
 - rotation, 329
 - to scale, 311–312
 - shaded viewports, 329
 - sheet sets, 328
 - simple drawing example, 307–310
 - STB (Style Table) styles, 317–318
 - styles, 316–320
 - troubleshooting, 329–330
 - window area, 327
- PNGOUT command, 394
- POINT (PO) command, 143, 166
- Point Style dialog box, 165–166
- points
 - base, 179, 337–338
 - defined, 164
 - location, 164
 - object, 164–165
- polar arrays, 188
- POLAR button, 28, 131
- polar coordinates, 132
- polar snap technique, precision practices,
 - 131, 138–139
- polar tracking technique, precision practices, 131, 138

- POLYGON (POL) command, 61–62, 142, 145, 153
- polygons
 center point, 153
 radius, 154
- polylines
 circular arcs, 150–151
 connecting lines with, 147–151
 converting to collection of line and arc segments, 148
 curved segments, 148, 150–151
 end-to-end single lines, 152
 grip editing, 148
 PEDIT command, 148
 straight segments, 149–150
 width, 148
- Portable Document Format (PDF), 392–393
- precision
 versus accuracy, 129
 AutoCAD advantages, 12
 coordinate entry technique, 130–133
 direct distance entry technique, 130, 138
 double-floating point, 215
 editing, 178
 importance of, 129–130, 385
 lack of precision problems, 129
 lines, 146
 of measurement, 80
 object snap overrides technique, 130, 133–135
 object snap tracking technique, 130
 ortho technique, 130, 138
 polar snap technique, 131, 138–139
 polar tracking technique, 131, 138
 running object snaps technique, 130, 136–137
 snap spacing settings, 138
 snap technique, 130
 temporary overrides, 139
- predefined hatch patterns, 295–296
- preparation and setup. *See* drawing setup procedures
- previewing
 drawings, 67
 plotting, 74, 310–311
- Previous selection option, 174
- Previous zooming option, 209
- primary units, dimensions, 277
- printable area, plotting, 74
- printed drawings, 72–75
- printer drivers, 304–306
- Printer/Plotter option (Plot dialog box), 73
- Product Support help option, 46
- Program Parameters (PGP) file, 34
- prompts, command window, 33–34
- properties
 color, 115–116
 current property display, 112–114
 discussed, 111
 layer, 112–115
 linetype, 115
 lineweight, 115–116
 matching, 202
 object, 115–117
 plot style, 115
- Properties button (Standard toolbar), 112
- Properties palette
 description of, 42
 toggling on/off, 112
- Properties toolbar, 26
- property filters, layers, 124
- PSPACE command, 104
- publishing commands, 378–380
- PURGE command, 347
- purging unused block definitions, 347
- *Q* •
- QNEW command, 89, 107
- QuickCalc palette, 42
- *R* •
- radial dimensions, 267
- radius
 circles, 156
 polygons, 154
- rapid transmission, Internet features, 371–372
- raster image files
 attaching, 363–364
 blocks, 334, 362–365
 clipping, 364
 description of, 334
 file size considerations, 365
 maintenance, 364–365

- raster image files (*continued*)
 - uses for, 336
 - vector images, 362
 - RAY command, 142, 145
 - realistic visual style, 3D object creation, 226
 - real-time panning, 205–207
 - real-time zooming, 206–207, 209
 - recalling commands, 38
 - receiving and sending files, Internet
 - features, 369–370
 - recently used commands, 38
 - RECTANG (REC) command, 57, 143, 145, 152
 - rectangles
 - corner points, 152
 - dashed, 68
 - size, 153
 - rectangular arrays, 65–67, 188–189
 - Red Green Blue (RGB) color option, 119
 - REFEDIT command, 359
 - Reference Manager dialog box, 374–375
 - REGENALL command, 216
 - REGENAUTO command, 216
 - regeneration, 215–216
 - relative coordinates, 57, 131
 - relative path settings, xrefs, 360
 - reloading xrefs, 360
 - renaming layouts, 103
 - Render control panel (3D Modeling
 - workspace), 222
 - rerunning commands, 38
 - resolution, minimum system
 - requirements, 16
 - Restore button, 24
 - restoring
 - named views, 211
 - windows, 24
 - reusing drawings, 79
 - REVCLOUD command, 143, 155, 163–164
 - RGB (Red Green Blue) color option, 119
 - Rich Text Format (RTF), 398
 - right-clicking
 - in command window, 38
 - in drawing area, 41
 - rollover highlighting, 174
 - ROTATE (RO) command, 177, 186–187
 - rotation
 - ellipses, 159
 - object, 186–187
 - plotting, 329
 - rotation parameters, blocks, 352
 - rounded corners, 58
 - round-trip transfer, exchange formats, 391
 - Row Offset option, 67
 - rows, table, 260–261
 - RTF (Rich Text Format), 398
 - running object snaps technique, precision
 - practices, 130, 136–137
- S •
- S (STRETCH) command, 68–70, 177, 179, 183
 - Save As command (File menu), 6, 16, 105
 - Save As dialog box, 105
 - Save Drawing As dialog box, 54, 105
 - SAVETIME system variable, 43
 - saving drawings
 - frequent saves, 387–388
 - as template, 105
 - SCALE (SC) command, 177, 187–188
 - scale factors, 53, 311–312
 - SCALETEXT command, 188
 - scaling
 - hatch patterns, 298
 - objects, 187–188
 - Scientific units of measure, 80
 - screen capture, 397–398
 - screen space, maximizing, 39
 - scroll bars, 208
 - scroll wheel, panning and zooming using,
 - 207
 - second points
 - arcs, 157–158
 - splines, 161
 - Select Color dialog box, 55–56, 119
 - Select Linetype dialog box, 120
 - Select Template dialog box, 22, 52, 219
 - selection-first editing, 168
 - selections, object
 - ALL option, 174
 - area selections, 174
 - command-first options, 173–174
 - CPolygon option, 174
 - crossing object selection, 171–172
 - Crossing option, 174
 - Fence option, 174
 - implied windowing, 171

- Last option, 174
- one-by-one, 170–171
- Previous option, 174
- rollover highlighting, 174
- selection preview features, 174
- window object selection, 171–172
- Window option, 174
- WPolygon option, 174
- semi-infinite lines, 145
- sending and receiving files, Internet features, 369–370
- SETBYLAYER command, 117
- SETBYLAYERMODE command, 117
- SETBYLEADER command, 18
- setup and preparation. *See* drawing setup procedures
- shaded viewports, 329
- shared features, 4–5
- Sheet Set Manager palette, 42
- sheet sets, 104, 328
- sheet size
 - calculating, 85
 - dimensions, 84–85
 - drawing setup procedures, 83–87
 - extra drawing space, 85–86
- SHX (compiled shape) fonts, 239
- SI (System International) units of measure, 80
- side-by-side dimensions, 281–282
- single-line text, 243
- size, rectangle, 153
- sketches, drawing setup procedures, 87
- smooth view transitions, 209–210
- snap and grid interval setup, 94–97
- Snap and Grid tab, 53–54
- SNAP button, 28, 131
- snap spacing settings, 88, 138
- snap technique, precision practices, 130
- solid and surface modeling techniques, 232
- SPLINE (SPL) command, 143, 155, 160–161
- splines
 - end point, 161
 - freeform curves, 160–161
 - grip editing, 162
 - NURBS (NonUniform Relational B-Spline) curves, 160
 - second point, 161
 - start point, 161
 - splitting objects, 193–194
- square brackets ([]), 37
- Standard toolbar
 - description and location of, 25
 - Properties button, 112
- standards, consistent use, 386
- start points
 - arcs, 157
 - splines, 161
- starting AutoCAD, 51
- state, layer, 123
- static columns, 256–257
- status bar
 - Annotation Scales drop-down list, 30
 - Annotation Visibility button, 30
 - Associated Standards File button, 31
 - Automatically Add Scales button, 30
 - Clean Screen button, 31
 - crosshairs coordinates, 28
 - DUCS (Dynamic User Coordinate System) button, 29
 - DYN (Dynamic Input) button, 29
 - GRID button, 28
 - Lock/Unlock Toolbar Palette Positions button, 31
 - LWT (Lineweight) button, 29
 - Manage Xrefs button, 31
 - Maximize Viewport button, 30
 - Minimize Viewport button, 30
 - MODEL/PAPER button, 29–30
 - ORTHO button, 28, 63
 - OSNAP (Object Snap) button, 29, 63
 - OTRACK (Object Snap Tracking) button, 29
 - POLAR button, 28
 - SNAP button, 28
 - Status Bar Menu button, 31
 - Trusted Autodesk DWG button, 31
- Status Bar Menu button, 31
- straight segments, polylines composed of, 149–150
- STRETCH (S) command, 68–70, 177, 179, 183
- Stretch button (Modify toolbar), 68
- stretching
 - lines, 184–185
 - objects, 183–186, 202–204
- Style Table (STB) styles, 317–318

styles

- dimension, 269–273
- multileaders, 288–289
- plotting, 316–320
- table, 258–260
- text, 237–241

Styles toolbar, 26

substyle, dimension, 273

System International (SI) units of
measure, 80

system printers, 304–306

system variables

- angular units and precision settings, 88
- annotation scaling settings, 88
- in current drawing session, 45
- dimension scale settings, 88
- drawing limit settings, 88
- drawing setup procedures, 87–88
- grid spacing and visibility settings, 88
- how to use, 45–46
- linear units and precision settings, 88
- linetype scale settings, 88
- MEASUREMENT, 81
- saved in drawings, 45
- SAVETIME, 43
- setting, 43–44
- snap spacing settings, 88
- values of, changing, 45
- viewing list of, 44–45
- in Windows Registry, 45

● T ●

tables

- block, 334
- cells, 259–260
- columns, 260–261
- copying, 262
- creation, 260–261
- data extraction, 262
- editing, 260–262
- importing, 262
- insertion point, 260
- rows, 260–261
- styles, 258–260

TABLESTYLE command, 258

tabs, layout, 39

Template Options dialog box, 107

templates

- naming, 106
 - new file creation, 88–90
 - saving drawings as, 105–106
 - self-created, 105–107
 - units of measure, 106
- temporary overrides, precision practices,
139

text

- annotations, 237, 246–248
- background masking, 252
- bulleted and numbered lists, 254–256
- commands, 236
- dimensions, 265, 275, 284
- DTEXT command, 244–246
- dynamic columns, 256–257
- editing, 257–258
- fonts, 238–239
- height, 242–243
- In-Place Text Editor, 250–251
- insert fields, 252–253
- justification options, 243–244
- MTEXT command, 244–246, 248–249
- multiline, 248–252
- paragraph, 243
- single-line, 243
- static columns, 256–257
- styles, 237–241

Text (TXT) files, 398

Text Formatting toolbar, 251

Text Style dialog box, 240

TEXTTTOFRONT command, 252

thickness, 59–60

3D Modeling workspace

- files, starting new, 22
- Layers control panel, 221
- Lens Length/Field of View slider, 224
- Lights control panel, 222
- Materials control panel, 222
- overview, 21
- parallel projection, 225
- Render control panel, 222
- 3D Make control panel, 221–222
- 3D Navigate control panel, 222, 224
- Visual Styles control panel, 222

3D object creation

- conceptual visual style, 226
- Dashboard interface controls, 220–224
- edge settings, 227

- navigation, 228–229
 - new file creation, 218–220
 - online resources, 232
 - parallel projection, 225, 231
 - perspective projection, 231
 - realistic visual style, 226
 - solid and surface modeling techniques, 232
 - specialized areas, 217
 - 3D Hidden visual style, 225
 - 3D Wireframe visual style, 225
 - 3DORBIT model, 229–232
 - views, 228–229
 - TIFF files, 394–395
 - TIFOUT command, 394
 - title bar control buttons, 24
 - title blocks, 102
 - tool palettes, 42
 - toolbars
 - Autodesk Impression, 21
 - closing, 26
 - customizing, 27
 - Dashboard interface, 32
 - Draw, 26, 71
 - Draw Order, 26
 - Layers, 26
 - Modify, 26, 59, 65, 68
 - moving, 26
 - opening, 26
 - Properties, 26
 - Standard, 25, 112
 - Styles, 26
 - Text Formatting, 251
 - Workspaces, 26
 - tooltips
 - commands, 144
 - dynamic input system, 33
 - general discussion, 27
 - traditional dimensions, 265
 - transparent commands, 38
 - tree view pane (DesignCenter palette), 126
 - TRIM (TR) command, 159, 177, 191–192
 - trimming objects, 191–192
 - troubleshooting plotting, 329–330
 - TrueType (TTF) fonts, 238–239
 - Trusted Autodesk DWG button, 31
 - 2D Drafting & Annotation, 21
 - 2D Wireframe visual style, 225
 - TXT (Text) files, 398
 - Typical installation option, 18
- **U** •
- underscore (), 38
 - Units command (Format menu), 91
 - units of measure
 - Architectural, 80
 - Decimal, 80
 - drawing setup procedures, 79–81, 91–92
 - Drawing Units dialog box, 91–92
 - Engineering, 80
 - Fractional, 80
 - imperial units, 79, 81
 - inches, 133
 - metric, 81
 - precision of measurement, 80
 - Scientific, 80
 - SI (System International), 80
 - templates, 106
 - UNIX operating system, 11–12
 - unloading xrefs, 360
 - unlocking layers, 123
 - unused block definitions, purging, 347
 - upgrades, version, 16–18
 - user-defined hatches, 296, 298
- **V** •
- variables, dimension, 269
 - VBA (Visual Basic for Applications), 16
 - vector images, 362
 - verb-noun editing, 168
 - versions
 - application compatibility, 16
 - DWG file format compatible, 14–16
 - upgrades, 16–18
 - VIEW command, 210–211
 - View Manager dialog box, 210–211
 - View Transitions dialog box, 210
 - viewports
 - defined, 39
 - description of, 30
 - layout creation, 102
 - 3D views, 228–229
 - views, isometric and orthographic, 228–229
 - visibility states, blocks, 348–351

visible object snaps, grips as, 197–200
 Visual Basic for Applications (VBA), 16
 visual styles, 3D object creation, 225–227
 Visual Styles control panel (3D Modeling workspace), 222
 Visual Styles Manager palette, 226–227
 VPMAX command, 215
 VPMIN command, 215

• W •

warnings
 command window, 33–34
 drawing scale selection, 83
 dynamic input system, 35
 file conversion, 15
 hatching overuse, 292
 migration custom settings, 24
 reusing drawings, 79
 WBLOCK command, 358
 width, polylines, 148
 window area, plotting, 327
 window object selection, 171–172
 Window option, zooming, 209
 Window selection option, 174
 windows, maximizing/restoring, 24
 Windows Clipboard, 395
 Windows Registry, 45
Windows Vista Timesaving Techniques For Dummies (Leonhard), 397
 wizards, Create Layout Wizard, 100–102
 WMF (Windows MetaFile), 393
 workspaces
 defined, 21
 new features, 17
 switching between, 22
 Workspaces toolbar, 26
 WPolygon selection option, 174

• X •

X (EXPLODE) command, 148, 177, 386
 X coordinates
 absolute coordinates, 131
 grid and snap interval setup, 96
 relative coordinates, 131
 XLINE (XL) command, 142, 145
 XOPEN command, 358

xrefs (external references)
 advantages of, 355–356
 attaching, 356–358
 automatic update features, 356
 binding, 360
 blocks, 355–359
 child/parent drawings, 355
 clipping, 361
 detaching, 360
 discussed, 334
 editing, 358–359
 file creation, 358–359
 full path settings, 359–360
 maintenance, 360–361
 opening, 361
 overlays, 358
 relative path settings, 360
 reloading, 360
 unloading, 360
 views, switching between, 360
 when to use, 361

• Y •

Y coordinates
 absolute coordinates, 131
 grid and snap interval setup, 96
 relative coordinates, 131

• Z •

ZOOM command, 64, 93
 Zoom command (View menu), 54, 71
 zooming
 how to, 64–65
 layouts, 212–215
 magnifying glass cursor, 65
 Object option, 209
 panning, 205
 Previous option, 209
 real-time, 206–207, 209
 reasons for, 64
 smooth view transitions, 209–210
 using scroll wheel, 207
 Window option, 209
 Zoom All option, 208–209
 Zoom Extents option, 208–209
 zooming in/out, 205