

# Index

## • Symbols and Numerics •

' (apostrophe) command prefix, 33  
\* (asterisk) wildcard character, 39  
@ (at sign) relative coordinate prefix, 51  
< > (brackets, angled) command option delimiters, 33  
dimension text placeholder, 259  
[ ] (brackets, square) command option delimiters, 30, 32–33  
: (colon) drawing scale character, 74  
– (dash) coordinate fraction prefix, 124  
= (equal sign) drawing scale character, 74  
second point arc, 141, 147, 148  
displacement, 170, 172  
third-party application, 13, 15  
3D, AutoCAD LT support, 14  
3P (3-Point) circle, 145  
2P (2-Point) circle, 145  
\_ (underscore) command prefix, 33

## • A •

ACAD files, 22  
acad.dwt file, 47, 80  
acad.fmp file, 366  
ACAD\_ISO linetype, 113  
acadiso.dwt file, 47, 80  
acadiso.lin file, 112, 115  
acad.lin file, 112, 115

accuracy, precision versus, 120  
ACI (AutoCAD Color Index), 111  
Acrobat software, 389  
action, block, 321–323  
ADCenter command, 358  
Add Printer Wizard, 278  
Add-A-Plot Style Table Wizard, 290  
Add-A-Plotter Wizard, 278  
Adobe Reader software, 389  
aesthetic of plotted drawing, 353  
AIA (American Institute of Architects), *CAD Layer Guidelines*, 354, 357  
alignment  
dimension, aligned, 243, 255  
text, 214, 223  
ALL object selection mode, 165  
American National Standards Institute.  
*See* ANSI  
angle  
arc, 147  
dimension, angular, 243  
dimension display, dynamic, 27  
ellipse rotation angle, 149  
increment, specifying, 25  
measurement unit, 84  
Polar tracking, 25  
rotation angle, 178  
annotation  
hatching as geometry annotation, 266  
plot, 78  
ANSI (American National Standards Institute)  
hatching standard, 269  
paper size, 76

apostrophe (') command prefix, 33  
arc  
angle, 147  
center point, specifying, 147, 148  
dimension, 243  
endpoint, specifying, 140, 147, 149  
extending, 182–184  
joining, 187–188  
offset, 180  
revision cloud, in, 154–155  
second point, specifying, 141, 147, 148  
segment, 140, 141  
splitting, 184–185  
start point, specifying, 147, 148  
trimming, 182–184  
Arc command, 133, 140, 145, 148–149  
architectural drawing  
measurement unit, 84, 123–124  
paper, architectural size, 76–77  
scale, 75  
*Architectural Graphic Standards* (industry reference book), 352  
ARCHIVE command, 368  
ARray command, 58–59, 168, 179–180  
Array dialog box, 58, 180  
ARX (AutoCAD Runtime eXtension), 15  
asterisk (\*) wildcard character, 39  
at sign (@) relative coordinate prefix, 51  
ATTDEF command, 313, 315  
ATTDIA system variable, 316

attribute  
 block, 303, 309,  
 312–316, 318  
 sheet set, 347  
 text table, extracting  
 attribute data to, 236  
 Attribute Definition dialog  
 box, 313–314  
 Attribute Extraction  
 Wizard, 316, 347  
 AUNITS system variable, 80  
 AUPREC system variable, 80  
 AutoCAD Color Index  
 (ACI), 111  
 AutoCAD LT, 13, 14  
 AutoCAD Runtime  
 eXtension (ARX), 15  
 AutoCAD Text Window,  
 31, 32  
 Autodesk Web site, 13

## • B •

Background Mask dialog  
 box, 227–228  
 backup, 53, 383, 384  
 BAK files, 383  
 Base point prompt, 171  
 Batch Standards Checker  
 feature, 359  
 BATTMAN command, 315  
 BEdit command, 322  
 bitmap image, 304. *See also*  
 raster image  
 block. *See also* title block  
 action, 321–323  
 advantages/disadvan-  
 tages, 305  
 attribute, 303, 309,  
 312–316, 318  
 authoring, 303, 319, 320  
 base/insertion point, 307,  
 308, 314, 319, 322  
 callout block, 347  
 color, 111  
 consistency, importance  
 of, 358  
 copying definition, 309  
 database analogy, 313

definition/redefinition,  
 303, 304, 306–309,  
 311, 314–315  
 described, 303  
 description, entering, 308  
 dynamic, 15, 303, 304,  
 305, 318–325  
 editing, 305, 308, 312,  
 316, 318–321  
 exploding, 317–318, 382  
 field, 313  
 grip, 323–324  
 grouping objects in,  
 305, 306, 307  
 inheritance, 310  
 inserting, 303, 305, 307,  
 308, 310–312  
 label block, 347  
 layer, 307, 310, 312  
 library, storing symbol  
 collection in, 309  
 naming, 307  
 organizational tool, as, 331  
 parameter, 321–323  
 purging unused, 317  
 redefinition, 307, 311  
 reusability, 304, 305  
 rotating, 311, 322  
 scale, 307–308, 311  
 sheet set, 316  
 table, 304, 309  
 tag, 313  
 text, 312, 314, 316, 318  
 version requirement, 304  
 visibility state,  
 318, 319–320  
 xref, converting to  
 block, 330  
 xref versus, 304, 325, 326  
 Block Attribute  
 Manager, 315  
 Block Authoring palettes,  
 320, 322  
 Block Authoring toolbar,  
 320, 321  
 Block command, 309  
 Block Definition dialog box,  
 306, 307, 309

Block Editor window,  
 319, 322  
 blue line print, 276  
 BMP files, 386, 390–391. *See*  
*also* raster image  
 border, choosing  
 appropriate, 71, 79  
 brackets, angled (< >)  
 command option  
 delimiters, 33  
 dimension text  
 placeholder, 259  
 brackets, square ([ ])   
 command option  
 delimiters, 30, 32–33  
 BReak command,  
 169, 184–185  
 Buzzsaw Internet-based  
 service, 364

## • C •

CAD Layer Guidelines (AIA),  
 354, 357  
 calculator feature, 37, 78  
 callout block, 347  
 cartoon, 78  
 CELTSCALE system  
 variable, 80  
 CEnter command, 141  
 Center snap mode, 126, 128  
 CHAMfer command,  
 169, 185–187  
 Check Spelling dialog  
 box, 237  
 Check Standards dialog  
 box, 26, 359  
 child drawing, 325, 371. *See*  
*also* xref (external  
 reference)  
 circle  
 arc, circular, 147  
 center point, speci-  
 fying, 146  
 dimensioning, 243  
 donut, 133, 134,  
 145, 152–153  
 drawing, 53–54,  
 133, 145–146

- offset, 180
- polygon, drawing relative
  - to, 55, 143–144
- radius, 54, 145, 146
- semicircle, 147
- snap, using when
  - drawing, 126
- spacing object group in
  - circular pattern, 58, 179–180
- splitting, 184–185
- 3P, 145
- ttr, 145
- 2P, 145
- Circle command, 133, 145–146
- cloud, revision, 133, 145, 153–155
- colon (:) drawing scale character, 74
- color
  - ACI, 111
  - block, 111
  - display color, 391
  - gradient, 271
  - hatching, 271
  - HSL, 111
  - layer, 51, 109–110, 111–112, 119
  - lineweight, 108, 288, 289, 292–294
  - PANTONE, 112
  - plotting, 287–295, 290, 300, 355–356
  - property, setting, 107
  - RAL, 112
  - RGB, 112
  - text, 228, 233–234
- Color TaBle (CTB) files, 288, 290–291, 293, 365
- Comma Separated Value (CSV) file, exporting, 236
- command. *See also specific command*
  - action, accepting
    - default, 32
  - canceling, 32
  - dimension command
    - overview, 244–245
  - display options, 27
  - drawing command
    - overview, 132–134
  - editing command
    - overview, 167–169
  - editing, command-first, 159–160, 188
  - entering, 20, 29–33, 39–40
  - listing recent, 33
  - nesting, 33
  - option, entering, 30, 31, 32–33
  - prompt, 169
  - selection, command-first, 165
  - tooltip, display in, 27
  - transparent, 33
  - wildcard, using in, 39
- command line
  - accessing, 165
  - Draw toolbar versus, 134
  - dynamic input system,
    - behavior in, 17, 27–29, 133
  - entering command from, 29–33, 39–40
  - feedback display in, 27, 29, 36, 46, 133
  - transparency, 37
- Command Reference↔
  - Commands↔D
  - Commands, 245
- COMMANDLINE command, 165
- comment, leader, 260–263
- Communication Center
  - dialog box, 26
- compression, file, 367
- Configure Standards
  - feature, 359
- construction line, 132, 135
- Contents↔Command Reference↔System Variables↔D System Variables, 245
- Contents↔Customization Guide↔Custom Linetypes, 115
- Contents↔Driver, 276
- coordinate
  - absolute, 122, 123
  - display, 24, 27, 51, 84, 122
  - fraction representation, 124
  - keyboard, entering using, 122–124
  - measurement unit, 123–124
  - origin point, 24
  - polar, 122, 123
  - precision, 84, 121
  - rectangular, 122, 123
  - relative, 51, 122, 123
- COPY command, 29
- CoPy command, 168
- CoPy command, 168, 169–170, 172–174
- COPYBASE command, 174
- COPYCLIP command, 173, 174
- copying
  - block definition, 309
  - cutting and pasting, 173
  - dimension style, 245–246
  - displacement, specifying, 170–171
  - drawing, to another, 118–120, 173
  - grip, copying object using, 189, 193–194
  - hatching, 269
  - layer, 118–120
  - layout, 95–96, 118, 296
  - offsetting copied object, 180–182
  - scaled object, 179
  - sheet set, 340
  - text, 118, 232, 236
  - undoing copy operation, 172
- Windows clipboard, to, 173–174, 386, 391

- CPolygon selection mode, 165
  - cram, avoiding, 382–383
  - Create Layout Wizard, 92–95
  - Create New Dimension Style dialog box, 248
  - Create New Table Style dialog box, 233
  - Create Sheet Set Wizard, 339–340
  - Create Transmittal dialog box, 366, 368
  - crossing object selection, 60–62, 162–164, 165, 166, 176–177
  - CSV (Comma Separated Value) file, exporting, 236
  - CTB (Color Table) files, 288, 290–291, 293, 365
  - cursor
    - constraining movement to horizontal/vertical, 24
    - coordinate display, 24, 27, 51, 84, 122
    - dynamic, 27, 30, 33, 169
    - hand, 58, 200
    - magnifying glass, 57
    - Polar tracking, 25
    - rectangle, dashed, 61
  - curve. *See also* arc
    - elliptical, 149, 150
    - free-form, 150–152
    - NURBS, 151
    - polyline, curved, 138, 140–141
    - revision cloud, 133, 145, 153–155
    - snap, using when drawing, 126
    - spline, 133, 145, 150–152
  - Customization Guide↔
    - Basic Customization↔
    - Customize the User Interface↔Customize Toolbars, 23
  - CUTCLIP command, 173, 174
  - cutting and pasting, 173
- D •
- dash (-) coordinate fraction prefix, 124
  - ddEDit command, 259
  - Design Web Format file. *See* DWF file
  - DesignCenter palette
    - accessing, 118
    - Blocks section, 311
    - content pane, 117, 119
    - DC Online tab, 118
    - display when toggled on, 38
    - Folders tab, 118, 119, 120
    - History tab, 118
    - introduced, 36
    - navigation pane, 117, 118
    - Open Drawings tab, 118, 119, 246
    - standard implementation, using in, 358
    - toggling on/off, 119
    - toolbar, 117
  - dialog box, modal/modeless, 37
  - diazo blue-line machine, 274–275
  - digital signature, 364, 377–378
  - DIMARC command, 244
  - DIMASSOC system variable, 260
  - DimBAseline command, 256
  - DimCOntinue command, 256
  - DIMDISASSOCIATE command, 260
  - dimension
    - aligned, 243, 255
    - angular, 243
    - arc, 243
    - arrow, 242, 250, 251, 261
    - associativity, 244, 259–260
    - batch, adding in, 240
    - circle, 243
    - command overview, 244–245
    - described, 239
    - diameter, 243
    - display, dynamic, 27
    - editing, 249–253, 258–260
    - exploding, 244, 258, 382
    - geometry, 258
    - grip, 258
    - horizontal, 243, 254
    - importance of adding, 241
    - layer, 254, 261
    - leader, 260–263
    - line, drawing, 242, 250, 253, 254–255
    - linear, 243, 254–256
    - measurement unit, 252–253
    - origin point, 253, 254
    - plotting, 250
    - radial, 243
    - scale, 89–91, 246, 250, 251–252, 263
    - side-by-side, 256
    - snap, 253, 254, 255, 261
    - standard, 240, 244, 358
    - style, 239, 245–253, 258, 328, 358
    - system variable, 39
    - text, 242, 250–251, 259
    - trans-spatial, 257
    - updating, 240
    - variable, 245
    - vertical, 243, 254
  - Dimension Style Manager dialog box, 90, 246–247, 248, 249
  - Dimension toolbar, 244, 254, 255, 261
  - DIMREASSOCIATE command, 260
  - DIMREGEN command, 260
  - DIMSCALE system variable, 80, 90, 155, 220, 252
  - direct manipulation, 160
  - displacement vector, 170, 171, 176
  - display, changing default, 18
  - distance entry precision, 121, 129
  - dithering, mono-chrome, 294
  - DLine command, 142

- documentation
    - DWG file, 387
    - layer, documenting, 107
    - standard, documenting, 355
  - DOnut command, 133, 134, 145, 152–153
  - double floating-point precision, 209
  - Drafting Settings dialog box
    - Object Snap tab, 127
    - Snap and Grid tab, 48, 88, 129
    - system variable, setting using, 80
  - Draw→Arc, 147
  - Draw→Block↔Define
    - Attributes, 313
  - Draw→Insert, 319
  - Draw Order toolbar, 22, 23
  - Draw→Point↔Multiple
    - Point, 157
  - Draw→Table, 234
  - Draw→Text↔Single Line
    - Text, 222
  - Draw toolbar
    - Circle button, 53
    - command line versus, 134
    - Hatch button, 63
    - Insert Block button, 310
    - Line button, 125
    - Make Block button, 306
    - Multiline Text button, 224
    - Point button, 157
    - Polygon button, 54
    - Polyline button, 139
    - position, default, 22, 23
    - Rectangle button, 51
    - Spline button, 151
  - drawing area, 34–36, 48, 77, 285
  - Drawing eXchange Format (DXF), 13, 386, 388
  - Drawing Properties dialog box, 91
  - Drawing Standards (DWS) file, 26, 360
  - Drawing Units dialog box, 73, 80, 83
  - DRaworder command, 228, 334
  - driver
    - plotter, 297
    - printer, 276, 278, 300
  - DST file, 335, 337, 339, 366
  - DTEXT command, 221
  - DWF Composer feature, 362
  - DWF (Design Web Format) file
    - described, 362
    - DWG file, relation to, 372
    - ePlotting, 373–374
    - exchanging data with other software using, 386
    - hyperlink, embedding, 376
    - password protecting, 377, 378
    - plotting, 373–376
    - precision, 372
    - publishing, 375
    - sheet set, 373, 374
    - transmitting over Internet, 362
    - version used by AutoCAD, 373
  - DWF Viewer software, 372, 376, 377
  - DWF6 ePlot.pc3 file, 373
  - DWG files
    - AutoCAD 2006 support, 15
    - backward compatibility, 12, 13, 15
    - child, 325, 371
    - compression, 367
    - documentation, 387
    - DWF file, relation to, 372
    - exchanging data with other software using, 386–387
    - external, 26
    - parent, 325, 371
    - password protecting, 377
    - plot, legal precedence over, 241
    - reliability considerations when converting data to/from, 12
    - sheet set, 344
    - state of drawing, storage in, 383
    - title block, saving to separate DWG file, 79
    - transmitting over Internet, 363, 364–366, 367
    - version, opening file saved in earlier, 12
    - version, saving in earlier, 12, 13, 15
    - xref, 26
  - DWS (Drawing Standards) file, 26, 360
  - DWT files, 47, 98. *See also* template
  - DXF (Drawing eXchange Format), 13, 386, 388
  - dynamic input. *See* input, dynamic
- *E* ●
- EATTEDIT command, 316
  - EATTEXT command, 316
  - Edit Block Definition dialog box, 308, 318–319
  - Edit→Paste Special, 391, 392
  - Edit Scale List dialog box, 76, 283
  - Edit Text dialog box, 223
  - editing. *See also* undoing block, 305, 308, 312, 316, 318–321
    - command overview, 167–169
    - command-first, 159–160, 188
    - dimension, 249–253, 258–260
    - grip, 160, 161, 188, 189–197, 232
    - hatching, 274
    - layout, 95–96, 97
    - scale, changing, 179
    - selection-first, 159, 160, 161
    - sheet set, 340

- editing (*continued*)
    - spline, 151
    - text, 223, 232, 234–236, 259
    - xref, 306, 328
  - electronic plotting (ePlotting), 372–374
  - ellipse, drawing, 133, 145, 149–150. *See also* circle
  - e-mailing file, 363, 364, 369
  - engineering drawing
    - measurement unit, 84
  - Enhanced Attribute Editor dialog box, 316
  - Enter Attributes dialog box, 315
  - ePlotting (electronic plotting), 372–374
  - equal sign (=) drawing scale character, 74
  - erasing, 166, 168, 383
  - ET (Express Tools) feature, 16, 19, 22, 318
  - ETRANSMIT command, 363, 365–367, 387
  - Excel, exchanging data with, 236, 386
  - eXplode command, 138, 169, 258, 382
  - EXPORT command, 389, 390
  - Express↔Blocks↔Explode Attributes to Text, 318
  - EXPRESS file, 22
  - Express Tools (ET) feature, 16, 19, 22, 318
  - EXtend command, 168, 182–184
  - external reference. *See* xref
  - External Reference dialog box, 327
- **F** ●
- feedback display
    - command line, in, 27, 29, 36, 46
    - tooltip, in, 46
  - fence object selection mode, 165, 184
  - field
    - block, 313
    - text, 228–229, 235, 316
  - Field dialog box, 228
  - file. *See also specific file*
    - compression, 367
    - e-mailing, 363, 364, 369
    - naming, 49, 99
    - plotting to, 298
    - transmitting over Internet, 363, 364–370
    - xref, 328
  - File↔Close, 208
  - File↔Drawing Properties, 91
  - File↔Drawing Utilities ↔ Purge, 317
  - File↔eTransmit, 366
  - File↔Export, 390
  - File↔Install New Font, 370
  - File navigation dialog box, 363
  - File↔New, 47
  - File↔Page Setup Manager, 295
  - File↔Plot Style Manager, 290
  - File↔Plotter Manager, 300
  - File↔Publish, 375
  - File↔Save As, 98
  - File Transfer Protocol (FTP), 363, 368–369
  - Fillet command, 52–53, 169, 185–187
  - filtering, 116
  - FMP files, 366
  - folder
    - DesignCenter folder display, 118
    - hidden, showing, 99–100
    - custom, 216, 365
    - height, 214, 226
    - installing, 370
    - mapping, 366
    - SHX, 215–216, 217, 250, 365, 367
    - specifying, 217
  - substitution, 370
  - text style, included in, 214
  - title block, 215
  - transmitting over Internet, 365–366, 367, 370
    - TTF, 215, 365, 367, 370
  - FONTALT system variable, 366
  - FONTMAP system variable, 366
  - Format↔Dimension Style, 90, 248
  - Format↔Drawing Limits, 48
  - Format↔Linetype, 90
  - Format↔Lineweight, 113
  - Format↔Point Style, 156
  - Format↔Scale List, 76
  - Format↔Table Style, 233
  - Format↔Text Style, 214, 216
  - Format↔Units, 83
  - FTP (File Transfer Protocol), 363, 368–369
  - FullShot software, 393
- **G** ●
- geometry. *See also specific shape*
    - cram, avoiding, 382–383
    - dimension, 258
    - drawing, 131
    - hatching as annotation to, 266
    - paper/model space shared geometry, 97
    - precision, 121
    - tolerance, geometric, 253
  - gradient, color, 271
  - grid
    - limits, indicating using, 87–88
    - measurement unit, 87
    - model space grid setup, 87–89
    - snapping to, 24, 48–49, 87–89
    - spacing, 87, 89

text table, 233, 235  
visibility, 24  
zooming entire, 49

GRIDMODE system  
variable, 80

GRIDUNIT system  
variable, 80

grip  
block, 323–324  
cold, 190, 191, 192  
copying object using,  
189, 193–194  
custom, 323–324  
described, 188  
dimension, 258  
dragging, 189  
editing, 160, 161, 188,  
189–197, 232  
enabling/disabling, 161  
endpoint, 191, 195  
hot, 190, 191, 192  
mirroring object using,  
189, 190, 193  
moving object using,  
190, 191, 192–194  
polyline, 138  
rotating object using,  
189, 190, 193  
scaling object using,  
189, 190, 193  
snap, 189  
stretching object using,  
189–190, 194–197  
text, 232

Group Manager dialog  
box, 306

• **H** •

hand cursor, 58, 200

Hatch and Gradient  
dialog box  
accessing, 63  
Add Pick points option, 63  
Draw Order drop-down  
list, 273  
Gradient tab, 271  
Hatch tab, 267

Inherit Properties  
button, 269  
Preview button, 282  
Type drop-down list, 270

Hatch command, 267

Hatch Edit dialog box, 274

hatching  
angle, 270  
annotation to geometry,  
as, 266  
area hatched, defining, 63,  
266–267, 268, 272–273  
boundary, 266, 268,  
272–273  
color, 271  
consistency, importance  
of, 269  
copying, 269  
draw order, 273  
editing, 274  
exploding, 382  
inheritance, property, 269  
layer, 267  
measurement system, 73  
origin point, 274  
palette, creating, 274  
pattern, specifying,  
63, 267  
predefined, 269  
previewing, 63, 268  
scale, 179, 270, 272  
simplicity, importance  
of, 265  
solid, 271  
standard, 269, 358  
user-defined, 270

help  
online, 23, 41–42, 43  
Quickstart, 297

highlighting, rollover, 165

HiJaak software, 390

host drawing, 325. *See also*  
xref (external  
reference)

HP (Hewlett-Packard) Web  
site, 297

HPGAPTOL system  
variable, 267

HSL (Hue Saturation  
Luminance) color, 111

hyperlink, adding to  
drawing, 363, 376–377

• **I** •

image  
attaching raster image to  
drawing, 332–334  
bitmap, 304  
BMP, 386, 390–391  
exchanging data with  
other software using  
raster image, 385, 386,  
390–391, 393  
JPEG, 390  
PNG, 390  
TIFF, 390  
transmitting raster image  
over Internet, 365, 370  
vector image, 304, 332, 385

Image command, 333, 390

Image Manager dialog box,  
333, 370

imperial measurement  
system, 73, 74, 77

implied windowing, 162

Import Layouts as Sheets  
dialog box, 341

Inbit FullShot software, 393

Info Palette feature, 37, 42

input, dynamic  
accessing, 25, 133  
block, dynamic, 15, 303,  
304, 305, 318–325  
command line behavior,  
17, 27–29, 133  
cursor, 27, 30, 33, 169  
dimension display, 27  
introduced, 15  
pointer, 27  
status bar, 28  
tooltip, 27, 28, 29, 169

input, keyboard, 20, 29–33,  
122–124. *See also*  
command line

Insert dialog box, 310–311

- Insert↔External
    - Reference, 326
  - Insert↔Image Manager, 333
  - Insert Table dialog box, 234, 236
  - Insert↔Windows
    - Metafile, 389
  - International Organization for Standardization. *See* ISO
  - Internet. *See also specific Web site*
    - Buzzsaw Internet-based service, 364
    - dial-up access
      - suitability, 362
    - file, transmitting over, 363, 364–370
    - font, transmitting over, 365–366, 367, 370
    - FTP, 363, 368–369
    - help, online, 23, 41–42, 43
    - hyperlink, adding to
      - drawing, 363, 376–377
    - plot style, transmitting over, 365
    - publishing drawing to
      - Web, 363, 372, 376
    - raster image, transmitting over, 365, 370
    - sheet set, transmitting over, 339, 368
    - signature, digital, 364, 377–378
    - URL, 369
    - xref, transmitting over, 363, 365, 370
  - Intersection snap mode, 126
  - Ipswitch WS\_FTP
    - software, 369
  - ISO (International Organization for Standardization)
    - dimension style
      - standard, 248
    - hatching standard, 269
    - layer standard, 354
    - paper size standard, 76, 77
  - Join command, 169, 187–188
  - JPEG files, 390
  - JPGOUT command, 390
  - JUSTIFYTEXT command, 232
- ## K
- keyboard input, 20, 29–33, 122–124. *See also* command line
- ## L
- label block, 347
  - landscape drawing, 383
  - last object selection mode, 165
  - layer
    - AIA guideline, 354, 357
    - anatomy book
      - analogy, 105
    - block, 307, 310, 312
    - color, 51, 109–110, 111–112, 119
    - copying to another
      - drawing, 118–120
    - creating, 50, 54, 110–115
    - current, specifying, 51, 52, 106
    - description, adding, 114
    - dimension, 254, 261
    - documenting, 107
    - filtering, 116
    - freezing, 114–115, 383
    - grouping objects
      - using, 105
    - hatching, 267
    - line, 109, 112–113, 356–357
    - locking, 114
    - naming, 50, 54, 110–111
    - pin-bar drafting
      - equivalent, 105
    - plot, 109–110, 114, 356
    - property control using, 108–109, 381
    - standard, 354, 356–357, 358
    - text, 105, 214
    - translating, 358
    - turning off/on, 114–115
    - view, saving layer
      - configuration with, 204
    - visibility, 114
    - xref, 328
  - LAYER command, 50, 110
  - Layer Properties Manager
    - dialog box, 50, 110
  - Layer Translator
    - feature, 358
  - Layers toolbar
    - Layer button, 50
    - Layer drop-down list, 51, 52, 106
    - position, default, 21, 23
    - property change
      - functionality, 197
  - layout
    - copying, 95–96, 118, 296
    - creating, 92–95
    - described, 92
    - editing, 95–96, 97
    - naming, 93
    - page setup, saving to, 295–296
    - panning, 205
    - paper space, 92–97, 205–208, 284–287, 289, 337
    - plotting, 92–97, 281, 284–287, 293–294, 295–296
    - regen, 209
    - sheet set, 337, 340, 341
    - template, 95
    - title block, 94–95
    - viewport, 95, 96, 205, 207–208
    - zooming, 205–207
  - LAYOUTWIZARD
    - command, 92
  - LAYTRANS command, 358
  - leader, 260–263
  - LENGTHEN command, 168, 184

- library, online, 118
  - limits
    - grid, indicating using, 87–88
    - model space, 48, 85–86
    - plot, 65
    - zooming to area defined by, 202
  - LIMMAX system variable, 80
  - LIMMIN system variable, 80
  - LINE command, 30–31, 125, 132, 135–136
  - line, graphic. *See also* polyline; spline
    - ACAD\_ISO linetype, 113
    - color, linewidth, 108, 288, 289, 292–294
    - command line, drawing using, 30–31
    - construction, 132, 135
    - copying linetype to another drawing, 118
    - corner between two lines, creating curved, 185–186
    - creating linetype, 115
    - dash-dot linetype, 73, 89, 107
    - definition, linetype, 115
    - dimension line, 242, 250, 253, 254–255
    - double, 142
    - endpoint, 136, 139
    - extending, 182–184
    - filleting, 185–187
    - infinite, 134
    - joining, 187–188
    - layer, 109, 112–113, 356–357
    - loading linetype, 115
    - measurement unit, 73, 84, 112–113, 115
    - offset, 180–181
    - orthogonal, 24
    - parallel, 142, 180
    - plotting, controlling
      - linewidth when, 67, 287–289, 290, 292–294
    - point on, defining, 136
    - scale, linetype, 80, 89–90
    - screened, 288
    - segment, 31, 135–136, 137–139
    - semi-infinite, 134
    - snap, drawing using single point object, 124–125
    - specifying linetype, 112
    - specifying linewidth, 107, 113
    - splitting, 184–185
    - start point, 136, 139
    - stretching, 174
    - trimming, 182–184
    - visibility, linewidth, 108
    - xref, 328
  - line, text
    - adding blank, 231
    - break, 221, 226
    - multiline, 214, 220, 224–227
    - single-line, 214, 220, 221–223
  - Linetype Manager dialog box, 80, 90
  - Lineweight dialog box, 113
  - list, text, 229–232
  - Load or Reload Linetypes dialog box, 112, 115
  - locking
    - layer, 114
    - palette, 23, 26
    - Properties palette, 36
    - toolbar, 23, 26
    - viewport, 208
  - LTSCALE system variable, 80, 90
  - LUNITS system variable, 80
  - LUPREC system variable, 80
  - LWeight command, 113
- M •**
- magnifying glass cursor, 57
  - manipulation, direct, 160
  - markcad.com Web site, 378
  - Markup Set Manager, 37, 362
  - MBUTTONPAN system variable, 201
  - measurement system
    - changing, 72–74
    - choosing appropriate, 71
    - imperial, 73, 74, 77
    - metric, 47, 72
    - template, 47, 80
  - MEASUREMENT system variable, 73–74
  - measurement unit
    - angle, 84
    - architectural drawing, 84, 123–124
    - coordinate, 123–124
    - decimal representation, 73
    - dimension, 252–253
    - engineering drawing, 84
    - fraction representation, 73, 124
    - grid, 87
    - hatching, 73
    - line, 73, 84, 112–113, 115
    - model space, 83–84
    - paper, 94
    - precision, specifying, 73, 84
    - scaling unit, removing unused, 76
    - template, 99
  - memory requirement, 15
  - menu bar, 20–23
  - metric measurement system, 47, 72
  - Migrate Settings dialog box, 20
  - mirroring object
    - grip, using, 189, 190, 193
  - Mirror command, using, 168
  - model space
    - dimension scale, 89–91
    - displaying, 25, 34
    - drawing scale, 91
    - grid setup, 87–89
    - limits, specifying, 48, 85–86
    - linetype scale, 89–90
    - measurement unit, 83–84

- model space (*continued*)
    - panning in, 207
    - paper space, moving to/from, 26, 34, 36, 97, 382
    - paper space, shared geometry with, 97
    - plotting, 64–67, 279, 285, 289, 298
    - regen, 209, 210
    - viewport, 207
    - zooming in, 207
  - Modify⇨Clip⇨Image, 334
  - Modify Dimension Style dialog box, 90–91, 249–253
  - Modify⇨Object⇨
    - Attribute⇨Block Attribute Manager, 315
  - Modify⇨Object⇨
    - Attribute⇨Single, 316
  - Modify⇨Object⇨
    - Text, 232
  - Modify toolbar
    - Array button, 180
    - Break button, 185
    - Explode button, 317
    - Extend button, 182
    - Fillet button, 52
    - Join button, 188
    - Move button, 171
    - Offset button, 53
    - position, default, 22, 23
    - Rotate button, 178
    - Stretch button, 176
    - Trim button, 182
  - monochrome.ctb file, 66, 281
  - monochrome.stb file, 281
  - Move command, 168, 169–170, 171–172
  - moving object
    - base point, 170, 172
    - displacement, specifying, 170–171, 172
    - dragging, via, 173
    - grip, using, 190, 191, 192–194
    - selecting object for, 171
  - MSOLESCALE system variable, 392
  - MSpace command, 97
  - mText command
    - Background Mask option, 227–228
    - described, 220
    - Edit option, 232
    - Insert Field option, 228
    - list options, 229–232
    - Specify height option, 224
    - Specify opposite corner option, 224
    - TEXT command versus, 221
  - Multiline Text Editor, 221, 225, 228, 231, 232
  - MVIEW command, 96
- *N* ●
- naming
    - block, 307
    - dimension style, 248
    - file, 49, 99
    - layer, 50, 54, 110–111
    - layout, 93
    - plot style, named, 287, 289, 290, 294
    - sheet set, 339, 342, 344
    - template, 98
    - view, 203–204, 337, 346
  - National Institute of Building Sciences (NIBS), 354
  - National Institute of Standards and Technology (NIST), 72
  - Nearest snap mode, 126
  - NEW command, 82
  - New Dimension Style dialog box, 248
  - New Sheet dialog box, 343–344
  - New Table Style dialog box, 233–234
  - New Text Style dialog box, 217
  - New View dialog box, 203–204
  - New Visibility State dialog box, 321
  - New/Modify Dimension Style dialog box, 249–253
  - NIBS (National Institute of Building Sciences), 354
  - NIST (National Institute of Standards and Technology), 72
  - NODE snap mode, 155
  - NURBS (Non-Uniform Rational B-Spline) curve, 151
- *O* ●
- Object Linking and Embedding (OLE), 391–393
  - Object Snap toolbar, 125
  - Object Snap Tracking (OTRACK), 25
  - offset
    - arc, 180
    - circle, 180
    - copying, offsetting object when, 180–182
    - line, 180–181
    - plotting, 65, 280, 286, 299
    - polyline, 180–181
    - rectangle, 52
  - OLE (Object Linking and Embedding), 391–393
  - online help, 23, 41–42, 43
  - opening AutoCAD, 47
  - operating system support, 9–10, 13, 14, 18–19. *See also* Windows
  - Options dialog box
    - Display tab, 18, 285
    - Files tab, 289
    - Plot and Publish tab, 277, 299
    - Plotting tab, 289
    - quick help feature, 41
    - Selection tab, 46, 161

- Setup Wizards option, 83
  - User Preferences tab, 260
  - order, drawing, 22, 23, 228, 273, 334
  - origin point
    - coordinate, 24
    - dimension, 253, 254
    - hatching, 274
  - Ortho mode, 55–56, 121, 129
  - OTRACK (Object Snap Tracking), 25
- p •**
- padlock icon, 23
  - Page Setup dialog box, 286, 296
  - Page Setup Manager dialog box, 285
  - palette. *See also specific palette*
    - dialog box, as modeless, 37
    - hatch palette, creating, 274
    - locking, 23, 26
    - toggling on/off, 37
  - panning
    - hand cursor, using, 58, 200
    - layout, 205, 207
    - model space, in, 207
    - mouse, using, 201
    - paper space, in, 205, 207, 208
    - real-time, 57, 200, 201
    - regen, 209
    - title block, 205, 208
    - transition, smooth view, 203
    - viewport, in, 207
    - zooming, using in conjunction with, 58, 200–201
  - PANTONE color, 112
  - paper. *See also paper space*
    - ANSI size, 76
    - architectural size, 76–77
    - drawing area, calculating available in relation to, 77
    - ISO size, 76, 77
    - layout, saving page setup to, 295–296
    - measurement unit, 94
    - orientation, 94, 281
    - plotting, specifying paper size when, 65, 94, 280, 286
    - plotting, specifying paper type when, 297
    - plotting to multiple sheets, 78
    - printable area, 78
    - scaling drawing for, 70, 71, 75, 76–79
    - title block, fitting to, 94
    - type, specifying, 297
  - paper space
    - displaying, 25
    - layout, 92–97, 205–208, 284–287, 289, 337
    - model space, shared geometry with, 97
    - moving between model space and, 26, 34, 36, 97, 382
    - panning in, 205, 207, 208
    - viewport, 95
    - zooming in, 205, 207, 208
  - parent drawing, 325, 371. *See also xref (external reference)*
  - password protection, 364, 377, 378
  - PASTEBLOCK command, 174
  - PASTECLIP command, 173, 174
  - PASTEORIG command, 174
  - pasting. *See copying*
  - PC2 files, 293
  - PC3 files, 93, 277, 298
  - PCP files, 293
  - PCX files, 390
  - PDF (Portable Document Format), 386, 388–389
  - Pdf995 utility, 389
  - PDMODE system variable, 157
  - PDSIZE system variable, 157
  - PEdit command, 181
  - Peripheral Guide⇨Use
    - Plotters and Printers, 276
  - Perpendicular snap mode, 126
  - pin-bar drafting, 105
  - PLine command, 132, 134, 136–142
  - Plot dialog box
    - Apply to Layout button, 294
    - Drawing Orientation area, 281
    - Help button, 297
    - Learn about Plotting option, 297
    - More Options area, 65–66, 280, 287
    - Paper Size area, 280
    - Plot Area area, 280, 298
    - Plot Object Lineweights check box, 292
    - Plot Offset area, 280, 299
    - Plot Options area, 281, 299
    - Plot Scale area, 75, 280, 286
    - Plot Stamp On option, 298
    - Plot Style Table (Pen Assignments) area, 281, 289, 293, 294
    - Plot to File option, 298
    - Plot Upside-Down option, 299
    - Plot with Plot Styles check box, 281, 292
    - Preview button, 282
    - Printer/Plotter area, 279, 297–298, 300
    - Properties button, 297
    - Scale drop-down list, 283
    - Shaded Viewport option, 299

- Plot Screening and Fill Patterns.dwg file, 295
- Plot Style Manager, 290
- Plot Style Table Editor dialog box, 290
- Plotter Configuration Editor dialog box, 297–298, 300
- Plotter Manager, 278, 300
- plotting
  - adding plotter, 278
  - adding printer, 278
  - aesthetic of plotted drawing, 353
  - annotation, 78
  - area of drawing, 298
  - assigning plot style by layer, 109–110, 114
  - background processing, 299
  - centering plot, 65, 280, 299
  - color, 287–295, 290, 300, 355–356
  - confirmation notification, 66
  - convention, 299
  - creating plot style, 289–291
  - dimension, 250
  - dithering, 294
  - driver, plotter, 297
  - driver, printer, 276, 278, 300
  - DWF file, 373–376
  - ePlotting, 372–374
  - file, to, 298
  - generating plot, 66
  - layer, 109–110, 114, 356
  - layout, 92–97, 281, 284–287, 293–294, 295–296
  - legal precedence over DWG file, 241
  - limits, specifying, 65
  - lineweight, controlling, 67, 287–289, 290, 292–294
  - log, 300
  - model space, 64–67, 279, 285, 289, 298
  - monochrome, 279–281, 287, 288, 294, 389
  - named plot style, 287, 289, 290, 294
  - offset, 65, 280, 286, 299
  - outsourcing, 295, 375
  - paper sheets, to multiple, 78
  - paper size, specifying, 65, 94, 280, 286
  - paper space, attaching to plot style, 289
  - paper type, specifying, 297
  - previewing, 66, 281, 282–283, 287
  - report, generating, 300
  - saving plot configuration with drawing, 67
  - scale, 280, 283–284, 286, 300, 374
  - screening, 287, 288, 295, 356
  - service bureau, 295, 375
  - sheet set, 347, 348
  - specifying plot style, 107
  - specifying plotter, 279, 286
  - specifying printer, 65, 93, 277, 279, 286
  - stamp, 298
  - standard, applying to
    - achieve appearance consistency, 355–356
  - system printer, 93, 276, 277, 300
  - table, plot style, 281, 288–291, 293, 300, 348
  - template, plot style, 82, 289
  - text, 218, 250
  - title block, 78, 94
  - transmitting plot style over Internet, 365
  - troubleshooting, 299–300
  - upside-down, 299
  - view, 92, 298
  - viewport, shaded, 299
  - PLT files, 363, 375–376
  - PNG files, 390
  - PNGOUT command, 390
  - point
    - arc center point, specifying, 147, 148
    - arc endpoint, specifying, 140, 147, 149
    - arc second point, specifying, 141, 147, 148
    - arc start point, specifying, 147, 148
    - block base/insertion point, 307, 308, 314, 319, 322
    - break point, 185
    - circle center point, specifying, 146
    - circle, 2P, 145
    - circle, 3P, 145
    - coordinate origin point, 24
    - corner point, 51, 52, 142–143
    - curve start point, specifying, 147, 148
    - described, 155
    - dimension origin point, 253, 254
    - displacement base point/second point, 170, 172, 177
    - display size, 156–157
    - ellipse center point, specifying, 149
    - ellipse endpoint, specifying, 149–150
    - grip endpoint, 191, 195
    - hatching origin point, 274
    - line, defining on, 136
    - line endpoint, specifying, 136, 139
    - line start point, specifying, 136, 139
    - object, 155
    - pixel, single, 156
    - polygon center point, specifying, 55, 143

- polygon corner point, specifying, 51, 52, 142–143
- polyline endpoint, specifying, 139
- polyline start point, specifying, 139
- rectangle corner point, specifying, 142–143
- rotation base point, 178
- scaling base point, 179
- snap point, 124–127, 128, 155
- spline endpoint, specifying, 151
- spline start point, specifying, 151
- style, 156
- text insertion point, 222, 234
- zooming to window
  - diagonal points, 202
- POint command, 133, 157
- Point Style dialog box, 156–157
- pointer, dynamic, 27
- polar
  - array, 179–180
  - coordinate, 122, 123
  - snap, 121, 130
  - tracking, 25, 121, 129, 175
- polygon. *See also* rectangle center point, specifying, 55, 143
  - circle, drawing relative to, 55, 143–144
  - circumscribed option, 55
  - corner point, specifying, 51, 52, 142–143
  - described, 143
  - inscribed option, 55
  - Ortho mode, 55–56
  - polyline, as, 134, 144
  - regular, 143
  - selection, polygonal, 165, 166–167
  - sides, specifying number of, 32, 55, 143
  - POLygon command, 32, 49, 132, 134, 143–144
- polyline
  - curved, 138, 140–141
  - described, 134
  - endpoint, specifying, 139
  - exploding, 138, 382
  - extending, 182–184
  - filletting, 53
  - grip, 138
  - joining, 187–188
  - offset, 180–181
  - polygon as, 134, 144
  - segment, 137–139
  - spline, converting to, 133
  - splitting, 184–185
  - start point, specifying, 139
  - trimming, 182–184
  - width, specifying, 139
- Portable Document Format (PDF), 386, 388–389
- precision
  - accuracy versus, 120
  - coordinate, 84, 121
  - distance entry, 121, 129
  - double floating-point, 209
  - DWF file, 372
  - error multiplication
    - caused by lack of, 120
  - geometry, 121
  - gross, 84
  - importance of, 120–121, 381
  - manual drawing environment
    - compared, 10
  - measurement unit
    - precision, specifying, 73, 84
  - Ortho mode, 121
  - polar tracking, 121
  - saving drawing, precision maintained when, 208–209
  - snap, 121, 129
- previewing
  - array, 59
  - dimension style, 250
  - hatching, 63, 268
  - plot, 66, 281, 282–283, 287
- previous selection mode, 165
- printer
  - adding, 278
  - driver, 276, 278, 300
  - specifying, 65, 93, 277, 279, 286
  - system, 93, 276, 277, 300
- Printer Support File Path⇨
  - Plot Style Table Search Path, 289
- printing. *See* plotting
- Properties palette
  - display when toggled on, 38
  - hatch property, editing using, 274
  - locking, 36
  - property change
    - functionality, 197
    - toggling on/off, 105
- Properties toolbar
  - choosing as property change tool, 197
  - Color Control drop-down list, 109
  - Linetype Control drop-down list, 109
  - Lineweight Control drop-down list, 109
  - Plot Style Control drop-down list, 109
  - position, default, 22, 23
- PSLTSCALE system variable, 80
- PSpace command, 97
- Publish dialog box, 375–376, 378
- Publish Drawing Sheets dialog box, 375
- Publish⇨Publish to Plotter, 347
- publishing drawing to Web, 363, 372, 376
- PURge command, 317

## • Q •

QDIM command, 256  
 qLeader command, 260–263  
 QNEW command, 82, 99  
 Quadrant snap mode, 126  
 QuickCalc feature, 37, 78  
 Quickstart help, 297

## • R •

radius  
 block rotation, 322  
 circle, 54, 145, 146  
 dimension, radial, 243  
 fillet, 52–53, 186  
 RAL color, 112  
 raster image  
 attaching to drawing, 332–334  
 bitmap, 304  
 BMP, 386, 390–391  
 described, 304, 385  
 exchanging data with  
 other software using, 385, 386, 390–391, 393  
 JPEG, 390  
 PNG, 390  
 TIFF, 390  
 transmitting over Internet, 365, 370  
 RAY command, 132, 134–135  
 REctang command, 51, 52, 132, 134, 142–143  
 rectangle  
 array, rectangular, 180  
 coordinate, rectangular, 122, 123  
 corner point, specifying, 142–143  
 cursor, dashed  
 rectangle, 61  
 drawing, 49–53, 132, 134, 142–143  
 offset, 52  
 polyline, as, 134, 144  
 spacing object group in  
 rectangular pattern, 58–60  
 square, 143  
 stretching, 60–63  
 Red Green Blue (RGB)  
 color, 112  
 Redraw command, 210  
 REFEDIT command, 312  
 Reference Manager feature, 363, 370–371  
 regen (regeneration), 209–210  
 REgenAll command, 210  
 REGENAUTO system  
 variable, 209  
 Registry, system variable  
 storage in, 40  
 Rename and Renumber  
 Sheet dialog box, 342  
 Rename and Renumber  
 View dialog box, 346  
 resource drawing, 336, 338, 344–347. *See also*  
 sheet set  
 revision cloud, 133, 145, 153–155  
 RGB (Red Green Blue)  
 color, 112  
 Rich Text Format (RTF), 227, 386, 394  
 rollover highlighting, 165  
 ROMANS.SHX font, 215, 217  
 rotating object  
 block, 311, 322  
 grip, using, 189, 190, 193  
 ROTate command, using, 168, 178  
 text, 222  
 round-trip transfer, 387.  
*See also* software,  
 exchanging data with  
 other  
 RTF (Rich Text Format), 227, 386, 394  
 R12 DXF format, 13, 386

## • S •

Save Drawing As dialog  
 box, 49, 98, 378  
 SAVETIME system  
 variable, 38  
 saving drawing  
 automatic, 38, 384  
 backup file creation,  
 automatic, 53  
 importance of saving  
 regularly, 383–384  
 naming file, 49, 99  
 plot configuration, 67  
 precision maintained  
 when, 208–209  
 storage location,  
 specifying, 49, 99  
 template, as, 82, 98–99  
 scale  
 architectural, 75, 77  
 base point, 179  
 block, 307–308, 311  
 changing, 179  
 choosing appropriate,  
 71, 74–75  
 copying scaled object, 179  
 determining existing scale  
 factor, 220  
 dimension, 89–91, 246,  
 250, 251–252, 263  
 drawing scale, 74, 91, 218  
 entering scale factor, 75,  
 90–91, 179  
 ePlot, 374  
 grid spacing, coordinating  
 with, 87  
 grip, scaling object using,  
 189, 190, 193  
 hatching, 179, 270, 272  
 importance of knowing  
 current, 382  
 leader, 263  
 linetype, 80, 89–90  
 notation, 74, 218  
 paper, for, 70, 71, 75, 76–79

- plot, 280, 283–284, 286, 300, 374
- removing unused scaling unit, 76
- resource drawing, 345
- revision cloud, 155
- sheet set, 345
- standard, 71, 74
- text, 179, 218, 219, 232
- viewport, 95, 207
- zooming to scale
  - percentage, 202
- S`Scale` command, 168, 178–179
- S`CALETEXT` command, 179, 232
- screen capture, exchanging data with other
  - software using, 393–394
- screening, 287, 288, 295, 356. *See also* plotting
- second point
  - arc, 141, 147, 148
  - displacement, 170, 172
- Security Options dialog box, 378
- Select Color dialog box, 51, 111, 112
- Select internal point prompt, 268
- Select Linetype dialog box, 112
- Select objects
  - prompt, 165
- Select Template dialog box, 47, 81, 82
- selection
  - ALL object selection
    - mode, 165
    - box, 162–164
    - command-first, 160, 165
    - crossing object, 60–62, 162–164, 165, 166, 176–177
    - editing, selection-first, 159, 160, 161
    - entire object, 161–162
    - erasing, 166–167
    - fence object, 165, 184
    - group of objects, 162
    - last object, 165
    - one-by-one, 161–162
    - polygon area, 165, 166–167
    - previous selection
      - mode, 165
    - removing object from, 164
    - rollover highlighting, 165
    - sheet set, 343
    - window object, 162, 165
  - semicircle, 147
  - service bureau plotting, 295, 375
  - S`ETvar` command, 39–40
  - sheet set
    - adding sheet, 341–342
    - archiving, 339, 368
    - attribute, 347
    - block, 316
    - consistency, importance of, 358
    - copying, 340
    - creating, 338, 339–340, 343–344
    - description, entering, 339
    - DWF file, including in, 373, 374
    - DWG file, 344
    - editing, 340
    - grouping, 343
    - importing, 341–342
    - index, 338, 339, 342
    - label block, 347
    - layout, 337, 340, 341
    - naming, 339, 342, 344
    - opening, 338
    - organizational tool, as, 335–336
    - plotting, 347, 348
    - publishing, 339, 347
    - renumbering, 342
    - resource drawing, 336, 338, 344–347
    - scale, 345
    - selection, 343
    - storage location, 339, 343
    - subset, 341, 342–343
    - table, sheet list, 338, 342, 347–349
    - template, 338, 343
    - transmitting over Internet, 339, 368
    - view, 336–337, 345–346, 347
  - Sheet Set Manager palette described, 37
    - display when toggled on, 38
    - Publish option, 376
    - Resource Drawings tab, 336, 338, 345
    - Sheet List tab, 337, 338, 341, 343, 348
    - toggling on/off, 336
    - View List tab, 336–337, 338, 339, 346, 347
  - Sheet Set Properties dialog box, 343
  - shortcut key, 20, 29–30
  - SHX files, 215–216, 217, 250, 365, 367
  - SI (Système International d’Unites), 72
  - signature, digital, 364, 377–378
  - SIMPLEX.SHX font, 215
  - SnagIt software, 393
  - snap
    - Center mode, 126, 128
    - curve, 126
    - dimension, 253, 254, 255, 261
    - grid, to, 24, 48–49, 87–89
    - grip, 189
    - Intersection mode, 126
    - leader, 261
    - menu, displaying, 126
    - Nearest mode, 126
    - NODE mode, 155
    - object snap tracking, 25
    - overriding, 124, 130
    - Perpendicular mode, 126

- snap (*continued*)
  - point, 124–127, 128, 155
  - Polar, 121, 130
  - precision, 121, 129
  - Quadrant mode, 126
  - running object, 25, 124, 127–128
  - spacing, specifying, 129
  - text, 222, 223
- SNAPMODE system
  - variable, 80
- SNAPUNIT system
  - variable, 80
- software, exchanging data with other
  - DWF file, using, 386
  - DWG file, using, 386–387
  - Excel, 236, 386
  - OLE, using, 391–393
  - PDF, using, 386, 388–389
  - round-trip transfer, 387
  - RTF file, using, 386, 394
  - screen capture, using, 393–394
  - TXT file, using, 386, 394
  - Windows clipboard, using, 386, 391
  - WMF file, using, 386, 389
  - Word, 386, 393
- software, third-party
  - add-on, 13, 15
- spacing object group using
  - array, 58–60
- SPell command, 237
- spline
  - drawing, 150–152
  - editing, 151
  - endpoint, specifying, 151
  - joining, 187–188
  - polyline, converting to, 133
  - splitting, 184–185
  - start point, specifying, 151
- SPLine command, 133, 145, 150–152
- SPLinEdit command, 151
- square, drawing, 143. *See also* rectangle
- standard. *See also specific standard organization*
  - choosing appropriate, 353–354
  - compliance, monitoring, 359–360
  - Configure Standards
    - feature, implementing using, 359
  - consistency, role in achieving, 351, 355–356
  - DesignCenter, implementing using, 358
  - dimension, 240, 244, 358
  - documenting, 355
  - DWS file, 26, 360
  - hatching, 269, 358
  - importance of implementing, 352, 383
  - industry-specific, 354
  - layer, 354, 356–357, 358
  - paper size, 76, 77
  - plotting, 355–356
  - project-specific, 354
  - scale, 71, 74
  - text, 215, 357
  - Tool Palettes interface, implementing using, 358
- Standard Colors dialog
  - box, 51
- Standard toolbar
  - DesignCenter button, 119
  - Markup Set Manager button, 362
  - Match Properties button, 197
  - Plot button, 279
  - position, default, 21, 23
  - Properties button, 105
  - QNEW button, 99
  - Undo button, 167
  - Zoom Realtime button, 57
- STANDARDS command, 359
- starting AutoCAD, 47
- state of drawing, storage in DWG file, 383
- status bar
  - button display mode, 27
  - Communication Center button, 26
  - customizing, 26–27
  - DYN button, 25
  - Grid button, 24
  - Lock/Unlock Toolbar Palette Positions button, 26
  - LWT button, 25
  - Maximize/Minimize Viewport button, 26
  - MODEL button, 25–26, 285
  - ORTHO button, 24
  - OSNAP button, 25
  - OTRACK button, 25
  - padlock icon, 23
  - PAPER button, 25–26, 285
  - POLAR button, 25
  - Snap button, 24
  - xref icon, 26, 325
- STB (Style Table) files, 289, 290, 365
- stretching object
  - grip, using, 189–190, 194–197
  - Stretch command, using, 60–63, 168, 169–170, 174–177
- style
  - assigning plot style by layer, 109–110, 114
  - color-dependent plot style, 287, 288–289, 290
  - creating plot style, 289–291
  - dimension, 239, 245–253, 258, 328, 358
  - model space, attaching to plot style, 289
  - named plot style, 287, 289, 290, 294
  - paper space, attaching to plot style, 289
  - point, 156
  - specifying plot style, 107
  - table, plot style, 281, 288–291, 293, 300, 348

- template, plot style, 82, 289
  - text, 214–217, 233–234, 250, 328, 357
  - transmitting plot style over Internet, 365
  - Style Table (STB) files, 289, 290, 365
  - Styles toolbar
    - Dim Style Control list, 254
    - Dimension Style Manager button, 248
    - position, default, 21, 23
  - SV\$ files, 384
  - symbol
    - collection, storing in block library, 309
    - table display, 119
  - system requirement, 15
  - system variable, 38–41. *See also specific system variable*
  - Système International d'Unités (SI), 72
- T •**
- table
    - block table, 304, 309
    - plot style, 281, 288–291, 293, 300, 348
    - sheet list, 338, 342, 347–349
    - text, 232–235, 316
  - Table Style dialog box, 233, 234, 348
  - TableStyle command, 233–234
  - Tangent-Tangent-Radius (ttr) circle, 145
  - TechSmith SnagIt software, 393
  - template
    - advantages/disadvantages, 70
    - creating drawing from template, 47–49, 80–83
    - creating template from drawing, 82, 98–100
    - default, 47, 80, 99
    - layout, creating from, 95
    - listing all available templates, 47
    - measurement system, 47, 80
    - measurement unit, specifying, 99
    - naming, 98
    - plot style, 82, 289
    - sheet set, creating from, 338, 343
    - storage location, 98, 99–100
    - title block, 82
  - text. *See also font*
    - adding at end of drafting process, 213
    - aligning, 214, 223
    - background mask, 227–228
    - block, 312, 314, 316, 318
    - case, 226
    - color, 228, 233–234
    - copying, 118, 232, 236
    - CSV file, exporting, 236
    - dimension, 242, 250–251, 259
    - editing, 223, 232, 234–236, 259
    - field, 228–229, 235, 316
    - front, bringing to, 228
    - grip, 232
    - height, 214, 217–220, 222, 224–226, 250
    - importing, 227, 236
    - indenting, 230, 231
    - insertion point, 222, 234
    - justifying, 214, 221, 222, 224–225, 232
    - layer, 105, 214
    - leader, 262–263
    - line, adding blank, 231
    - line break, 221, 226
    - list, 229–232
    - multiline, 214, 220, 224–227
    - paragraph, 214, 220, 224–227
    - plotting, 218, 250
    - rotating, 222
    - RTF, 227, 386, 394
    - scale, 179, 218, 219, 232
    - single-line, 214, 220, 221–223
    - snap, 222, 223
    - spacing, 231
    - spelling, checking, 236–238
    - standard, 215, 357
    - style, 214–217, 233–234, 250, 328, 357
    - tab, 230, 231
    - table, 232–235, 316
    - underlining, 229
    - wrap, 221, 224, 226, 230, 232
  - TEXT command, 214, 220–223
  - Text Formatting toolbar, 225, 226, 227
  - Text Style dialog box, 214, 215, 216
  - TEXTTTOFRONT command, 228
  - third-party application, 13, 15
  - 3D, AutoCAD LT support, 14
  - 3P (3-Point) circle, 145
  - TIFF files, 390
  - TIFOUT command, 390
  - title bar, 20
  - title block
    - choosing appropriate, 71
    - DWG file, saving to separate, 79
    - font, 215
    - layout, 94–95
    - panning, 205, 208
    - paper, fitting to, 94
    - plotting, 78, 94
    - reusing, 79
    - template, 82
    - xref, applying to, 79, 94
    - zooming, 205, 208
  - TOLERANCES command, 253
  - Tool Palettes interface, 36, 38, 358

- toolbar. *See also specific toolbar*
    - closing, 22
    - customizing, 23
    - locking, 23, 26
    - moving, 22
    - opening, 22
  - ToolPalettes command, 358
  - Tools⇨Attribute
    - Extraction, 316
  - Tools⇨Block Edit, 319
  - Tools⇨CAD Standards⇨
    - Check, 359
  - Tools⇨CAD Standards⇨
    - Configure, 359
  - Tools⇨CAD Standards⇨
    - Layer Translator, 358
  - Tools⇨DesignCenter, 118
  - Tools⇨Folder Options⇨
    - View, 99
  - Tools⇨Options⇨
    - Display⇨Colors, 391
  - Tools⇨Options⇨Files⇨
    - Template Settings, 99
  - Tools⇨QuickCalc, 78
  - Tools⇨Security
    - Options, 378
  - Tools⇨Spelling, 237
  - Tools⇨Tool Palettes
    - Window, 358
  - Tools⇨Wizards⇨Create
    - Layout, 92
  - tooltip feature
    - command display in, 27
    - described, 23
    - dynamic, 27, 28, 29, 169
    - feedback display in, 46
  - transparency
    - command, transparent, 33
    - display quality, 37
  - TRim command,
    - 168, 182–184
  - TTF (TrueType) font, 215,
    - 365, 367, 370
  - ttr (Tangent-Tangent-Radius) circle, 145
  - 2P (2-Point) circle, 145
  - TXT files, 227, 386, 394
  - Txt.shx font, 250
- u •
- underscore ( \_ ) command
    - prefix, 33
  - undoing
    - copy operation, 172
    - erase operation, 167
    - extend operation, 183, 184
    - trim operation, 183, 184
  - URL (Uniform Resource Locator), 369
- U •
- variable. *See also specific variable*
    - dimension, 245
    - system, 38–41
  - VBA (Visual Basic for Applications), 15
  - vector
    - displacement,
      - 170, 171, 176
    - image, 304, 332, 385
  - version
    - AutoCAD LT, 13, 14
    - block, version
      - requirement when working with, 304
    - DWF version used by AutoCAD, 373
    - DWG file backward compatibility, 12, 13, 15
    - upgrading from previous, 14–15
  - view. *See also viewport*
    - category, 204, 347
    - described, 200
    - layer configuration,
      - saving with, 204
    - naming, 203–204, 337, 346
    - number, 346
    - plotting, 92, 298
    - redrawing, 210
    - refreshing, 99, 210
    - restoring, 205
    - sheet set, 336–337, 345–346, 347
    - title, 346
    - transition, smooth view, 203
  - View dialog box, 203
  - View⇨Named Views, 203
  - View⇨Redraw, 210
  - View⇨Refresh, 99
  - View⇨Regen, 210
  - View⇨Regen All, 210
  - View⇨Viewports⇨New Viewports, 96
  - View⇨Zoom⇨All, 49
  - View⇨Zoom⇨
    - Extents, 279
  - View⇨Zoom⇨Previous, 208
  - viewport. *See also view*
    - described, 34
    - layout, 95, 96, 205, 207–208
    - locking, 208
    - maximizing/minimizing, 26, 208
    - model space, 207
    - panning in, 207
    - paper space, 95
    - plotting shaded viewport, 299
    - regen, 210
    - scale, 95, 207
    - sheet set, 345–346
    - zooming in, 207
  - Viewports dialog box, 96
  - Viewports toolbar, 76
  - Visual Basic for Applications (VBA), 15
  - VPMAX command, 208
  - VPMIN command, 208
  - VuePrint software, 390

## • W •

Wblock command, 309, 328  
 Web, publishing drawing to,  
 363, 372, 376  
 Welding Fixture-1.dwg  
 file, 92  
 window  
 maximizing/minimizing, 20  
 selection mode, window  
 object, 162, 165  
 zooming to window  
 diagonal points, 202  
 windowing, implied, 162  
 Windows  
 Add Printer Wizard, 278  
 clipboard, 173–174,  
 386, 391  
 Registry, system variable  
 storage in, 40  
 support, 9–10, 13,  
 14, 18–19  
 WinZip software, 367  
 WMF (Windows MetaFile),  
 386, 389  
 WMFIN command, 389  
 Word, exchanging data  
 with, 386, 393  
 WPolygon selection mode,  
 165, 166–167  
 WS\_FTP software, 369

## • X •

XCLIP command, 331  
 XLine command,  
 132, 134–135  
 XNOTIFYTIME system  
 variable, 325  
 XOPEN command, 328  
 xref (external reference)  
 attaching, 326–327  
 binding, 330  
 block, converting to, 330

block versus, 304, 325, 326  
 child drawing, 325, 371  
 clipping, 331  
 consistency, importance  
 of, 358  
 described, 325  
 detaching, 330  
 DWG file, 26  
 editing, 306, 328  
 file, 328  
 host drawing, 325  
 Internet, transmitting  
 over, 363, 365, 370  
 layer, 328  
 linetype, 328  
 listing all xrefs, 330  
 notification display, 325  
 opening xrefed drawing,  
 328, 330  
 organizational tool,  
 as, 331  
 overlaying, 327  
 packaging with drawing,  
 importance of, 331  
 parameter, 327  
 parent drawing, 325, 371  
 path, 327, 328–330  
 reloading, 330  
 report, generating,  
 316, 329  
 status bar xref icon,  
 26, 325  
 storage location, 326,  
 327, 328–330  
 text style, 328  
 title block, applying to,  
 79, 94  
 unloading, 330  
 update, automatic, 326  
 Xref Manager dialog box  
 accessing, 326  
 Attach button, 327  
 Bind option, 330  
 Detach option, 330

List of external references  
 option, 330  
 Open button, 328, 330  
 Path Type drop-down  
 list, 329  
 Reload option, 325, 330  
 Unload option, 330  
 XREFNOTIFY system  
 variable, 325

## • Z •

zipping file for Internet  
 transmittal, 367  
 zooming  
 extending, 202  
 grid, entire, 49  
 in, 199  
 layout, 205–207  
 limits, to area defined  
 by, 202  
 magnifying glass  
 cursor, 57  
 model space, in, 207  
 mouse, using, 201  
 object, to fill screen  
 with, 203  
 out, 199  
 panning, using in  
 conjunction with,  
 58, 200–201  
 paper space, in,  
 205, 207, 208  
 real-time, 57–58,  
 200, 201, 202  
 regen, 209  
 returning to previous  
 zoom, 200, 203, 208  
 scale percentage, to, 202  
 title block, 205, 208  
 transition, smooth  
 view, 203  
 viewport, in, 207  
 window diagonal points,  
 to area defined by, 202

