

Index

Special Characters

* wildcard, 649–650
/? switch, 662, 979, 981–982
? wildcard, 650
| symbol, 667
< symbol, 666
> symbol, 667
>> symbol, 667

Numerics

3DNow! technology, 135
3 1/2-inch floppy disk, 238
4-pin peripheral connector, 286
5 1/4-inch floppy disk, 238
6-pin PCI Express (PCIe) connector, 287–288
8-pin (RJ-45) connector, 312–313
8-pin PCI Express (PCIe) connector, 287–288
8.3-character naming convention, 615–617
9-pin serial connector, 316
10 Gigabit Ethernet standards, 902
10Base2 Ethernet, 307, 901
10Base5 Ethernet, 307, 901
10BaseFL Ethernet, 901
10BaseT Ethernet, 900
+12V2DC (12-volt power connector), 286–287
12-volt power connector (+12V2DC), 286–287
16-bit applications, 729–734, 839
24-pin Molex main power connector, 284
25-pin connector, 316
32-bit (x86) processor, 526
32-bit applications, 726–729
36-pin Centronics connector, 312, 399–400
50-pin Centronics connector, 312
64-bit (x64) processor, 526
64-bit applications, 727–729
72-pin SIMMs, 160–162
100/1000 network card, 337
100BaseFX Ethernet, 901
100BaseT Ethernet, 901
404 error message, 1029
802.11 networking standard, 904, 1031–1032

802.11a networking standard, 933
802.11b networking standard, 904, 933–934
802.11g networking standard, 905, 934–935
802.11n networking standard, 905, 935
802.3 networking standard, 904
802.5 networking standard, 904
1000BaseLX Ethernet, 901
1000BaseSX Ethernet, 901
1000BaseT Ethernet, 901
2009 Examination Objectives, CompTIA A+ Exam Reference Matrix, 1117–1124

A

/A switch, 634, 636
-A <ipaddress> switch, 981
-a switch, 982
A+ exams
 arranging to take, 13
 certification, purpose of, 9–10
 day of, 13–16
 objectives of, 10–12
 overview, 9
 pass level, 16
 preparing for, 12
absolute paths, 650–653
AC (alternating current) adapter, 289–291, 440, 447–448
AC (alternating current) port damage, 448
Accelerated Graphics Port (AGP), 55, 74–75, 103
accelerated video cards, 348
access methods, Internet, 1026–1027, 1029–1032
access points, 929, 943
access time, 213
access tokens, generating, 1051–1052
Accessibility Options applet, 555
Accessibility Options dialog box, 330–331
accessibility options, keyboard, 329–331
 .ace extension, 626
ACPI (Advanced Configuration and Power Interface), 444
activating Windows, 591, 596–597

- Active disk status, 260
- active heat sink, 143
- active matrix display, 449
- active partition, 248–250
- Active Server Pages (ASP), 1011
- activity light, network card, 907
- actuator arm, 211
- ad hoc mode, 929–930
- adapter cards, 52
- adapter unit interface (AUI) port, 896
- adaptive exams, 10–11, 15
- Add a Network Place Wizard, 554
- Add Hardware applet, 555
- Add Hardware Wizard, 234, 703
- Add or Remove Programs applet, 555, 721–724
- Add or Remove Programs dialog box, 605–606
- Add Printer Wizard, 404–407, 409–411, 995
- Add/Remove Hardware applet, 555
- address bus, 115–116
- address lines, 115
- Address Resolution Protocol (ARP), 977–978
- address space, 729
- Administrative Tools applet, 555
- administrative tools, Windows, 763–764
- Administrator account, 593–594
- Administrator password, 194, 581–582, 918, 936
- ADSL (Asynchronous Digital Subscriber Line), 56–57, 1030
- Advanced Attributes dialog box, 633, 635–636, 642
- Advanced button, PIF Properties window, 737
- Advanced Configuration and Power Interface (ACPI), 444
- Advanced Micro Devices (AMD) processor, 135–138
- Advanced Packaging Tool (APT), 532
- Advanced Power Management (APM), 444
- Advanced Programmable Interrupt Controller (APIC), 370
- Advanced Research Projects Agency (ARPA), 1007–1008
- Advanced RISC Computing Specification (ARC) pathnames, 682–683
- Advanced Technology Attachment (ATA) standard, 49–50, 217
- adware, 1103
- Aero desktop, Windows Vista, 530
- Agena processor, 137
- AGP (Accelerated Graphics Port), 55, 74–75, 103
- air intake areas, 474
- airflow. *See* ventilation
- Alerter service, 769
- alkaline battery, 441
- /all switch, 979
- allocation unit, 243
- Allocation Unit Size field, Format dialog box, 257
- alphanumeric keys, 326
- alternating current (AC) adapter, 289–291, 440, 447–448
- alternating current (AC) port damage, 448
- Always Show Extension option, Edit File Type dialog box, 623
- ambient room temperature, 473
- AMD (Advanced Micro Devices) processor, 135–138
- amps (amperes), 280
- AMR (Audio/Modem Riser), 104–105
- analog audio/video connectors, 320
- analog multimeter, 492–493
- .ani extension, 627
- answer file, 597–600
- antistatic bag, 38
- antistatic mat, 493–494
- antistatic strap, 37–38, 493–494
- antivirus software, 482, 1092, 1099–1102, 1107
- APIC (Advanced Programmable Interrupt Controller), 370
- APIPA (Automatic Private IP Addressing), 969
- APM (Advanced Power Management), 444
- Apple menu, 535
- Application layer, OSI, 905, 1011–1012
- Application log, Event Viewer, 796

- application service provider (ASP), 1011
- application support, Windows, 573
- applications
 - installing, 720–723
 - MS-DOS based, 734–743
 - multitasking, 724–725
 - overview, 719
 - removing, 723–724
 - troubleshooting, 745–746, 838–840
 - Windows, 726–745
- Applications tab, Task Manager, 758
- APT (Advanced Packaging Tool), 532
- ARC (Advanced RISC Computing Specification) pathnames, 682–683
 - .arc extension, 626
- Archive attribute, 631–632, 659
- arguing with customers, 27
- arguments (data), 667–668
 - .arj extension, 626
- ARP (Address Resolution Protocol), 977–978
- ARPA (Advanced Research Projects Agency), 1007–1008
- ARPANET, 1007–1008
- ASP (Active Server Pages), 1011
- ASP (application service provider), 1011
 - .asp extension, 629
 - .aspx extension, 629
- ASR (Automatic System Recovery), 866–868
- Asynchronous Digital Subscriber Line (ADSL), 56–57, 1030
- AT commands, 334–335
- AT connector, 79
- AT keyboard, 327
- ATA (Advanced Technology Attachment) standard, 49–50, 217
- ATA command, 334
- ATA-2/EIDE standard, 217–218
- ATAPI (ATA Packet Interface) specification, 218
- ATDP <number> command, 334
- ATDT <number> command, 334
- ATH command, 334
- Athlon 64 processor, 137
- Athlon 64 X2 processor, 137
- Athlon Mobile 64 processor, 137
- Athlon XP processor, 136
- ATL command, 334
- attacks. *See* security
- attended installations
 - Windows 2000, 575–586
 - Windows Vista, 591–597
 - Windows XP, 586–591
- attrib.exe command, 673, 640–641, 659–660
- ATX motherboard, 94–95, 282
- ATX power connector, 83–84, 284
- ATZ command, 334
- audible continuity test feature, multimeters, 492
- audio, troubleshooting, 507
- Audio CD status, 260
- Audio tab, Sound and Audio Devices Properties dialog box, 357
- Audio/Modem Riser (AMR), 104–105
- auditing, 944, 1081–1084, 1091
- AUI (adapter unit interface) port, 896
- authentication, 1050–1053
- authorization, 1053–1054
- auto ranging feature, multimeters, 492
- autoexec.bat boot process file, 688
- automated maintenance, 470
- Automated System Recovery Wizard, 867–868
- automatic display hold feature, multimeters, 493
- automatic power off option, multimeters, 492
- Automatic Private IP Addressing (APIPA), 969
- automatic switching, 281
- Automatic System Recovery (ASR), 866–868
- automatic update tools, 472
- Automatic Updates applet, 556, 833
- auto-restart errors, Windows, 831–833
 - /ax switch, 652

B

- /b switch, 652
- Baby AT motherboards, 91–93
- background printing, 408
- Background settings, PIF Properties
 - window, 741
- backing up
 - overview, 856–861, 1058–1059
 - restoring backups, 861–862
 - settings and files before changing, 20–21
 - tape drives, 241–242
- backlight functionality, 462
- back-probing power connectors, 514–515
- Backup Job Information window, 858–859
- Backup or Restore Wizard, 857, 861–862
 - .bak extension, 627
- Balanced Technology eXtended (BTX)
 - motherboard form factor, 95
- bar code reader, 340
- bare listing, 652
- barrel connector, 318
- BartPE disks, 873–874
- BartPE tools, 498
- Base 2 numbers, 616–617
- baseband transmission, 900
- Basic disk status, 260
- basic disks, creating, 250–252
- basic input-output system. *See* BIOS
- Basic Service Set Identifier (BSSID), 930
- basic-rate ISDN, 1031
 - .bat extension, 625, 665
- Batch File setting, PIF Properties
 - window, 737
- batch files
 - assembly, 672–673
 - autoexec.bat file, 688
 - getting directions, 666–667
 - locating command, 672
 - looping, 671–672
 - making decisions, 668–671
 - overview, 665
 - parameters and arguments, 667–668
 - rem statements, 672–673
 - starting file, 665–666
- batteries
 - CMOS, 73–74, 187, 193, 195, 442
 - disposing of, 41
 - laptop, 440–443, 462, 484–485, 516
 - overview, 73–74
 - troubleshooting, 512–515
- Battery Act, 41
- baud rate, 302–303, 510
- Bayonet Neill-Concelman (BNC) connector,
 - 313–314, 893–895
- BCD (Boot Configuration Database), 687,
 - 814–815
- BEDO (burst extended data output), 158
- beep codes, POST, 500
 - .bhx extension, 626
- bidirectional communication, 302
 - .bin extension, 627
- binary number system, 616–617
- biometric devices, 340
- BIOS (basic input-output system)
 - built-in testing software, 499
 - date and revision number, 197–198
 - ECHS, 214–215
 - LBA, 214–215
 - overview, 53, 58, 72–73
 - purpose of, 181–182
 - ROM, 153
 - security, 1048, 1067–1068
 - troubleshooting, 501
 - upgrading, 183–185
 - versions, 184–185, 198
- Bitmap fonts, 738
- blackouts, 292
- blanking plate, 457
- blowhole, 475
- Blue screen errors, Windows, 833–836
- Bluetooth, 455, 941–942
- Blu-ray discs, 240
- blurry monitor images, 508
 - .bmp extension, 628
- BNC (Bayonet Neill-Concelman) connector,
 - 313–314, 893–895
- body oils, 484
- Boot Configuration Database (BCD), 687,
 - 814–815
- boot disk, 36, 498, 847–848

boot errors, Windows, 601, 811–816
 boot files, Windows, 812–816
 boot floppy, 567–568
 boot partition, 680
 boot process
 memory, 691–694
 overview, 679
 POST process, 679–680
 system files, 687–691
 virtual memory, 691–694
 Windows 2000, 680–686
 Windows Vista, 686–687
 Windows XP, 680–686
 boot sector, 680
 boot sequence, 193–194, 199
 bootable CD, 568
 boot.ini file, 681–682, 812–814
 bootlog, 850–851
 bootmgr file, 687, 814
 bottlenecks, finding in Windows, 751–752
 bridges, 909–910
 brightness, monitor, 452, 507
 British Naval Connector (BNC). *See*
 Bayonet Neill-Concelman
 broadband cable, 56–57, 1030
 broadcast messages, 977
 brownouts, 292
 Browse in Same Window option, Edit File
 Type dialog box, 623
 browse master, 999–1000
 browser, Internet. *See* Internet Explorer
 BSD socket, 1013
 BSD Unix, 532
 BSSID (Basic Service Set Identifier), 930
 BTX (Balanced Technology eXtended)
 motherboard form factor, 95
 buffer, 907, 1045
 built-in network adapter settings, 198–199
 burning CDs, 238–239
 burnt pixels, 508
 burst extended data output (BEDO), 158
 Bus Enumerator, 711–712
 bus mastering, 98–100
 bus topology, 885–886
 buses, 50, 55, 96–105

C

/C switch, 634
 /c switch, 659
 -c switch, 981
 .cab extension, 627, 803
 cable adapters, 318–319
 cable Internet access method, 1030
 cable testers, 498, 898
 cables. *See also names of specific cables*
 baud rate, 302–303
 checking for damage, 509
 eSATA, 236
 length of, 509
 orientation of, 308–309
 problems with AC adapter, 448
 SATA, 235
 troubleshooting, 498
 types of, 305–308
 cache, system restore, 864
 cache memory
 IDE devices, 216
 increasing motherboard performance,
 106
 Level 1, 166
 Level 2, 167
 Level 3, 167
 overview, 69–70, 116–117, 144, 166
 SRAM, 155
 /CACHESIZE=x switch, 800
 Caching option, Sharing dialog box, 987
 calibration, printer, 486
 call-waiting, 509
 camera, 427–431
 Cancel All Documents option, print queue
 menu, 417
 canister, 35
 capacitive keyboard, 326
 capacitors, laptop, 516
 card services, laptop, 457
 carpet spray, 38
 Carrier Sense Multiple Access/Collision
 Avoidance (CSMA/CA), 899
 Carrier Sense Multiple Access/Collision
 Detection (CSMA/CD), 898–899

- cascading IRQs, 368–373
- case cracker, 496
- case standoffs, 495
- casing, 55, 480
- CAT1 (Category 1) cable, 306
- CAT2 (Category 2) cable, 306
- CAT3 (Category 3) cable, 306
- CAT4 (Category 4) cable, 306
- CAT5 (Category 5) cable, 307
- CAT6 (Category 6) cable, 307
- CAT7 (Category 7) cable, 307
- cathode ray tube (CRT) monitor, 39–41, 351–352
- CCD (charge-coupled device), 424–425, 427
- CD drive, 483, 505
- CD included with book, 1113–1116
- CD Recordable (CDR), 239
- CD ReWritable (CDRW), 238–239
 - .cda extension, 629
- CDR (CD Recordable), 239
- CD-ROM (compact disc–read-only memory)
 - booting from, 193, 575–577
 - installation failures, 601
 - overview, 238–239
- CDRW (CD ReWritable), 238–239
- Celeron processor, 130
- cellular Internet access method, 1032
- central processing unit (CPU), 48–49. *See also* processor
- centralized administration, 882
- Centronics 36-pin connector, 312, 399–400
- Centronics 50-pin connector, 312
- CERN (Conseil Européen pour la Recherche Nucléaire), 1009
- CF (CompactFlash) card, 241–242
- CFX v1.3 (Compact Form Factor), 289
- CGA (Color Graphics Adapter), 347
- chairs, computer, 42–43
- Change Icon button, PIF Properties window, 737
- channel assignments, DMA, 373–374
- charge-coupled device (CCD), 424–425, 427
- chassis, 37–38
- chdir command, 653–654
- Check Disk (chkdsk.exe) utility, 269–270, 482, 658–659, 674, 783–784
- checking versions, 542–545
 - /checkupgradeonly switch, 576
- chemicals, 472
- chip creep, 480
- chip extractor, 34
- chip inserter, 35
- chip packaging, 69, 121–123, 144, 160–163
- chipsets, 53, 70–72
- chkdsk.exe (Check Disk) utility, 269–270, 482, 658–659, 674, 783–784
- choice statement, 669–671
- cipher.exe utility, 636–637
- classes
 - Bluetooth network device, 941
 - IP address, 963
- Classic environment, Mac OS X, 535
- classification, 1061–1062
- clean memory location, 694
- cleaning, 418, 443, 450–451, 472, 477–478, 480–486, 506–507
- cleaning blade, 393, 396
- client
 - defined, 881, 929
 - overview, 954–957
 - wireless network performance, 943
- client isolation, 940
- Client Service for Netware applet, 956–957
- client upgrade paths
 - to Windows 2000, 602
 - to Windows XP, 603
- client-server (server-based) network, 883–884
- clock multiplying, 126
- Close on Exit setting, PIF Properties window, 737
- clothing, 26
- cloths, cleaning, 472
- clusters
 - FAT file system, 243–244
 - FAT32 file system, 245–246
 - overview, 212, 272
 - .cmd extension, 625

- Cmd Line setting, PIF Properties window, 737
- /cmd:<command> switch, 576
- /cmdcons switch, 576
- cmd.exe utility, 647–649
- CMOS (complementary metal-oxide semiconductor)
 - advanced settings, 196–201
 - basic settings, 187–196
 - batteries, 73–74, 187, 193, 195, 442
 - overview, 54, 58, 155–156, 181, 185–187
 - RAM, 187
 - Save & Restore utility, 196
 - setup program, 186
 - troubleshooting, 501
 - Windows, 574
- CNR (Communication and Network Riser), 104–105
- coaxial network cabling, 892–896
- codecs, 431–432, 435
- cold swapping, 712
- color depth, video card, 56
- Color Graphics Adapter (CGA), 347
- color inkjet printer, 397
- color LCD, 449
- Color Quality settings
 - Desktop Properties dialog box, 349
 - Display Properties dialog box, 353
- colors, monitor, 508
- COM (communications) port, 75
- .com extension, 625
- combo card, 339
- command prompt
 - batch files, 665–673
 - cmd.exe, 647–649
 - command.com, 647–649
 - comparisons, 657
 - diagnostic utilities, 658–659
 - directory management, 649–657
 - edit, 662–665
 - file management, 654–657
 - miscellaneous, 659–662
 - navigating via, 554–555
 - overview, 647
 - setting file attributes, 639–641
- Command Prompt window, 555
- command shell, 1020–1021
- command.com utility, 647–649
- Comment field, Sharing dialog box, 987
- Commit charge, Task Manager, 755
- Communication and Network Riser (CNR), 104–105
- communication skills, 25
- communications (COM) port, 75
- compact disc–read-only memory. *See* CD-ROM
- Compact Form Factor (CFX v1.3), 289
- compact.exe utility, 633–634
- CompactFlash (CF) card, 241–242
- compatibility modes, Windows, 743–745
- complementary metal-oxide semiconductor. *See* CMOS
- compliance, 1061
- Components Wizard, 605–606
- Compress attribute, 632–634
- compressed air, 471, 482
- compression utilities, 626–627
- compression/decompression (codec) software, 431–432, 435
- CompTIA A+ Essentials Exam, 10–11
- CompTIA A+ Exam Reference Matrix, 1117–1124
- CompTIA A+ Practical Application Exam, 10–12
- CompTIA IT Pro Web site, 13
- CompTIA Web site, 13
- computer, defined, 47–48
- computer browser, 769, 999
- Computer Information section, Network Diagnostics tool, 798
- computer location settings, Windows Vista, 595
- Computer Management utility, Windows, 793–794
- computer name, 571, 581–582, 970–972
- Computer Name Changes dialog box, 971
- computer vacuum, 471–472
- Computer window, Windows, 551–553
- condensation, 473, 476
- confidentiality, 26

- config.sys file, 687–688
 - Configuration Manager, 711–712
 - configuration utilities, Windows, 784–792
 - Confirm Open After Download option, Edit File Type dialog box, 623
 - connection speed, 510
 - connections. *See also* cables; *names of specific connectors*
 - power, 284–288
 - printer, 399–402
 - scanner, 425
 - troubleshooting, 500
 - types of, 309–315
 - wireless network, 931–932
 - Conseil Européen pour la Recherche Nucléaire (CERN), 1009
 - Content Advisor, 1024
 - continuous form feeder, 392
 - Contributor permission level, 991
 - Control Panel applets, 555–557
 - controllers, 70, 216, 218
 - conventional memory, 738–739
 - conventions used in book, 1–2
 - conversion of voltage, 280
 - cookies, 1023–1024
 - cooling fan. *See* fan
 - cooling system, 52–53, 141–143
 - cooling time, printer, 418
 - cooperative multitasking, 729
 - Co-owner permission level, 991
 - Copy backup, 860
 - copy command, 655, 673
 - /copydir:<folder> switch, 576
 - copying files, 1080
 - Core 2 Duo processor, 134
 - Core 2 Quad processor, 134
 - Core 2 Solo processor, 134
 - corona wire, 394–396
 - corrosion, 476
 - corrupt cache memory, 199–200
 - corrupt shortcuts, 838
 - cost of exam, 13
 - country standards, 512
 - Covington chip, 130
 - .cpl extension, 627
 - CPU (central processing unit), 48–49. *See also* processor
 - CPU usage, Task Manager, 753
 - crash dump files, 799, 820–821
 - critical system resources, 760–761
 - cross talk, 305–306, 399
 - cross-linked file, 784
 - CRT (cathode ray tube) monitor, 39–41, 351–352
 - cscript.exe utility, 802
 - CSMA/CA (Carrier Sense Multiple Access/Collision Avoidance), 899
 - CSMA/CD (Carrier Sense Multiple Access/Collision Detection), 898–899
 - .css extension, 629
 - cultural sensitivity, 28
 - .cur extension, 627
 - Cursor Blink Rate slider, Keyboard Properties dialog box, 330
 - cursor keys, 326
 - Custom Level button, Internet Options dialog box, 1023
 - cut-off switch, LCD, 462, 516
 - C:\Windows folder, 561
 - C:\WinNT folder, 561
 - cylinders, 212
-
- ## D
-
- /D switch, 636
 - /d switch, 659
 - DAC (digital-to-analog converter), 346
 - daemon, 1018–1019
 - Daily backup, 860
 - damaged pixels, 508
 - DARPA (Defense Advanced Research Projects Agency), 1007–1008
 - DART (Diagnostics and Recovery Toolkit), 498
 - DAT (Digital Audio Tape), 242
 - .dat extension, 627
 - data bits, 510
 - data bus, 114
 - data integrity, 267

- Data Link layer, OSI, 906
- data protection, 470
- data security, 1056–1062. *See also* security
- data skew, 399
- dataflow analysis, 129
- Date and Time applet, 556
- date settings
 - CMOS, 193
 - Windows 2000 installation, 582–583
- daughter board, 51
- DB-9 connector, 310
- DB-9 port, 77
- DB-15 connector, 311
- DB-25 connector, 311, 316, 399–400
- DB-25 port, 77
- DC (direct current) adapter, 292
- DC (direct current) controller, 440
- DC (direct current) voltage regulation, 281
- DDR (double data rate) memory, 159–160
- DDS (Digital Data Storage), 242
- DD-WRT firmware, 941
- Debugging Mode, 852
- default gateway, 965–966, 980
- default printer, 417
- default user template, 791
- Defense Advanced Research Projects Agency (DARPA), 1007–1008
- `defrag.exe` command, 658, 673, 781–783
- defragmenting hard drives, 267–269, 482, 658, 673, 765–766, 781–783
- deionized water, 506
- `del` command, 656
- Demilitarized Zone (DMZ), 939–940, 1086–1087
- demodulation, 56
- Deneb processor, 137
- denial of service (DoS), 1043
- Department of Defense (DoD), 1007
- desktop PCs, installing memory, 169–171
- Desktop Properties window, 354–355
- DET (Directory Entry Table), 256
- detachable multimeter probe leads, 492
- device drivers. *See* drivers
- device load process, 685
- Device Manager, 792–793
- device-related errors, Windows, 816–818
- `dfrg.msc` utility, 781–783
- DHCP (Dynamic Host Configuration Protocol), 916, 940, 967–968, 998
- diagnostic utilities
 - command line, 658–659
 - software, 498–499
 - Windows, 794–800
- Diagnostics and Recovery Toolkit (DART), 498
- dialup Internet access method, 1030
- Differential backup, 860
- digital audio connector, 320
- Digital Audio Tape (DAT), 242
- digital camera, 427–431
- Digital Data Storage (DDS), 242
- digital infrared thermometer, 496
- digital multimeter, 35, 492–493
- Digital Signal Processor (DSP), 332
- digital video camera, 431
- digital video interface (DVI), 304, 348
- digital zoom, 429
- digital-to-analog converter (DAC), 346
- digitizer, 518
- DIMM (dual inline memory module), 68–69, 161–162, 170
- DIN connector, 79, 328
- DIP (dual inline package) chip, 121
- DIP (dual inline package) switch, 89–90
- `dir` command, 649–653, 674
- `dircmd` environment variable, 653
- direct current (DC) adapter, 292
- direct current (DC) controller, 440
- direct current (DC) voltage regulation, 281
- direct memory access (DMA), 219, 373–375, 383
- directory entry format, 616
- Directory Entry Table (DET), 256
- directory management, 649–654, 657
- Directory Services Restore Mode, 851
- dirt, 477–478
- Disable Automatic Restart on System Failure option, 852

- disable command, 855
- Disable option, local area connection
 - contextual menu, 953
- Disable Volume Shadow Copy option,
 - Backup Job Information window, 859
- disabling
 - cache memory, 199–200
 - drives, 189
 - USB ports, 198
- disaster recovery
 - Automatic System Recovery, 866–868
 - backups, 856–862
 - boot disks, 847–848
 - Emergency Repair Process, 852–856
 - F8 boot-up options, 848–852
 - overview, 847
 - recovery CDs, 868–869
 - recovery partitions, 868–869
 - rescue CDs, 869–874
 - rescue installations, 874–875
 - rescue partitions, 874–875
 - restore points, Windows, 862–865
- discharging
 - batteries, 443, 485
 - CRTs, 40
- discoloration, image, 508
- discretion, 26
- disk, ARC standard, 683
- Disk Cleanup, 270–271, 768
- Disk Defragmenter utility, 268–269, 793
- disk duplexing, 261–262
- disk geometry, 210–212
- disk maintenance utilities, Windows,
 - 779–784
- Disk Management snap-in, 779–781
- disk management tools, 267–272
- disk mirroring, 261–264
- disk quotas, 246
- disk size detection problems, 503–505
- disk striping, 261
- diskcomp.com command, 657
- diskpart utility, 271–272, 660–661,
 - 779–781
- display. *See* monitor
- Display applet, 556
- Display Name value, 685
- Display Properties dialog box, 353–354
- display toggle function key, 452
- /displaydns switch, 979
- disposing of components, 40–42
- distractions, avoiding workplace, 28
- distributed administration, 883
- distribution point, 607–608
- DivX codec, 432
- .dll (Dynamic Link Library) files, 628,
 - 799–800
- DMA (direct memory access), 219, 373–375,
 - 383
- DMZ (Demilitarized Zone), 939–940,
 - 1086–1087
- DNS (domain name system), 975–976,
 - 1027–1029
 - .doc extension, 626
- docking station, 455
- Document Type Definitions (DTDs), 1017
- documentation, 22–24
- .docx extension, 626
- DoD (Department of Defense), 1007
- domain, 571–572
- domain name system (DNS), 975–976,
 - 1027–1029
- DoS (denial of service), 1043
- DOS protected-mode interface (DPMI)
 - memory, 740
- doskey.com program, 688
- .dot extension, 626
- dot matrix printer, 392, 398, 414, 419
- dot pitch, monitor, 351–352
- .dotx extension, 626
- double data rate (DDR) memory, 159–160
- double-sided memory module, 166
- DPI (dots per inch) levels, 768
- DPMI (DOS protected-mode interface)
 - memory, 740
- Dr. Watson, 799, 820–821
- draft-quality printer, 398
- DRAM (Dynamic RAM), 154, 156–160, 173
- dress, 26
- drive faceplate, 497
- drive imaging, 569–570

- drive-overlay programs, 503
 - drivers
 - changing, 706–708
 - failure, 715–716
 - keyboard, 327
 - loading, 701–706
 - modem, 335
 - network adapter, 950–954
 - overview, 701
 - permissions, 713–714
 - Plug and Play, 710–713
 - printer, 767, 829–830
 - removing, 708–709
 - signed, 709–710
 - troubleshooting, 837
 - unsigned, 709–710
 - updating, 472, 708, 951–952
 - verifying installation, 714
 - drum scanner, 424
 - .drv extension, 628
 - DSP (Digital Signal Processor), 332
 - DTDs (Document Type Definitions), 1017
 - dual core processor, 119–120
 - dual inline memory module (DIMM), 68–69, 161–162, 170
 - dual inline package (DIP) chip, 121
 - dual inline package (DIP) switch, 89–90
 - dual ported memory, 350
 - dual-boot system, 244–245, 607, 611
 - dual-channel configuration, 165–166
 - dual-scan display, 449
 - duplexing, disk, 261–262
 - Duron processor, 136
 - dust, 477–478
 - DV format, 432
 - DVD (digital versatile disc), 239–240, 483, 505
 - DVDRW (digital versatile disc ReWritable), 239–240
 - DVI (digital video interface), 304, 348
 - dynamic disk, 253–255, 780
 - Dynamic disk status, 260
 - dynamic execution, 128–129
 - Dynamic Host Configuration Protocol (DHCP), 916, 940, 967–968, 998
 - Dynamic Link Library (.dll) files, 628, 799–800
 - Dynamic Memory Allocation check box, PIF Properties window, 741
 - Dynamic RAM (DRAM), 154, 156–160, 173
-
- ## E
- /E switch, 636
 - /e:<command> switch, 575
 - Easy Transfer, 609, 611
 - eavesdropping attack, 1044
 - ECC (error-checking and correction) memory, 165
 - ECHS (Extended Cylinder/Head/Sector), 214–215
 - ECP (Extended Capabilities Port), 191, 302
 - edit command, 662–665, 674, 803
 - Edit File Type dialog box, 622–624
 - EDO (extended data output), 158
 - EEPROM (electrically erasable programmable ROM), 72, 153, 182–183
 - EFS (Encrypting File System), 246, 635
 - EFS (Encrypting File System) Recovery Agent, 635
 - EGA (Enhanced Graphics Adapter), 347
 - EIDE (Enhanced Integrated Drive Electronics), 216–218, 224
 - EIDE/ATA-2 standard, 217–218
 - EISA (Extended Industry Standard Architecture), 99
 - electrical tape, 497
 - electrically erasable programmable ROM (EEPROM), 72, 153, 182–183
 - electromagnetic interference (EMI), 38, 478
 - electrostatic discharge (ESD), 36–38, 477
 - e-mail, 1013–1015
 - Emergency Repair Process, 852–856
 - EMI (electromagnetic interference), 38, 478
 - EMS (expanded) memory, 739–740
 - enable command, 855
 - Enable File and Folder Compression check box, Format dialog box, 258
 - Enable option, local area connection contextual menu, 953

- enabling auditing, 1081–1083
 - encoding, 1013
 - Encrypt attribute, 632
 - Encrypting File System (EFS), 246, 635
 - Encrypting File System (EFS) Recovery Agent, 635
 - encryption, 634–637, 1060
 - Energy Star specification, 281
 - Enhanced Graphics Adapter (EGA), 347
 - Enhanced Integrated Drive Electronics (EIDE), 216–218, 224
 - enhanced keyboard, 327
 - Enhanced Parallel Port (EPP), 191, 302
 - EPA (Environmental Protection Agency), 40
 - EPP (Enhanced Parallel Port), 191, 302
 - EPROM (erasable programmable ROM), 153
 - .eps extension, 628
 - erase command, 656
 - ergonomic keyboard, 43, 327–328
 - ergonomics, 42–43
 - Error Control value, 685
 - Error Reporting Service, 769, 821–822
 - error-checking, 164–165
 - error-checking and correction (ECC) memory, 165
 - errors
 - printer, 411
 - Ultra DMA devices, 218
 - Windows diagnostic tools, 820–823
 - eSATA (external SATA), 50, 87, 236–237
 - ESD (electrostatic discharge), 36–38, 477
 - ESSID (Extended Service Set Identifier), 930
 - Ethernet, 900–902
 - Event Log service, 770, 822–823
 - event logs, 819
 - Event Viewer utility, 793, 796–798, 822–823, 837
 - EventID Web site, 797
 - exceptions, firewall, 1087–1089
 - .exe (executable) files, 625
 - Executive Services, 545
 - exhaust areas, 474
 - exit rollers, 393
 - expanded (EMS) memory, 739–740
 - expand.exe utility, 803
 - expansion slots, 74–75
 - explorer.exe utility, 554
 - Export Registry File dialog box, 788–789
 - Extended (XMS) memory, 740
 - Extended Capabilities Port (ECP), 191, 302
 - Extended Cylinder/Head/Sector (ECHS), 214–215
 - extended data output (EDO), 158
 - Extended Graphics Array (XGA), 347
 - Extended Industry Standard Architecture (EISA), 99
 - extended partition, 248–250, 780
 - Extended Service Set Identifier (ESSID), 930
 - Extensible Markup Language (XML), 1017–1018
 - external cables, 316–318
 - external cache, 69
 - external hard drive, 241, 459–460
 - external knowledge bases, 23–24
 - external modem, 333–334
 - external monitor, 462, 516
 - external SATA (eSATA), 50, 87, 236–237
 - external SCSI connector, 229, 231
 - external support professionals, 24
 - eye care, 43
-
- ## F
-
- F connector, 893–894
 - /F switch, 634, 636
 - F8 boot-up options, 848–852
 - faceplates, drive, 497
 - Failed disk status, 260
 - faint printing, 414–415
 - fan
 - installing, 142–143
 - overview, 52–53, 832
 - printer, 486
 - purpose of, 474–475
 - FAST (Files and Settings Transfer) Wizard, 609–611
 - fast page mode (FPM), 157–158
 - Fast Pasting option, PIF Properties window, 742

- Fast ROM Emulation check box, PIF Properties window, 741
- Fast SCSI-2, 230
- Fast User Switching Compatibility service, 770
- Fast Wide SCSI-2, 232
- FAT (File Allocation Table) file system, 243–245, 256, 549, 572–573
- FAT32 file system, 245–246, 549, 573
- fax machines, 392
- `fc.exe` command, 657
- FDDI (Fiber Distributed Data Interface), 903
- fiber optic cable, 307–308, 896–897
- File Allocation Table (FAT) file system, 243–245, 256, 549, 572–573
- File and Printer Sharing Services, 985–986
- file associations, 619–624
- file attributes
 - basic, 631–632
 - overview, 630
 - setting, 638–642
 - storage of, 630–631
 - Windows NTFS extended, 632–638
- file extensions, 620, 624–630
- file locations, 561–562
- file management utilities, 654–657, 855
- file sharing, 961, 985–986, 991
- File System field, Format dialog box, 257
- file system optimization, 267
- file system resources, sharing, 984–994
- file systems, 243–247, 548–549, 572–573, 579
- File Transfer Protocol (FTP), 1018–1020
- file-naming conventions
 - file associations, 619–624
 - file extensions, 624–630
 - name length, 617–619
 - overview, 615–617
- Files and Settings Transfer (FAST) Wizard, 609–611
- FilterKeys option, Accessibility Options dialog box, 331
- filters, Web site, 916
- Finder, Mac OS X, 535
- fingerprint scanners, 340
- Firefox, 1021
- firewall
 - Demilitarized Zone, 1086–1087
 - exceptions, 1087–1089
 - hardware, 1087
 - home router, 917–918
 - overview, 1032–1033, 1084–1086, 1090
 - port security, 1087–1089
 - software, 1087
- FireWire (IEEE 1394) connection, 81–82, 303–304, 315, 402
- FireWire 800 (IEEE 1394b) connection, 82
- firmware
 - keyboard, 327
 - overview, 53, 58, 153
 - updating, 472, 918
 - wireless network security, 940–941
- fixed focus camera, 428
- flash drive, 49, 240–241, 459–460
- flash ROM, 184
- flashlight, 496
- flat memory model, 681
- flatbed scanner, 424, 435
- FlexATX motherboard, 95–96
- flicker, screen, 508
- floppy disk drive
 - ASR backups, 866–867
 - BIOS updates, 184
 - booting off of, 193
 - CMOS, 189–190
 - connectors, 88, 284–286
 - overview, 49, 237–238
 - preventive maintenance, 483
 - troubleshooting, 502–503
- flow control, 510
- `/flushdns` switch, 979
- Folder Options applet, 556
- Folder Options dialog box, 622, 625, 990
- folder structure, Windows, 553
- Folders Explorer Bar, Windows Explorer, 553
- Font tab, PIF settings, 738
- fonts, 561
- Fonts applet, 556

Foreground settings, PIF Properties
 window, 741
Foreign disk status, 260
form factor
 motherboard, 90–96, 282
 overview, 55
 power supply, 288–289
format command, 256, 258, 661, 674
Format dialog box, Disk Management snap-
 in, 257–258
Formatting disk status, 260
formatting partitions and volumes, 255–258
FPM (fast page mode), 157–158
FQDN (fully qualified domain name),
 974–978
fragmented disk, 267–268, 781–783
frame type, 958–959
friction feeder, 392
FSB (front side bus), 133
FTP (File Transfer Protocol), 1018–1020
ftp: access method, 1027
full AT motherboard, 91
full-duplex communication, 914
fully qualified domain name (FQDN),
 974–978
function keys, 326, 451–452, 462, 516–517
fuser rollers, 393

G

gadgets, 529, 775
Game Controllers applet, 556
gateways, 911, 942
gender changers, 318–319
General Protection Fault (GPF), 542, 840
General tab, PIF settings, 736
ghosted print, 415
GHz (gigahertz), 114
 .gif extension, 629
Gigabit Ethernet standards, 901–902
gigahertz (GHz), 114
glidepad, 517
Globally Unique Identifier (GUID), 196–197
GNOME desktop environment, 533–534
gold pins, 169

gopher: access method, 1027
Gopher protocol, 1015–1016
goto statement, 669
GPF (General Protection Fault), 542, 840
graphic files, 426, 628–629
graphical user interface. *See* GUI
graphics accelerator card, 348
grounding equipment, 37–38, 478
Group value, 685
groups, security, 1071–1073
GUI (graphical user interface)
 Linux, 533–534
 Macintosh OS, 535–536
 overview, 525
 Windows, 529–530, 641–642, 773–775,
 819–820
GUID (Globally Unique Identifier), 196–197
GUI-mode phase, Windows attended
 installation
 overview, 574–575
 Windows 2000, 580–585
 Windows Vista, 591–596
 Windows XP, 589–591

H

/H switch, 636
hal.dll file, 815–816
half-duplex communication, 913
handheld devices, 460–461
handheld scanner, 424
handles, 754
hard drive
 adding to printers, 403
 CMOS, 188–189
 controller, 70, 216
 defrag.exe utility, 658
 destruction, 1057
 external, 241
 laptop, 441
 overview, 49, 766
 paging file, 765–766
 performance of, 219
 preventive maintenance, 482–483
 recycling, 1057

- requirements, 528, 532, 570, 601
 - status of, 260
 - troubleshooting, 503–505
 - hard drive self-test, 499
 - hardening systems, 1090
 - hardware address, 907
 - Hardware Compatibility List (HCL), 571
 - hardware firewall, 1087
 - Hardware tab, Sound and Audio Devices
 - Properties dialog box, 357
 - hardware tools, 491–498
 - hazardous materials, disposal of, 40
 - HCL (Hardware Compatibility List), 571
 - HD DB-15 connector, 304, 311
 - HDMI (High-Definition Multimedia Interface), 348
 - head alignment, 483, 502
 - head cleaning, 483
 - head positioning mechanism, 211
 - headphones port, 355
 - Healthy disk status, 260
 - heat pipe, 142
 - heat sink, 52, 142–143, 475
 - Heka processor, 137
 - Help and Support service, 770
 - help command, 662
 - help desks, 23
 - hertz, 114
 - hibernate mode, 447
 - Hidden attribute, 631, 659
 - hidden shares, 991–993
 - High Performance File System (HPFS), 247
 - High-Definition Multimedia Interface (HDMI), 348
 - high-voltage equipment, 38–40
 - hives, Registry, 790–791
 - HKEY_CLASSES_ROOT subtree, 786
 - HKEY_CURRENT_CONFIG subtree, 786
 - HKEY_CURRENT_USER subtree, 786–788
 - HKEY_LOCAL_MACHINE subtree, 786–788
 - HKEY_USERS subtree, 786
 - hoaxes, 1104–1105
 - home router, 916–917, 1032–1033
 - host adapter, 226–227
 - host ID, 963
 - hostile remote networks, 939
 - HOSTS file, 976–977
 - hot fixes, 544
 - hot-swappable technology, 712
 - HPFS (High Performance File System), 247
 - .hqx extension, 626
 - .htm extension, 629
 - HTML (HyperText Markup Language), 1009, 1016–1018
 - .html extension, 629
 - HTT (hyperthreading technology), 119
 - HTTP (HyperText Transport Protocol), 1015–1018
 - http: access method, 1027
 - HTTPS (HyperText Transfer Protocol Secure), 1018
 - https: access method, 1027
 - hub, 81, 198, 886–887, 911, 1091–1092
 - humidifier, 38
 - humidity, 449, 476–477
 - hybrid topology, 888–889
 - HyperCard program, 1015
 - HyperText Markup Language (HTML), 1009, 1016–1018
 - HyperText Transfer Protocol Secure (HTTPS), 1018
 - HyperText Transport Protocol (HTTP), 1015–1018
 - hyperthreading technology (HTT), 119
 - hypothesis generation and evaluation, 17
-
- I
- /I switch, 634, 636
 - I386 folder, 569
 - IAB (Internet Architecture Board), 1007
 - IBM POST codes, 500
 - IBM-type data connector (IDC), 309–310, 902–903
 - icons used in book, 4–5
 - ICS (Windows Firewall/Internet Connection Sharing) service, 770
 - IDC (IBM-type data connector), 309–310, 902–903

- IDE (Integrated Drive Electronics), 49–50, 85–86, 216–221
- IDE/ATA standard, 217
- Idle Sensitivity setting, PIF Properties window, 742–743
- IE (Internet Explorer), 1021–1026
- IEEE (Institute of Electrical and Electronics Engineers) standards, 903–905
- IEEE 1284 bidirectional cable, 316
- IEEE 1394 (FireWire) connection, 81–82, 303–304, 315, 402
- IEEE 1394b (FireWire 800) connection, 82
- `if` statement, 668–671
- illegal operations, 840
- Image Path value, 685
- image skew, 508
- IMAP (Internet Message Access Protocol), 1014–1015
- IMAPI CD-Burning COM Service, 770
- impact printer, 398
- Incremental backup, 860
- Index attribute, 632
- indexing files, 637–638, 775–776
- Indexing Service, 637–638, 770
- Industry Standard Architecture. *See* ISA
- INF files, 702
- infrared communication
 - devices, 927–928
 - laptops, 454
 - ports, 915
 - printer connections, 402
 - thermometers, 496
- infrastructure mode, 929–930
 - `.ini` files, 550–551, 628, 688–689
- ink cartridge, 397–398
- inkjet printer, 396–398, 415, 419, 485–486
- inline UPS, 293
- input supply voltage, 281
- input/output (I/O) address, 364–367, 383
- input/output (I/O) devices, 358
- input/output (I/O) ports, 75
- input-under voltage, 281
- Inspect Registry option, Emergency Repair Process, 853–854
- instances, 761
- Institute of Electrical and Electronics Engineers (IEEE) standards, 903–905
- instruction pipelines, 127–128
- integrated cache, 69
- Integrated Drive Electronics (IDE), 49–50, 85–86, 216–221
- Integrated Services Digital Network (ISDN), 56–57, 1031
- integrated sound card, 356
- Intel processors, 126–135
- interference
 - wire, 305–306
 - wireless, 942
- internal modem, 333–334
- internal SCSI connector, 229–230
- internal support professionals, 24
- Internet
 - access methods, 1026–1027, 1029–1032
 - browsers, 1021–1026
 - domain names, 1027–1029
 - overview, 1007–1009
 - protocols, 1011–1021
 - researching on, 24
 - sharing, 916
 - using, 1026
 - Web sites, 1027–1029
- Internet Architecture Board (IAB), 1007
- Internet Explorer (IE), 1021–1026
- Internet Message Access Protocol (IMAP), 1014–1015
- Internet Options applet, 556
- Internet Options dialog box, 1022–1026
- Internet Protocol (IP) address, 962–965, 980, 1027
- Internet Protocol (TCP/IP) Properties window, 968, 973, 976
- Internet service provider (ISP), 1009–1011
- Internet Services section, Network Diagnostics tool, 798
- Internetwork Packet Exchange/Sequenced Packet Exchange (IPX/SPX), 958–960, 1000
- interrupt request. *See* IRQ
- inventory list. *See* complementary metal-oxide semiconductor (CMOS)

I/O (input/output) address, 364–367, 383
 I/O (input/output) devices, 358
 I/O (input/output) ports, 75
 IP (Internet Protocol) address, 962–965, 980, 1027
 ipconfig utility, 978–979, 1000
 IPX/SPX (Internetwork Packet Exchange/Sequenced Packet Exchange), 958–960, 1000
 IRQ (interrupt request)
 cascading, 368–373
 overview, 89, 368, 383
 sound cards, 356
 troubleshooting, 378–379
 ISA (Industry Standard Architecture)
 bus, 55, 74–75
 overview, 97–98
 sound cards, 356
 ISDN (Integrated Services Digital Network), 56–57, 1031
 Isopoint pointing, 517
 ISP (Internet service provider), 1009–1011
 Itanium II processor, 133–134
 Itanium processor, 133–134

J

jackets, cable, 890
 journal-based file systems, 533
 .jpeg extension, 629
 .jpg extension, 629
 jumper
 assigning SCSI ID, 228–229
 BIOS updates, 185
 configuring resources, 380
 master/slave configuration, 222–224
 overview, 88–90
 password clear, 195
 troubleshooting, 503–504

K

/K switch, 636
 K6 processor, 135
 K6-2 processor, 135

K6-III processor, 135–136
 kernel, Linux, 531
 Kernel memory, Task Manager, 754–755
 kernel mode, Windows, 545
 key words, exam question, 14
 keyboard
 accessibility options, 329–331
 configuring, 329–331
 connections, 57, 78–79, 341
 controller, 70
 drivers, 327
 ergonomic, 43
 installing, 328–329
 laptop, 441, 450–452
 overview, 325–327
 ports, 304
 preventive maintenance, 481–482
 troubleshooting, 505–507
 types of, 327–328
 Keyboard applet, 556
 Keyboard Properties dialog box, 329–330
 keycode, 326
 keyed connectors, 83, 308
 keyswitch, 326
 Knoppix, 498, 869–873
 knowledge bases, external, 23–24

L

L1 (Level 1) cache, 69, 117, 166, 173
 L2 (Level 2) cache, 69–70, 117, 167, 173
 L3 (Level 3) cache, 167, 173
 lab exercises, 1115
 labeling optical media, 484
 LAN (local area network), 884–885, 904
 LAN Settings button, Internet Options dialog box, 1024
 laplink cable, 915
 laptop
 AC adapters, 289–291, 447–448
 automatic switching, 281
 batteries, 441–443
 biometric devices, 340
 communication components, 453–455
 components of, 440–441

- laptop (*continued*)
 - docking stations, 455
 - installing memory, 171–172
 - keyboard, 450–452
 - LCD panels, 449–450
 - overview, 439
 - PCI Express cards, 458
 - PCMCIA cards, 456–457
 - pointing devices, 339–340, 452–453
 - port replicators, 455
 - power-management features, 444–447
 - preventive maintenance, 484–485
 - projectors, 352
 - troubleshooting, 461–462, 515–518
 - upgrading, 458–460
 - wireless networking, 929
- laser printer
 - charging drum, 395
 - cleaning, 396, 486
 - developing image, 395
 - exposing drum, 395
 - fusing image, 396
 - laser printing process, 394–395
 - overview, 392–394
 - preventive maintenance, 418–419
 - process, 419
 - transferring image, 396
 - troubleshooting, 415–416
- Last Known Good Configuration, 851
- latency, 213
- layered approach, 20
- LBA (Logical Block Addressing), 214–215
- LC (local connector), 897
- LCD (liquid crystal display) monitor
 - connecting to computer, 450
 - cut-off switch, 462, 516
 - handling, 449–450
 - overview, 352, 441, 449
- Least Recently Used (LRU) algorithm, 694
- LEDs, keyboard, 326
- legacy devices, 200, 383, 713
- Level 1 (L1) cache, 69, 117, 166, 173
- Level 2 (L2) cache, 69–70, 117, 167, 173
- Level 3 (L3) cache, 167, 173
- LFX v1.1 (Low Profile Form Factor), 289
- license agreement, Windows, 577–578, 586–587, 592
- Licensing (Server) applet, 556
- lights, network card, 907
- Li-Ion (lithium-ion) battery, 442, 484–485
- line conditioners, 292
- linear approach, 20
- linear format exams, 10–11
- line-in port, 79–80, 355
- line-of-sight technology, 402, 454, 928
- line-out port, 79–80, 355
- link light, network card, 907
- Linux, 530–534, 869–873, 1033
- Li-Poly (lithium-ion polymer) battery, 484–485
- liquid cooling system, 142
- liquid crystal display monitor. *See* LCD monitor
- liquids, 476–477, 481, 505–506
- listening to customers, 25
- listsvc command, 855
- lithium-ion (Li-Ion) battery, 442, 484–485
- lithium-ion polymer (Li-Poly) battery, 484–485
- Live CD, 36, 533, 869
- LMHOSTS file, 974
- local area network (LAN), 884–885, 904
- local connector (LC), 897
- local printer, 404
- Local Security Policy application, 714
- Local Users and Groups utility, 793
- location settings, Windows Vista
 - installation, 595
- lockdown cable, 485
- log files, installation, 600
- logic bomb, 1047
- Logical Block Addressing (LBA), 214–215
- Logical Disk Manager service, 770
- logical drive, 248–249
- logon command, 855
- loopback address, 964, 980
- loopback plugs, 496–497
- looping, 671–672
- low profile extended (LPX) motherboard, 93
- Low Profile Form Factor (LFX v1.1), 289

Low Voltage Differential (LVD), 232
 LPT1 (printer) port, 76
 LPX (low profile extended) motherboard, 93
 LRU (Least Recently Used) algorithm, 694
 LVD (Low Voltage Differential), 232

M

MAC (Media Access Control) address, 907, 937–938
 Macintosh OS, 534–536, 620
 magnetic pickup tools, 494
 magnetic tape drive, 49
 Mail applet, 556
 mailto: access method, 1027
 main laptop battery, 441–442
 main power connector, 285–286, 514
 malware (malicious software), 842–843, 1102–1104
 man-in-the-middle, 1045
 manual switching, 281
 manuals, vendor, 23
 Map Network Drive dialog box, 993–994
 mapping network drives, 993–994
 Master Boot Record (MBR), 199, 213–214
 master/slave configuration, 222–224
 Material Safety Data Sheets (MSDS), 41–42
 math co-processor, 117–118, 369
 MAU (multistation access unit), 902–903
 MBR (Master Boot Record), 199, 213–214
 MCA (Micro Channel Architecture), 98–99
 MDA (Monochrome Display Adapter), 346
 MDRAM (Multibank DRAM), 350
 Mean Time Before Failure (MTBF), 479
 mechanical mouse, 331–332, 482
 mechanical transfer-registered jack (MT-RJ), 897
 Media Access Control (MAC) address, 907, 937–938
 megapixels, 428, 435
 mem command, 674
 membrane keyboard, 326
 mem.exe command, 659

memory
 boot process, 691–694
 cache, 166–167
 chip packaging, 160–163
 CMOS, 189–191
 corrupted space, 839
 error-checking, 164–165
 installing, 168–172
 laptop, 441
 management of, 542
 overview, 50–51, 58, 151
 printer, 416
 problems with, 832
 purpose of, 152
 RAM, 154–160
 related objects, 761
 requirements, 528, 532, 570
 ROM, 152–153
 single channel versus dual channel, 165–166
 single sided versus double sided, 166
 troubleshooting, 501–502
 types of, 173
 virtual, 765–766
 memory address, 375–376
 memory bank, 161
 memory controller, 70, 116
 memory modules, 173
 memory stick, 240–241, 459–460
 Memory tab, PIF settings, 738–740
 Mendocino processor, 130
 Messenger service, 770, 998
 MIC-in port, 79–80, 355
 Micro Channel Architecture (MCA), 98–99
 microATX motherboard, 95–96
 MicroDIMM (micro dual inline memory module), 162–163
 microphone, 432–433
 microphone port, 79–80
 Microsoft Diagnostics and Recovery Toolkit (DART), 498
 Microsoft Internet Explorer. *See* Internet Explorer
 Microsoft Management Console (MMC), 557

- Microsoft Office, 625–626, 1098–1099
- Microsoft Virtual PC, 244
- Microsoft Windows. *See* Windows
- Microsoft Windows 2000. *See* Windows 2000
- Microsoft Windows 2003, installing, 597–599
- Microsoft Windows 9x, 527
- Microsoft Windows Vista. *See* Windows Vista
- Microsoft Windows XP. *See* Windows XP
- MIDI (Musical Instrument Digital Interface), 320, 433–434
- MIMO (Multiple-Input Multiple-Output), 935
- mini-DIN connector, 304, 314, 328, 333
- minimum and maximum trap feature, multimeters, 493
- mirror, 496
- mirrored volume, 253
- mirroring, disk, 261–264
- Misc tab, PIF settings, 741–743
- MJPEG codec, 432
- `mkdir` command, 653
- MMC (Microsoft Management Console), 557
- MMC (multimedia card), 358
- MMF (multimode fiber) cable, 307–308, 897
- MMX (MultiMedia eXtensions), 118
- modem
 - characteristics of, 333–334
 - AT commands, 334–335
 - configuring, 335–336
 - installing, 335
 - laptop, 454
 - overview, 56–58, 79–80, 333
 - troubleshooting, 509
- Modems and Network Adapters section, Network Diagnostics tool, 798
- modulation, 56
- Molex connector, 308
- monitor
 - adjustment tools, 496
 - cathode ray tube, 39–41, 351–352
 - display settings, 352–354
 - liquid crystal display, 352, 441, 449–450, 462, 516
 - multidisplay support, 354–355
 - overview, 55–56, 58, 351
 - plasma, 352
 - ports, 304
 - position of, 43
 - preventive maintenance, 481
 - projector, 352
 - requirements, 528, 532
 - resolution, 56
 - safety, 39–40
 - troubleshooting, 462, 507–509
- Monochrome Display Adapter (MDA), 346
- monochrome LCD, 449
- Moore's Law, 932
- motherboard
 - bus architectures, 96–105
 - components of, 66–82
 - DIMM sockets, 68–69
 - DIP switches, 88–90
 - drive connectors, 85–88
 - jumpers, 88–90
 - modems, 79–80
 - mouse connectors, 78–79
 - overview, 51, 65
 - performance considerations, 105–106
 - power connectors, 82–84
 - sound cards, 356
 - troubleshooting, 501
 - types of, 90–96
- mount point, 258–260
- mounting bay, 220, 476
- mounting kit, 497
- mouse
 - connections, 78–79, 304, 341
 - installing, 332–333
 - maintenance, 506
 - overview, 331
 - port, 57
 - preventive maintenance, 481–482
 - troubleshooting, 505–507
 - types of, 331–332
- Mouse applet, 556
- mouse ball, 452

- Mouse settings, PIF Properties window, 742
 move command, 656
 moving files, 1080
 Mozilla Firefox, 1021
 MPEG1 codec, 432
 MPEG2 codec, 432
 MPEG4 codec, 432
 .msc extension, 628
 msconfig.exe utility, 785
 MS-DOS, 526, 615–616, 734–743
 MSDS (Material Safety Data Sheets), 41–42
 .msg extension, 628
 .msi files, 628, 720
 MSN Messenger, 430
 MTBF (Mean Time Before Failure), 479
 MT-RJ (mechanical transfer-registered jack), 897
 multi, ARC standard, 683
 Multibank DRAM (MDRAM), 350
 multibit screwdriver, 495
 multicore processor, 119–120
 multidisplay support monitor, 354–355
 multimedia card (MMC), 358
 multimedia connector, 319–320
 MultiMedia eXtensions (MMX), 118
 multimeter, 35, 492–493, 513
 multimode fiber (MMF) cable, 307–308, 897
 multiple branch prediction, 128
 multiple shares, 992
 Multiple-Input Multiple-Output (MIMO), 935
 multiprocessing systems, 132
 multistation access unit (MAU), 902–903
 multitasking capabilities, 118
 multithreaded environment, 725–726
 Musical Instrument Digital Interface (MIDI), 320, 433–434
 My Computer, 551–553
 My Network Places, 554
 NAT (Network Address Translation), 969–970
 National Center for Supercomputing Applications (NCSA) Mosaic, 1016
 natural keyboard, 327–328
 Navigation pane, Windows Explorer, 553
 NBTSTAT utility, 981–982
 NCSA (National Center for Supercomputing Applications) Mosaic, 1016
 net command, 828–829
 net localgroup command, 983
 net use command, 984
 net user command, 983
 net view command, 984
 NetBEUI (NetBIOS Extended User Interface), 958, 1000
 NetBIOS names, 970–974
 NetBIOS over TCP/IP Statistics (NBTSTAT utility), 981–982
 NetBIOS session interface, 1013
 Netbooks, 135
 NETSTAT utility, 982
 network adapter, 336–339
 network adapter driver, 950–954
 Network Address Translation (NAT), 969–970
 Network and Dial-up Connections applet, 556
 Network and Sharing Center, 556, 931–932
 network attacks, 832–833
 network cable printer connection, 400–401
 Network Connections applet, 556
 Network Connections window, 770, 953
 Network Diagnostics, Windows, 798
 network ID, 962–963
 Network Identification Wizard, Windows 2000, 585–586
 network installation, Windows, 569
 network interface card. *See* NIC
 Network layer, OSI, 906
 network operating system (NOS), 883
 network printer, 404, 409, 411
 Network Setup Wizard applet, 556
 Network Stumbler tool, 943–944
 network switch, home router, 917

N

- /N switch, 636
 -n switch, 981
 name resolution, 972, 975

- Network+ certification, 5
- networking
 - access methods, 898–899
 - architectures, 900–903
 - cabling, 890–898
 - client, 954–957
 - communication methods, 913–914
 - devices, 906–913
 - infrared ports, 915
 - name resolution, 970–978
 - overview, 914, 949–950
 - ports, 915
 - protocols, 903–906, 957–960
 - services, 960–961
 - sharing file system resources, 984–994
 - sharing printer resources, 994–996
 - Small Office/Home Office, 916–918
 - TCP/IP, 962–970, 978–984
 - terminology, 884–885
 - topologies, 885–890
 - troubleshooting, 980
 - types of, 881–884
 - Windows services, 996–1000
 - wireless, 928–944
- Networking tab, Task Manager, 755–756
- networks settings, Windows 2000
 - installation, 583–584
- new low profile extended (NLX)
 - motherboard, 93
- New Partition Wizard, 251–252
- New Technology File System (NTFS),
 - 246–247, 273, 549, 573
- New Volume Wizard, 255, 262–263,
 - 265–266
- news : access method, 1027
- NIC (network interface card)
 - EISA, 99
 - ISA, 97–98
 - laptops, 454
 - MCA, 98–99
 - overview, 79–80, 907–908, 914–915,
 - 950–951
 - PCI Express, 104
 - PCI/nlPeripheral, 100–101
 - PCI-X, 103–104
 - PCMCIA, 101–102
 - printers, 400
- NiCad (nickel-cadmium) battery, 442,
 - 484–485
- NiMH (nickel-metal hydride) battery, 442,
 - 484–485
- NLX (new low profile extended)
 - motherboard, 93
- No operating system found message, 812
- noise, 290
- noncontact voltage indicator, 513
- noncooperative program, 725
- nonintegrated cache, 69
- nonparity memory, 164–165, 169
- nonreentrant code, 729
- nonroutable protocol, 958
- nonunicast traffic, 756
- Normal backup, 860
- North Bridge chip, 71–72
- NOS (network operating system), 883
- notification area, 558
- Novell servers, 961
- NPU (numeric processing unit), 117–118
- NSLOOKUP utility, 983
- ntbackup.exe utility, 857
- ntbootdd.sys file, 681, 812
- ntbtlog.txt file, 850–851
- ntdetect.com file, 684, 814
- NTFS (New Technology File System),
 - 246–247, 273, 549, 573
- ntldr utility, 680–681, 684, 813
- ntoskrnl.exe file, 684–685, 815–816
- ntuser.dat file, 791
- NTVDM (Virtual DOS Machine), 730
- null modem adapter, 319
- null modem cable, 317–318, 915
- Num Lock key, 462, 517
- numeric keypad, 326, 517
- numeric processing unit (NPU), 117–118
- nut driver, 495
- NWLink protocol, 958–960

O

- o switch, 982
- Object not found message, 1029
- octets, 962
- Office, 625–626, 1098–1099
- Offline disk status, 260
- offline files/folders, 562
- offline UPS, 292
- offsite storage, 1059
- ohms, 280
- OLGA (organic land grid array), 134
- onboard cache settings, 199–200
- Online (errors) disk status, 260
- Online disk status, 260
- online UPS, 293
- Open dialog box, 663
- Open Systems Interconnect (OSI) model, 905–906
- Open With dialog box, 620–621
- opening
 - files via command prompt, 662–663
 - monitors, 39
- operating system. *See* OS; Windows
- Opteron processor, 136–137
- optical drive, 49
- optical media maintenance, 484, 505
- optical mouse, 332, 482
- optical zoom, 428
- opto-mechanical mouse, 332
- organic land grid array (OLGA), 134
- organizational unit (OU), 956
- OS (operating system). *See also* Windows
 - 32-bit versus 64-bit, 526
 - Linux, 530–534
 - Macintosh, 534–536
 - overview, 525
 - purpose of, 525–526
 - Windows, 526–530
- OSI (Open Systems Interconnect) model, 905–906
- OU (organizational unit), 956
- Out of Memory error, 416

- overclocking, 120
- over-current protection, 281
- overload protection feature, multimeters, 492
- /ox switch, 652

P

- p <protocol> switch, 982
- /p switch, 652
- P2P (peer-to-peer) network, 881–883
- P4 connector, 84, 286–287
- PAC (pin array cartridge), 134
- Packet Internet Groper (ping) utility, 979–980, 1000
- page faults, 757
- page file usage, Task Manager, 754
- page pool, 755
- page printer, 392–393
- paging file, 546–548, 739, 765, 818–819
- pairing, 942
- PAN (personal area network), 941–942
- paper errors, printer, 411
- paper feeder mechanism, 391–393
- paper jams, 412, 414–415
- paper transport path, 393
- parallel cable, 316, 399–400
- parallel devices, 358
- parallel port
 - CMOS, 191–192
 - overview, 57, 76–77, 302–303
 - scanner connections, 425
 - troubleshooting, 509–510
- parallel processing, 128
- parameters, 667–668
- parity data, 253, 265
- parity error, 164–165
- parity memory, 164–165, 169
- partition, ARC standard, 683
- partition options
 - Windows Vista installation, 592–593
 - Windows XP installation, 587–588

- partitions
 - cluster size, 212
 - creating, 250–255
 - diskpart .exe utility, 660–661
 - drive status, 260
 - extended, 248–250, 780
 - FAT file system, 243–244
 - FAT32 file system, 245–246
 - formatting, 255–258
 - mount points, 258–260
 - primary, 248
 - status of, 260
 - Windows, 567–568, 572, 577–579
- passive FTP, 1019
- passive heat sink, 143
- passive matrix display, 449
- pass-through connector, 512
- password
 - attacks, 1041–1043
 - CMOS, 194–196
 - policies, 1090–1091
 - strong, 1053
 - wireless network security, 936–937
- patching systems, 1090
- PATHPING utility, 982
- pausing print queue, 417
- PC Card, 101–102
 - .pcd extension, 629
- PCI (Peripheral Component Interconnect), 55, 74–75, 100–101, 335, 337–338, 356
- PCI Express (PCIe), 55, 104, 287–288, 458
- PCI-X (Peripheral Component Interconnect Extended), 55, 103–104
- PCMCIA (Personal Computer Memory Card Industry Association), 101–102, 441, 456–457, 463
- PCMCIA card, 101–102
 - .pcx extension, 629
- PDA (personal digital assistant), 439, 452, 460–461
 - .pdf extension, 629
- PE (Preinstallation Environment), 591
- PE Builder, 873–874
- peer server, 882
- peer-to-peer (P2P) network, 881–883
- Pentium processors, 66–67, 69, 126–134
- Perform a Quick Format check box, Format dialog box, 258
- performance
 - hard drive, 219
 - improving, 470
 - laptop battery, 442–443
 - motherboard, 105–106
 - Windows, 758–763
 - wireless network, 942–943
- Performance Logs and Alerts utility, 770, 793
- Performance Monitor, 759–762
- Performance Options dialog box, 547–548
- Performance tab, Task Manager, 752–755
- Peripheral Component Interconnect
 - Extended (PCI-X), 55, 103–104
- Peripheral Component Interconnect (PCI), 55, 74–75, 100–101, 335, 337–338, 356
- peripheral connector, 286–287
- permissions
 - application errors, 745–746
 - copying files, 1080
 - moving files, 1080
 - overview, 1053–1054, 1077–1080
 - share, 987–991
 - user-level access control, 985
- Permissions dialog box, 988
- Permissions option, Sharing dialog box, 987
- personal area network (PAN), 941–942
- Personal Computer Memory Card Industry Association (PCMCIA), 101–102, 441, 456–457, 463
- personal digital assistant (PDA), 439, 452, 460–461
- personalization, Windows 2000 installation, 580–581
- Personalization applet, 556
- PF (Power Factor), 293
- PFC (Power Factor Corrected) power supply, 294
- PGA (pin grid array) chip, 121, 123, 140–141

- Phenom II processor, 137
- Phenom processor, 137
- phishing, 1103–1104
- Phone and Modem Options applet, 556
- phone line issues, 509
- photocopier, 392
- photomultiplier tube (PMT), 424
- Physical layer, OSI, 906
- physical memory, Task Manager, 754
- physical security, 1047–1050
- pickup rollers, 485
- pickup tools, 494
- PIF (program information file)
 - Font tab, 738
 - General tab, 736
 - Memory tab, 738–740
 - Misc tab, 741–743
 - overview, 734–736
 - Program tab, 737–738
 - Screen tab, 740–741
 - Summary tab, 743
 - troubleshooting, 839
- Pin 1 indicator, 140–141, 170–171, 221, 308–309
- pin array cartridge (PAC), 134
- pin grid array (PGA) chip, 121, 123, 140–141
- pin-1 rule, 86
- ping (Packet Internet Groper) utility, 979–980, 1000
- pins
 - configuration, 285–288, 317
 - dot matrix printer, 414
- PIO (Programmed I/O) mode, 219
- PIV Xeon MP processor, 132
- PIV Xeon processor, 132
- pixels, 349, 508
- PKI (Public Key Infrastructure), 635
- plasma monitor, 352
- platen, 424, 486
- platter, 210–211
- plenum, 898
- Plug and Play, 100–101, 381–383, 710–713
- Plug and Play BIOS (PnP BIOS), 196
- PMT (photomultiplier tube), 424
 - .png extension, 629
- PnP BIOS (Plug and Play BIOS), 196
- Point and Print, 996
- pointer recalibration, 517–518
- polarity base plug, 478
- poor-quality printout, 415
- POP3 (Post Office Protocol version 3), 1014
- pop-ups, 1103–1104
- port replicator, 455
- port security, firewall, 1087–1089
- portable unique storage devices, 459–460
- ports. *See also names of specific ports*
 - AUI, 896
 - FireWire, 303–304
 - headphones, 355
 - keyboard, 304
 - Line-in, 355
 - Line-out, 355
 - MIC-in, 355
 - monitor, 304
 - mouse, 304
 - overview, 57–58, 301
 - parallel, 302–303, 425
 - serial, 302–303
 - settings for printers, 830–831
 - USB, 303
 - video, 346
- positive attitude, 26
- POST (Power-on Self-Test)
 - BIOS, 53, 72–73
 - errors, 500
 - overview, 182
 - process, 679–680
 - ROM, 153
- Post Office Protocol version 3 (POP3), 1014
- posture, 42
- power conditioning, 478
- Power Factor Corrected (PFC) power supply, 294
- Power Factor (PF), 293
- Power Options applet, 556

- Power Options window, 445–446
- power supply and management
 - AC adapters, 289–290, 447–448
 - amps, 280
 - connectors, 83–84, 221, 284–288
 - consumption of, 283, 479
 - form factors, 288–289
 - laptop, 444–447
 - laptops, 461
 - ohms, 280
 - overview, 51–52, 58, 279
 - preventive maintenance, 478–481
 - printer, 394
 - specification, 281
 - suppressors, 290–294
 - testers, 513–514
 - troubleshooting, 512–516, 832
 - UPS, 290–294
 - volts, 279
 - watts, 280
- power supply unit (PSU), 39, 280–281
- power surges, 290
- power-on password, 194
- Power-on Self-Test. *See* POST
- .pps extension, 626
- .ppsx extension, 626
- .ppt extension, 626
- .pptx extension, 626
- Preinstallation Environment (PE), 591
- Prep Test, 12, 1115
- Presentation layer, OSI, 905
- preventive maintenance
 - environmental controls, 473–479
 - overview, 469–471
 - tasks, 480–486
 - tools for, 471–473
- primary corona wire, 394–395
- primary partition, 248–249
- primary-rate ISDN, 1031
- print drum, 393, 395
- print head, 398, 414, 485–486
- print queue, 416–417, 828
- Print Spooler service, 413–414, 770, 828–829, 998
- Print Test Page option, 408, 412
- printer (LPT1) port, 76
- Printers and Faxes applet, 556
- printers and printing
 - connections, 399–402
 - dot matrix, 398
 - inkjet, 396–398
 - laser, 392–396
 - optimizing, 767
 - overview, 391
 - paper feeder mechanisms, 391–392
 - preventive maintenance, 418, 485–486
 - safety precautions, 418
 - sharing, 961, 985–986, 994–996
 - thermal, 399
 - troubleshooting, 411–417, 827–831
 - upgrading hardware, 403
 - Windows, 404–411
- Printers applet, 556
- Priority setting, printer Properties dialog box, 407
- privacy, 26
- private IP address, 969
- private keys, 635
- processes, defined, 754
- Processes tab, Task Manager, 756–757
- processor
 - 32-bit versus 64-bit, 526
 - cooling, 141–143
 - installing, 138–141
 - Intel, 126–134
 - IRQ, 368–369
 - non-Intel, 135–138
 - overview, 48–49, 58, 66–67, 113
 - performance, 144
 - requirements, 528, 532, 535, 570
 - retrieving information from, 167
 - sockets, 123–126
 - speed of, 114
 - terminology, 114–123
 - troubleshooting, 501–502
- professional behavior, 26–28
- Program and Features applet, 555
- program files, 562

program information file. *See* PIF
 Program tab, PIF settings, 737–738
 Programmed I/O (PIO) mode, 219
 Programs Control Panel applet, 722
 projector monitor, 352
 protected-mode processor, 118
 protocol suite, 960
 proxy server, 1024–1025
 PS_ON# feature, 281
 PS/2 connector, 78–79, 304, 314, 328, 333
 PSU (power supply unit), 39, 280–281
 Public Key Infrastructure (PKI), 635
 public keys, 635
 /PURGECACHE switch, 800

Q

/Q switch, 634, 636
 QIC (Quarter-inch cartridge), 242
 quad-core processor, 119
 querying modem, 335–336
 Quick Assessment tests, 1114
 quick format, 258
 Quick Start guide, 936

R

/R switch, 637
 -r switch, 981
 /r:<folderpath> switch, 575
 radio frequency interference (RFI), 478
 radio grade (RG), 893
 RAID (Redundant Array of Inexpensive Disks), 261–267, 1059–1060
 RAID 5 volume, 253, 264–267
 RAM (random access memory), 50–51, 154–160, 173, 441, 691–694
 rambus DRAM (RDRAM), 159
 rambus inline memory module (RIMM), 159
 random access memory (RAM), 50–51, 154–160, 173, 441, 691–694
 .rar extension, 627

rdisk, ARC standard, 683
 rdisk.exe utility, 852
 RDP (Remote Desktop Protocol), 558–559
 RDRAM (rambus DRAM), 159
 Reader permission level, 991
 Readiness Analyzer report, 602
 Read-only attribute, 631, 659
 read-only memory (ROM), 72, 152–153, 173
 read/write head, 211–213
 real-mode processor, 118
 receptacle tester, 513
 recovery agent, 246
 recovery CD, 472, 868–869
 Recovery Console, 854–856
 recovery partition, 868–869
 Red Hat Package Manager (RPM), 532
 redirection symbols, 666–667
 Redundant Array of Inexpensive Disks (RAID), 261–267, 1059–1060
 reflective infrared, 402
 refresh rate, monitor, 351–352
 .reg extension, 788–790
 regedit.exe utility, 786–790
 regedt32.exe utility, 790–792
 Regional and Language Options applet, 556
 Regional Options applet, 556
 regional settings, Windows 2000
 installation, 580–581
 registers, 116
 registration rollers, 393
 Registry
 device and service settings in, 685
 Emergency Repair Process, 853–854
 file associations, 619–620
 information in, 785–790
 overview, 550–551
 Plug and Play configuration, 712
 services in, 686
 troubleshooting, 817–818
 UnInstall key, 723
 Registry Editor, 787–792, 999–1000
 reinstallation, 21–22
 relative path, 650–653
 /release switch, 979

- Reliability and Performance utility, 759, 793
- Reliability Monitor, 759
- `rem` statement, 672–673
- Remote Assistance, 559–560
- Remote Desktop Connection, 558–559
- Remote Desktop Protocol (RDP), 558–559
- remote management, 794
- removable storage, 237–242
- Removable Storage Management utility, 793
- removing
 - device drivers, 708–709
 - Windows components, 605–606
- `ren` command, 656
- Rename option, local area connection
 - contextual menu, 954
- `/renew` switch, 979
- Repair option, local area connection
 - contextual menu, 954
- repairing Windows installations, 577
- Repeat Delay slider, Keyboard Properties dialog box, 330
- Repeat Rate slider, Keyboard Properties dialog box, 329–330
- repeater, 908–909
- repetitive strain injury (RSI), 42, 327–328
- Replace dialog box, 664–665
- replacing
 - keyboards, 451
 - laptop hard drives, 459
 - LCDs, 450
- Request for Comments (RFC), 1007–1008
- rescue CD, 472, 869–874
- rescue disk, 498
- rescue installation, 874–875
- rescue partition, 874–875
- reserve resources settings, 200–201
- reserving system resources, 382–383
- resistor, 37
- resolution
 - digital camera, 428
 - monitor, 56
 - video adapters, 348–349
- Resource Arbitrator, 711–712
- resource conflict, 365–366
- Resource Monitor, 755
- respect for customers, 27–28
- restarting Windows services, 997–998
- Restore and Manage Media tab, Backup or Restore Wizard, 861
- restore operations, testing, 1059
- restore points, 862–865
- restoring
 - backups, 861–862
 - to previous state with restore points, 865
 - user data files, 608–611
- retake policy, 16
- `/REVERT` switch, 800
- reviewing security logs, 1083–1084
- RFC (Request for Comments), 1007–1008
- RFI (radio frequency interference), 478
- RG (radio grade), 893
- ribbon cable, 85–86, 220–221, 305, 476
- rights, 1054, 1074–1076
- RIMM (rambus inline memory module), 159
- Ring 0 (kernel mode), 545
- Ring 3 (user mode), 545
- ring topology, 888
- RJ-11 connector, 312, 892
- RJ-45 connector, 312–313, 892
- RJ-45 port, 79–80
- `rmdir` command, 654
- rollback options, 716
- rollers, printer, 393, 485
- ROM (read-only memory), 72, 152–153, 173
- room temperature, 473
- root directories, 649
- routable protocol, 958
- router
 - default gateways, 965–966
 - overview, 910, 919
 - security, 918
 - wireless, 912–913
- RPM (Red Hat Package Manager), 532
- RS-232 port, 76
- RSI (repetitive strain injury), 42, 327–328
- rubber mouse ball, 453

Run command, 993
 Run Registry keys, 773
 Run setting, PIF Properties window, 737
 /rx:<folderpath> switch, 575

S

/S switch, 634, 636
 /s switch, 652
 /s:<path> switch, 575–576
 Safe Mode, 716, 818–819, 849–850
 Safe Mode with Command Prompt boot option, 850
 Safe Mode with Networking boot option, 850
 safety
 batteries, 442
 disposing of components, 40–42
 electromagnetic interference, 38
 electrostatic discharge, 36–38
 ergonomics, 42–43
 high-voltage equipment, 38–40
 overview, 33
 printers, 418
 tools, 33–36
 SAM key, 853–854
 Samba Network Neighborhood, 872
 SAS (Serial Attached SCSI), 49
 SATA (Serial ATA), 49–50, 86–87, 235–237, 287
 satellite Internet access method, 1031
 Save & Restore utility, 196
 Save As dialog box, 663–664
 saving files, via command prompt, 663–664
 SC (Subscriber connector) connector, 897
 /SCANBOOT switch, 800
 ScanDisk utility, 269
 scanner
 connecting, 425
 optimizing, 767–768
 overview, 423–424, 435
 preventive maintenance, 485–486
 scanning images, 425–427
 scanning process, 424–425
 Scanner and Camera Wizard, 429–430
 Scanners and Cameras applet, 556
 Scanners and Cameras Wizard, 426–427
 /SCANNOW switch, 800
 /SCANONCE switch, 800
 scans, hard drive, 482, 783–784
 scatter infrared, 402
 Schedule setting, printer Properties dialog box, 407
 scheduled maintenance, 470–471
 Scheduled Task Wizard, 801
 Scheduled Tasks applet, 557
 Scheduled Tasks folder, 801–802
 scheduling backups, 857–859
 SCP (Secure Copy Protocol), 1020
 .scr extension, 628
 scratches in optical media, 484
 screen flicker, 508
 screen projectors, 352
 Screen tab, PIF settings, 740–741
 screwdriver, 34, 495
 screws, 494–495
 SCSI (Small Computer System Interface)
 adapters, 225
 addressing, 227–229
 bus, 225
 cabling, 229
 chains, 233
 connections, 358, 402, 425
 controller, 88
 host adapter, 226–227
 IDs, 227–229, 233
 issues with, 812
 overview, 49, 225–232
 termination, 229–230
 types of, 230–232
 SCSI, ARC standard, 683
 SCSI-1, 230
 SD (Secure Digital) card, 241
 SDHC (Secure Digital High Capacity)
 card, 241

- SDRAM (synchronous DRAM), 158–159
- Search, Windows, 775–776
- SEC (Single Edge Contact), 66–67, 122–123, 129
- SECC (Single Edge Contact Connector), 129
- secondary corona wire, 394, 396
- Secondary Logon service, 770
- sector blocks, 211
- sector translation, 214
- sectors, 211
- Secure Copy Protocol (SCP), 1020
- Secure Digital High Capacity (SDHC) card, 241
- Secure Digital (SD) card, 241
- Secure File Transfer Protocol (SFTP), 1020
- secure shell (`ssh`), 1020–1021
- Secure Sockets Layer (SSL), 1018
- security
 - auditing, 1081–1084
 - authentication, 1051–1053
 - authorization, 1053–1054
 - best practices, 1090–1093
 - BIOS, 1067–1068
 - data, 1056–1062
 - disabling booting options, 193
 - driver installation permissions, 713–714
 - EFS, 246
 - FAT file system, 244
 - firewalls, 1084–1089
 - malicious software, 1102–1104
 - NAT devices, 970
 - overview, 1039, 1067–1096
 - pairing, 942
 - permissions, 1077–1080
 - physical, 1047–1050
 - rights, 1074–1076
 - server-based networking, 883–884
 - Small Office/Home Office network, 917–918
 - transmission, 1054–1056
 - types of attacks, 1039–1047
 - user accounts, 1068–1073, 1076–1077
 - viruses, 1097–1102
 - wireless networks, 936–941, 1092–1093
 - security bits, 495
 - Security Center applet, 557, 770
 - Security dialog box, 836
 - SECURITY key, 853–854
 - Security log, Event Viewer, 796
 - Security+ certification, 5
 - seek time, 213–214
 - Select User dialog box, 635
 - Select Users or Groups dialog box, 988
 - Self-Monitoring, Analysis and Reporting Technology (S.M.A.R.T.), 483
 - Sempron processor, 137
 - Separate-Video (S-Video) connector, 348
 - serial and parallel ports, 915
 - Serial ATA (SATA), 49–50, 86–87, 235–237, 287
 - Serial Attached SCSI (SAS), 49
 - serial cable, 316–317, 400
 - serial mouse, 332–333
 - serial port, 57, 75–76, 192–193, 302–303, 509–510
 - server
 - drive imaging, 569
 - network installations of Windows, 569
 - overview, 881
 - peer, 882
 - proxy, 1024–1025
 - Small Office/Home Office network, 917
 - Server Core Installation, 1020
 - Server service, 770, 998
 - server-based (client-server) network, 883–884
 - service documentation, 23
 - service load process, 686
 - Service Packs, Windows, 608, 816–817
 - Service Set Identifier (SSID), 930, 937
 - Services Administrative Tool, 769
 - Services console, 997–998
 - Services MMC snap-in, 828
 - Services tab, Task Manager, 757
 - Services utility, 793
 - session hijacking, 1045
 - Session layer, OSI, 905
 - Set as Default Printer option, print queue menu, 417

- set statement, 669–671
- setup boot disks, 568
- setup loader phase, Windows attended installation, 574, 577, 586, 591
- Setup Manager, 598–599
- setup program, Windows
 - problems starting, 601
 - Windows 2000, 577–585
 - Windows Vista, 591–596
 - Windows XP, 589–591
- setup switch, 575–576, 598–599
- Setupact.log file, 600
- Setupapi.log file, 600
- Setuperr.log file, 600
- Setuplog.txt file, 600
- SFTP (Secure File Transfer Protocol), 1020
- SFX v3.1 (Small Form Factor), 289
- SGRAM (Synchronous Graphics RAM), 350
- shadow RAM, 156
- shadowing, 156
- Share Name field, Sharing dialog box, 987
- Shared Folders utility, 793
- shares
 - hidden, 991–992
 - multiple, 992
- sharing
 - file system resources, 984–995
 - files/folders, 961, 985–991
 - printers, 994–996
- Sharing dialog box, 986–987
- Sharing option, printer Properties dialog box, 408–409
- sheetfeed scanner, 424
- shelf life, media, 484
- shielded twisted pair (STP) cable, 306, 890–891
- shock, 483
- shopping cart–transaction system, 1023
- Shortcut key setting, PIF Properties window, 737
- shorting probe, 40
- shutting down computers, 479
- Sidebar interface, Windows Vista, 529
- Signature, ARC standard, 683
- signed device driver, 709–710
- silver pins, 169
- SIMD (single instruction multiple data), 129–130
- SIMM (single inline memory module), 68–69, 160–162, 170–171
- Simple Mail Transport Protocol (SMTP), 1014
- simple volume, 253
- simplex communication, 913
- Single Edge Contact Connector (SECC), 129
- Single Edge Contact (SEC), 66–67, 122–123, 129
- single inline memory module (SIMM), 68–69, 160–162, 170–171
- single instruction multiple data (SIMD), 129–130
- single threaded applications, 754
- single threaded environment, 725
- single-channel configuration, 165–166
- single-mode fiber (SMF), 897
- single-ported memory, 350
- single-sided memory, 166
 - .sit extension, 627
- slave/master configuration, 222–224
- Sleep function key, 452
- sleep mode, 445–446
- slipstreaming, 608, 611
- slot 1, 66
- slot cover, 497
- slots, 74–75
- Small Computer System Interface. *See* SCSI
- Small Form Factor (SFX v3.1), 289
- Small Office/Home Office (SOHO) network, 916–918
- small outline dual inline memory module (SODIMM), 162, 171–172, 441, 458
- S.M.A.R.T (Self-Monitoring, Analysis and Reporting Technology), 483
- smart battery, 442
- smart card, 1052–1053
- smartphone, 452, 461
- smear printouts, 415
- SMF (single-mode fiber), 897

- SMTP (Simple Mail Transport Protocol), 1014
- snap-ins, 557. *See also names of specific snap-ins*
- social engineering attacks, 1040–1041
- socket services, 457
- sockets
 - identifying types of, 123–126
 - installing memory modules, 169–170
 - overview, 144
- SODIMM (small outline dual inline memory module), 162, 171–172, 441, 458
- soft power support, 94
- software firewall, 1087
- software key, 596, 853–854
- Software Update Service (SUS), 1105–1107
- SOHO (Small Office/Home Office) network, 916–918
- solenoid, 398
- solid-state storage medium, 50
- Sony/Philips Digital Interface Format (S/PDIF) connection, 320, 507
- Sound and Audio Devices Properties dialog box, 357
- sound card, 355–358, 507
- sound port, 79–80
- Sounds and Audio Devices applet, 557
- Sounds and Multimedia applet, 557
- Sounds applet, 557
- Sounds tab, Sound and Audio Devices Properties dialog box, 357
- South Bridge chip, 71–72
- spanned volume, 253
- S/PDIF (Sony/Philips Digital Interface Format) connection, 320, 507
- speaker port, 79–80
- speculative execution, 129
- Speech applet, 557
- spikes, voltage, 290
- spills, liquid, 476–477, 481, 505–506
- spinner, 227
- spoofing, 1043–1044
- Spool settings, printer Properties dialog box, 408
- spooling service, 408, 412–414, 767
- SPP (Standard Parallel Port) mode, 191
- spyware, 1103
- SQL injection, 1046
- SRAM (static RAM), 117, 155, 166, 173
- ssh (secure shell), 1020–1021
- SSID (Service Set Identifier), 930, 937
- SSL (Secure Sockets Layer), 1018
- ST (Straight tip) connector, 897
- standard DRAM, 157
- Standard Parallel Port (SPP) mode, 191
- standby mode, 445–446
- standby UPS, 292
- star topology, 886–887
- star-bus topology, 888
- Start menu, 558
- Start value, 685
- startup, Windows, 773
- Startup and Recovery dialog box, 875
- static charges, 36–37
- static RAM (SRAM), 117, 155, 166, 173
- Status option, local area connection contextual menu, 953
- StickyKeys option, Accessibility Options dialog box, 330–331
- stop bits, 510
- Stop errors, 833–836
- storage
 - devices for, 49–50, 58
 - ECHS, 214–215
 - of file attributes, 630–631
 - file systems, 243–247
 - IDE, 216–224
 - management tools, 267–272
 - overview, 209
 - partitions and volumes, 248–260
 - preventive maintenance, 483–484
 - RAID, 261–267
 - removable, 237–242
 - SATA, 235–237
 - SCSI, 225–234
 - terminology, 210–215
 - write process, 212–213
- storage unit, 243
- STP (shielded twisted pair) cable, 306, 890–891

Straight tip (ST) connector, 897
 stretching, 43
 striped volume, 253, 261
 stripper, wire, 497
 stylus, 453, 460–461, 518
 subnet mask, 964–965
 Subscriber connector (SC) connector, 897
 summary log, backup, 860
 Summary tab, PIF settings, 743
 Super VGA (SVGA) standard, 347
 Super XGA+ standard, 347
 superscalar design, 127–128
 suppressor, 290–294, 478–479
 SUS (Software Update Service), 1105–1107
 suspend mode, 445–446
 SVGA (Super VGA) standard, 347
 S-Video (Separate-Video) connector, 348
 swap file, 546–547, 739, 818–819
 swap process, 692–693
 switch-based keyboard, 326
 switches, 912, 1091–1092
 synchronous DRAM (SDRAM), 158–159
 Synchronous Graphics RAM (SGRAM), 350
 .sys extension, 628
 sysedit.exe file, 691
 System applet, 557
 System attribute, 631, 659
 system board. *See* motherboard
 System Configuration Editor, 691
 System Configuration utility, 785–786
 System File Checker, 799–800
 system files, 561, 627–628
 System Information tool, 543–544, 795
 SYSTEM key, 853–854
 system lockup, Windows, 836–837
 System log, Event Viewer, 796
 System Monitor, 759–762
 System Properties dialog box, 543
 System Recovery Options screen, 854
 System Rescue tools, 498
 system resources
 changing, 377–383
 conflicts, 376–377
 critical, 760–761
 direct memory access, 373–375
 I/O addresses, 364–367

IRQ, 368–373
 memory addresses, 375–376
 overview, 363–364
 system restore cache, 864
 System Restore Service, 770
 System Restore Wizard, 863–865
 System Summary screen, 189–190
 system.ini file, 688–690, 817
 systemroot command, 855

T

/t:<drive> switch, 575
 T1/T3 Internet access method, 1031
 tablet PC, 518
 Tag value, 685
 tape rotation, 1059
 tape storage, 241–242, 483
 .tar extension, 627
 Task Manager
 Applications tab, 758
 fixing corrupted memory space issues, 839
 fixing system lockup, 836–837
 Networking tab, 755–756
 overview, 752
 Performance tab, 752–755
 Processes tab, 756–757
 Services tab, 757
 terminating applications, 732
 Users tab, 758
 Task Scheduler utility, 770, 793, 800–802
 taskbar and notification area, 558
 Taskbar and Start Menu applet, 557
 taskkill.exe program, 764
 tasklist.exe program, 763–764
 TCP/IP (Transmission Control Protocol/Internet Protocol), 960, 966–967, 978–984, 1000, 1008, 1012–1013
 telnet access method, 1020, 1027
 /tempdrive:<drive> switch, 576
 temperature
 laptop, 449
 room, 473
 sensors, 120, 142

- template, default user, 791
- Temporal Key Integrity Protocol (TKIP), 938
- temporary files, 562, 768
- Terminal Services, 770
- terminal window, 533
- Terminate Stay Resident (TSR) programs, 688, 842–843
- termination, 229–230
- Termination settings, PIF Properties window, 741–742
- terminator, 231, 886
- terminology, use of, 25
- testing
 - changes, 21
 - computer parts, 19
 - related components, 22
 - rooms for, 14
- text-mode phase, Windows attended installation, 574, 577–579, 587–588
- TFT (thin-film transistor) display, 449
- TFX v2.2 (Thin Form Factor), 289
 - .tgz extension, 627
- theft, laptop, 485
- Themes service, 770, 772
- thermal compound, 142
- thermal printer, 399
- thermal sensor, 120, 142
- thermal stress, 473, 479
- thermometer, digital infrared, 496
- thick coax cable, 307
- Thicknet, 307, 892–893, 896
- thin coax cable, 307
- Thin Form Factor (TFX v2.2), 289
- thin-film transistor (TFT) display, 449
- Thinnet, 307, 313–314, 892–895
- third-party cookies, 1024
- threads, 119
- throttling, 120
- thumb drive, 240–241
 - .tif extension, 629
 - .tiff extension, 629
- time settings, 193
- timed exams, 10–11
- TKIP (Temporal Key Integrity Protocol), 938
- TLD (top-level domain), 1027–1028
 - .tmp extension, 629
- ToggleKeys option, Accessibility Options dialog box, 331
- token passing, 899
- token ring, 902–903
- Toliman processor, 137
- toner
 - cartridge, 393–394
 - disposing of, 41
 - overview, 418
- top-level domain (TLD), 1027–1028
- touch pad, 339–340, 452–453
- touch screen, 340
- trace route, 981
- TRACERT utility, 981
- trackpad, 517
- tracks, 211
- traffic, network, 756, 909
- training, vendor, 24
- transfer corona wire, 394, 396
- transfer rates
 - Blu-ray disc, 240
 - CD-ROM, 238
 - DVD, 240
 - network card, 337
 - SCSI technology, 230, 232
- transistor, 141–142
- translation factor, 215
- Transmission Control Protocol/Internet Protocol (TCP/IP), 960, 966–967, 978–984, 1000, 1008, 1012–1013
- transmission security, 1054–1056
- Transport layer, OSI, 906
- Travan, 242
- triple-core processor, 119
- Trojan horse, 1046, 1102
- trouble ticket system, 23
- troubleshooting
 - AC adapters, 448
 - applications, 745–746
 - audio, 507

batteries, 512–515
 BIOS, 501
 CD included with book, 1115–1116
 CD-ROM, 505
 CMOS, 501
 DVD-ROM, 505
 floppy drives, 502–503
 hard drives, 503–505
 keyboards, 505–507
 laptops, 461–462, 515–518
 memory, 501–502
 mice, 505–507
 modems, 509
 monitors, 507–509
 motherboards, 501
 network cabling, 898
 network connectivity, 980
 networks with TCP/IP, 978–984
 overview, 491, 499–500
 parallel ports, 509–510
 physical environment, 499–500
 power supplies, 512–515
 printers, 411–417
 procedures for, 17–24
 processors, 501–502
 serial ports, 509–510
 sound cards, 507
 system resources, 378–379
 tools for, 491–499
 USB, 511–512
 video, 507–509
 Windows, 600–601, 779–803, 827–843
 wireless networks, 943–944
 TrueType fonts, 738
 TSR (Terminate Stay Resident) programs, 688, 842–843
 .*ttf* extension, 628
 Turion 64 processor, 137–138
 Turion 64 X2 processor, 137–138
 TV tuner card, 434–435
 tweezers, 34
 twisted pair cable, 305–307, 890–892
 .*txt* extension, 629, 790
 Type A USB connector, 315

Type B USB connector, 315
 Type I PCMCIA card, 456
 Type II PCMCIA card, 457
 Type III PCMCIA card, 457
 Type value, 685
 typefaces, 561–562

U

/U switch, 634, 637
 /u:<filename> switch, 575
 UAC (User Account Control), 530, 1076–1077
 UDC (universal data connector), 902
 /udf:<id>, <filename> switch, 575–576
 Ultra DMA, 218–219
 Ultra SCSI, 232
 Ultra Wide SCSI, 232
 Ultra XGA, 347
 Ultra2 SCSI, 232
 Unallocated disk status, 260
 unattend file, 597–598
 /unattend:<filename> switch, 576
 unattended installations
 Windows 2000/XP/2003, 597–599
 Windows Vista, 599–600
 UNC (universal naming convention) path, 409, 993
 unicast network traffic, 756
 Uniform Resource Locator (URL), 1026
 UnInstall key, 723
 uninterruptible power supply (UPS), 290–294, 478–479, 832
 universal data connector (UDC), 902
 universal naming convention (UNC) path, 409, 993
 Universal Serial Bus. *See* USB
 Universally Unique Identifier (UUID), 197
 unshielded twisted pair (UTP) cable, 306–307, 890–891
 unsigned device driver, 709–710
 Update Driver Wizard, 951–952

- updating
 - BIOS, 153, 197–198
 - drivers, 472, 708
 - network drivers, 951–952
 - problems caused by, 501
 - ROM, 152–153
 - routers, 918
 - virus definitions, 1101–1102
 - Windows installation files, 607–608
 - Upgrade Advisor, 603–604
 - upgrading
 - BIOS, 183–185
 - laptops, 458–460
 - printer hardware, 403
 - Windows, 601–605
 - uploading pictures to computer, 429–430
 - UPS (uninterruptible power supply), 290–294, 478–479, 832
 - URL (Uniform Resource Locator), 1026
 - USB (Universal Serial Bus)
 - connectors, 315
 - external hard drives, 241, 459–460
 - flash drives, 240–241
 - hubs, 198
 - keyboards, 329
 - mice, 333
 - network adapters, 950–951
 - overview, 198, 359
 - ports, 57, 80–81, 303
 - printers, 401–402, 411
 - scanners, 425
 - troubleshooting, 511–512
 - User Account Control (UAC), 530, 1076–1077
 - user account security, 1068–1071
 - User Accounts applet, 557
 - user files, 561, 608–611
 - User Limit options, Sharing dialog box, 987
 - user mode, 545
 - user profile, 561
 - User State Migration Tool (USMT)
 - feature, 609
 - user template, default, 791
 - user-level access control, 985
 - user-related settings, 788
 - users, questioning of, 18–19
 - Users and Passwords applet, 557
 - Users tab, Task Manager, 758
 - USMT (User State Migration Tool)
 - feature, 609
 - UTP (unshielded twisted pair) cable, 306–307, 890–891
 - .uuu extension, 627
 - .uuu extension, 627
 - UUID (Universally Unique Identifier), 197
-
- ## U
-
- VA (volt-amps), 293
 - vacuum, computer, 471–472
 - vampire tap, 896
 - .vbs extension, 625
 - VBScript (Visual Basic Script), 802
 - vendor manuals, 23
 - vendor training, 24
 - ventilation
 - external, 473–474
 - internal, 474–476
 - monitors, 481
 - overview, 473
 - printers, 486
 - troubleshooting, 500
 - ver command, 661–662, 674
 - Verify Data after Backup option, Backup Job Information window, 858
 - verifying Windows installation, 600–601
 - versions
 - of Linux, 531–532
 - of Macintosh OS, 534–535
 - of Windows, 526–527, 542–545
 - vertical lines on printouts, 415
 - VESA (Video Electronics Standard Association), 100
 - VESA local bus (VLB), 100
 - VGA (Video Graphics Array), 347
 - vibration, 483

video
 standards, 346–347
 troubleshooting, 507–509

video adapter
 AGP, 103
 built-in coprocessors, 348
 installing, 350–351
 overview, 55–56, 77–78, 345–351
 problems with, 508–509
 resolution, 348–349
 special connectors, 347–348
 supported colors, 349
 types of, 359
 VESA, 100
 video memory, 349–350
 video standards, 346–347

video board, 441

video capture card, 434–435

video card port, 78

Video Electronics Standard Association (VESA), 100

Video Graphics Array (VGA), 347

video memory, 349–350

video port, 57, 78, 346

Video RAM (VRAM), 156, 350

Virtual DOS Machine (NTVDM), 730

virtual memory, 118, 542, 546–548, 691–694, 765–766

Virtual Memory dialog box, 548, 766

Virtual Memory Manager (VMM), 546–547, 692–694

Virtual PC, 244

Virtual Private Network (VPN), 939–940

virtual zoom, 429

viruses
 CMOS, 199–200
 Office macro security settings, 1098–1099
 overview, 842–843, 1046–1047, 1097
 protection from, 1099–1101
 scans for, 482
 types of, 1097–1098
 updating definitions, 1101–1102

Visual Basic Script (VBScript), 802

VLB (VESA local bus), 100

VMM (Virtual Memory Manager), 546–547, 692–694

Voice tab, Sound and Audio Devices
 Properties dialog box, 357

VoIP (Voice over IP), 906

volatile memory, 154, 156

voltage
 conversion of, 280
 input supply, 281
 input-under, 281
 noncontact indicator, 513
 processor, 138

voltage regulator module (VRM), 120–121

volt-amps (VA), 293

volts, 279

Volume attribute, 632

Volume Control dialog box, 433

Volume Label field, Format dialog box, 257

Volume Shadow Copy, 770, 859

Volume tab, Sound and Audio Devices
 Properties dialog box, 357

volumes
 creating, 250–255
 drive status, 260
 formatting, 255–258

VPN (Virtual Private Network), 939–940

VRAM (Video RAM), 156, 350

VRM (voltage regulator module), 120–121
 .vxd extension, 628

W

/W switch, 637

/w switch, 652

wait time, 166

Wake on LAN (WoL), 447

WAN (wide area network), 884–885, 942

WAN-cellular, 455

WAP (wireless access point), 889, 912–913

warm swapping, 712

watts, 280
 .wav extension, 629

Web browser. *See* Internet Explorer

- Web camera, 430–431
- Web sites
 - CompTIA, 13
 - CompTIA IT Pro, 13
 - EPA, 40
 - filters for, 916
 - overview, 1027–1029
 - researching on, 24
- WEP (Wired Equivalent Privacy), 938
- white stripes on printouts, 415
- wide area network (WAN), 884–885, 942
- Wide SCSI-2, 232
- Widescreen Ultra Extended Graphics Array (WUXGA), 347
- Wi-Fi Protected Access (WPA), 938–939
- wildcards, 649–650
- Win16Mutex flag, 729
- Window RAM (WRAM), 156, 350
- Windows
 - applications, 726–734, 743–745
 - boot errors, 811–816
 - components of, 545–551, 605–606
 - configuring TCP/IP in, 966–967
 - dual-boot systems, 607
 - errors, 816–823
 - file locations, 561–562
 - file sharing, 985–986
 - GUI elements, 529–530
 - installing, 567–601, 607–608
 - memory management, 542
 - navigating computer, 551–555
 - optimizing, 751–776
 - overview, 526, 541–542, 567
 - printer sharing, 985–986, 994–996
 - restore points, 862–865
 - system requirements, 527–528
 - tools, 555–560
 - troubleshooting, 779–803, 827–843
 - upgrading, 601–605
 - user data files, 608–611
 - versions of, 526–527, 542–545
- Windows 2000
 - boot process, 680–686
 - folder sharing, 986–988
 - installing, 575–586, 597–599
 - upgrading to, 602–603
- Windows 2003, installing, 597–599
- Windows 9x, 527
- Windows Easy Transfer, 609, 611
- Windows Explorer, 553–554
- Windows Features window, 606
- Windows Firewall applet, 557
- Windows Firewall/Internet Connection Sharing (ICS) service, 770
- Windows Installer service, 770
- Windows Internet Naming System (WINS), 972–973
- Windows keyboard, 327
- Windows Media Connect applet, 557
- Windows NT, 527, 602–603
- Windows on Windows (WOW), 727, 729
- Windows Script Host, 802
- Windows Search, 775–776
- Windows Server 2003, 961
- Windows shortcut keys, PIF Properties window, 743
- Windows Sockets (Winsock) interface, 1013
- Windows Software Update Services (WSUS), 1105–1107
- Windows Update, 702–703, 708, 1105
- Windows Update Driver Settings dialog box, 702–703
- Windows Vista
 - boot process, 686–687
 - folder sharing, 990–991
 - installing, 591–597, 599–600
 - upgrading to, 604–605
 - wireless network connections, 931–932
- Windows XP
 - boot process, 680–686
 - folder sharing, 989–990
 - installing, 586–591, 597–599
 - upgrading to, 603–604
 - wireless network connections, 931
- win.ini file, 690–691, 817
- winload.exe file, 687, 815
- WinMSD.exe tool, 795
- winnt32.exe program, 575–576, 599, 602–603
- winnt.exe program, 575, 599

WINS (Windows Internet Naming System), 972–973

Winsock (Windows Sockets) interface, 1013

wiping, 1057

wire cutters, 497

wire strippers, 497

Wired Equivalent Privacy (WEP), 938

wireless access point (WAP), 889, 912–913

wireless attacks, 1045–1046

wireless cut-off switch, 462

Wireless dialog box, 931

wireless Internet access method, 1031–1032

wireless keyboard, 333

Wireless Link applet, 557

wireless mouse, 333

wireless network card, 454

Wireless Network Connection Status dialog box, 931–932

Wireless Network Setup Wizard applet, 557

wireless networking

- auditing tools, 944
- components of, 929–930
- connecting to, 931–932
- overview, 928
- performance, 942–943
- printers, 401
- security, 918, 936–941
- Small Office/Home Office, 917
- standards, 904–905, 932–935
- troubleshooting, 943–944

wireless router, 912–913, 916–917

Wireless Status dialog box, 931

wireless topology, 889–890

wireless wide area network (WWAN), 942

Wireless Zero Configuration service, 770

- .wk4 extension, 626
- .wks extension, 626

WoL (Wake on LAN), 447

word recognition issues, 518

workgroup, 571–572, 971

workgroup or computer domain options, Windows 2000 installation, 584

Working Directory setting, PIF Properties window, 737, 841

Workstation service, 770, 998

World Wide Web (www), 1029

worm, 1047, 1102–1103

WORM (write once read many) disc, 239

WOW (Windows on Windows), 727, 729

WPA (Wi-Fi Protected Access), 938–939

- .wpd extension, 626
- .wpg extension, 626

WRAM (Window RAM), 156, 350

wrist strap, ESD, 37, 493–494

writable CD, 238–239

write once read many (WORM) disc, 239

wscript.exe utility, 802

WSUS (Windows Software Update Services), 1105–1107

WUXGA (Widescreen Ultra Extended Graphics Array), 347

WWAN (wireless wide area network), 942

www (World Wide Web), 1029

X

/X switch, 637

/x switch, 652

x64 (64-bit) processor, 526

x86 (32-bit) processor, 526

xcopy command, 655–656, 674

Xeon processor, 131–132

XGA (Extended Graphics Array), 347

- .xls extension, 626
- .xlsx extension, 626

XML (Extensible Markup Language), 1017–1018

XMS (Extended) memory, 740

XT keyboard, 327

Z

ZIF (zero insertion force) socket, 66–67, 121–122, 139–140

zip drive, 238

.zip extension, 627

zoom, camera, 428–429

